

- Manuals.plus /
- › VASAGLE /
 - › VASAGLE TV Stand LTV071B01V1 - Assembly and User Manual

VASAGLE LTV071B01V1

VASAGLE TV Stand LTV071B01V1 - Assembly and User Manual

Model: LTV071B01V1 | Brand: VASAGLE

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your new VASAGLE TV Stand, model LTV071B01V1. Please read all instructions carefully before beginning assembly and retain this manual for future reference. This TV stand features a robust design with adjustable shelves, barn doors, and a rustic brown and black finish, suitable for TVs up to 65 inches.



Image 1.1: The VASAGLE TV Stand LTV071B01V1 in a modern living room.

2. SAFETY INFORMATION

- Children are not permitted to climb or play on the TV stand for safety reasons.
- Please secure the TV stand to the wall using the included anti-tipping kit (item 31) for enhanced safety and stability.
- Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum load capacities specified in the 'Specifications' section.
- Place the TV stand on a level, stable surface to prevent tipping.

3. PACKAGE CONTENTS

Before assembly, verify that all parts and hardware are present and undamaged. Refer to the parts list provided in the assembly guide included in your package. If any parts are missing or damaged, please contact customer support.

- Wooden panels (labeled A-M)
- Metal frames and supports (labeled N-Q)
- Hardware (screws, dowels, cam locks, anti-tipping kit, etc., labeled 1-51)
- Assembly tools (Allen key, screwdriver)

4. ASSEMBLY INSTRUCTIONS

Follow the step-by-step instructions below and refer to the assembly video for visual guidance. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

Your browser does not support the video tag.

Video 4.1: Official VASAGLE LTV071B01V1 TV Stand Assembly Guide. This video provides a visual walkthrough of the entire assembly process, from identifying parts to securing the unit.

Step-by-Step Assembly:

1. **Prepare the Base:** Attach the bottom panel (B) to the back support (J) using screws (9). Ensure the pre-drilled holes align.
2. **Install Side Panels:** Secure the side panels (D, E, F, G) to the bottom panel using dowels (1) and screws (46).
3. **Attach Top Panel:** Place the top panel (C) onto the assembled structure, aligning the dowels and securing with screws (51).
4. **Add Metal Frames:** Attach the X-shaped metal frames (Q) to the sides of the unit using screws (44).
5. **Insert Adjustable Shelves:** Place the adjustable shelves (K, L) into the desired positions using the shelf pins (13).
6. **Assemble Barn Doors:** Attach the sliding door hardware (R) to the barn doors (M) using screws (38, 46).
7. **Install Sliding Doors:** Carefully hang the assembled barn doors onto the metal tracks (O) on the front of the TV stand.
8. **Final Checks and Safety:** Ensure all connections are tight. Install the anti-tipping kit (31) to secure the TV stand to the wall.

5. OPERATING INSTRUCTIONS

Storage and Organization:

- **Adjustable Shelves:** The TV stand features adjustable shelves behind the barn doors and in the open compartments. To adjust, remove the shelf pins (13), reposition the shelf to the desired height, and reinsert the pins.
- **Barn Doors:** The barn doors slide smoothly on metal tracks, allowing you to conceal or display items as needed. Gently slide the doors along the track.
- **Cable Management:** Utilize the two cable holes located on the back panel to route and organize your electronic device cables, keeping them tidy and out of sight.

VASAGLE



Image 5.1: Detail of the open shelf area, highlighting space for audio/video equipment.

Estante abierto

Mucho espacio para equipos de audio o vídeo



Image 5.2: The barn doors slide smoothly on metallic guides.

6. MAINTENANCE

- **Cleaning:** Wipe the surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish.

- **Dusting:** Regularly dust the unit with a dry, soft cloth to prevent dust buildup.
- **Inspection:** Periodically inspect all hardware connections to ensure they remain tight. Re-tighten any loose screws to maintain stability.
- **Avoid Moisture:** Do not place hot items directly on the surface. Protect the unit from excessive moisture and direct sunlight.

7. TROUBLESHOOTING

- **Wobbly Unit:** If the TV stand feels wobbly, check that all screws are fully tightened. Ensure the unit is on a level surface; adjust the adjustable feet if necessary.
- **Doors Not Sliding Smoothly:** Check the metal tracks for any obstructions or debris. Ensure the door hardware is correctly installed and tightened.
- **Missing Parts:** If you discover any missing parts during assembly, refer to the package contents list and contact VASAGLE customer support for assistance.

8. SPECIFICATIONS

Feature	Detail
Model Number	LTV071B01V1
Dimensions (W x D x H)	147 x 40 x 76 cm (57.9 x 15.7 x 29.9 inches)
Weight	31.9 kg (70.3 lbs)
Material	Particleboard, Steel
Max. Static Load Capacity (Top Board)	65 kg (143.3 lbs)
Max. Static Load Capacity (Total)	91 kg (200.6 lbs)
Compatible TV Size	Up to 65 inches
Assembly Required	Yes

Distribución razonable

Para organizar eficazmente todos tus objetos

- ❶ Estante ajustable
- ❷ Puerta corredera estilo granero
- ❸ Apto para televisores de hasta 65 pulgadas
- ❹ Puede acomodar altavoces largos
- ❺ Gran espacio de almacenamiento
- ❻ Orificios para la gestión de cables



Image 8.1: Detailed dimensions of the TV stand.



Image 8.2: Visual guide for TV size compatibility (up to 65 inches).

9. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please refer to the contact details provided in your product packaging or visit the official VASAGLE website. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BWXYCR7M>

More documents and user manuals: <https://manuals.plus/>