

ENERGETIC SMARTER LIGHTING MTSL1001AHB

ENERGETIC SMARTER LIGHTING LED Desk Lamp User Manual

Model: MTSL1001AHB

1. INTRODUCTION

Thank you for purchasing the ENERGETIC SMARTER LIGHTING LED Desk Lamp. This manual provides important information regarding the setup, operation, maintenance, and troubleshooting of your new desk lamp. Please read this manual thoroughly before using the product and retain it for future reference.

This LED desk lamp features a flexible gooseneck for adjustable lighting, eye-protection technology, and an energy-efficient design, making it ideal for bedrooms, home offices, and study areas.





Figure 1: ENERGETIC SMARTER LIGHTING LED Desk Lamp (Black)

This image shows the black ENERGETIC SMARTER LIGHTING LED Desk Lamp with its flexible gooseneck and round base, featuring a classic design suitable for various settings.

2. SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Do not expose the lamp to water or moisture.
- Ensure the power outlet voltage matches the lamp's requirements (AC-120V).
- Do not attempt to disassemble or modify the lamp. There are no user-serviceable parts inside.
- Keep the lamp away from heat sources and direct sunlight.
- Place the lamp on a stable, flat surface to prevent it from tipping over.

- Unplug the lamp from the power outlet before cleaning or if it will not be used for an extended period.
- This lamp is designed for indoor use only.

3. PACKAGE CONTENTS

Please check the package contents upon unboxing. If any items are missing or damaged, contact customer support.

- ENERGETIC SMARTER LIGHTING LED Desk Lamp (1 unit)
- User Manual (this document)

4. SETUP

Setting up your LED desk lamp is quick and easy:

1. Carefully remove the lamp and all packaging materials from the box.
2. Place the lamp on a stable, flat, and dry surface, such as a desk or table.
3. Uncoil the power cord and plug it into a standard AC-120V electrical outlet.
4. The lamp is now ready for use.



Figure 2: Lamp Dimensions and Power Cord

This image illustrates the dimensions of the desk lamp (height, base width, head dimensions) and the length of its power cord, providing a visual guide for placement and setup.

5. OPERATING INSTRUCTIONS

Your ENERGETIC SMARTER LIGHTING LED Desk Lamp is designed for simple and intuitive operation.

5.1 Power On/Off

- Locate the power switch on the base of the lamp.
- Flip the switch to the "ON" position to turn on the lamp.
- Flip the switch to the "OFF" position to turn off the lamp.

5.2 Adjusting the Light Angle

The lamp features a flexible gooseneck, allowing you to direct the light precisely where needed.

- Gently bend the gooseneck to adjust the lamp head to your desired angle and height.
- The 360° adjustable design ensures you can find the perfect lighting position for reading, working, or studying.

Multi-Angle Adjustable Design

Flexible gooseneck, easy to find the perfect lighting angle



Figure 3: Multi-Angle Adjustable Design

This image demonstrates the flexible gooseneck, showing how the lamp head can be bent and positioned at various angles to provide optimal lighting.

5.3 Eye-Protection Feature

The lamp is equipped with high-quality LED chips that provide non-flickering light, designed to protect eyesight and reduce fatigue during prolonged use.

Eye-Protection

No flicker, no dark area, protect your eyes from fatigue



Figure 4: Eye-Protection Feature in Use

This image shows the desk lamp in use, illuminating a child's workspace, highlighting its eye-protection feature by providing uniform, flicker-free light.

6. MAINTENANCE

To maintain your lamp's performance and appearance, follow these simple guidelines:

- **Cleaning:** Disconnect the lamp from the power outlet before cleaning. Use a soft, dry cloth to wipe the lamp's surface. Do not use abrasive cleaners, solvents, or harsh chemicals.
- **Bulb Replacement:** This LED desk lamp uses integrated LED chips and does not require bulb replacement. The LEDs are designed for a long lifespan.



Note: No bulb to replace ever

Figure 5: Integrated LED Design

This close-up image of the lamp head emphasizes that the LED light source is integrated and does not require traditional bulb replacement, simplifying maintenance.

7. TROUBLESHOOTING

If you encounter issues with your lamp, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lamp does not turn on.	- Power cord not securely plugged in. - Power outlet is not functioning. - Lamp switch is in the "OFF" position.	- Ensure the power cord is firmly plugged into both the lamp and the wall outlet. - Test the outlet with another device to confirm it has power. - Flip the power switch to the "ON" position.
Light flickers or is dim.	- Unstable power supply. - Lamp malfunction.	- Try plugging the lamp into a different outlet. - If the issue persists, contact customer support.

If the problem persists after trying these solutions, please contact customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	ENERGETIC SMARTER LIGHTING
Model Number	MTSL1001AHB
Power Consumption	3.5 Watts
Luminous Flux	240 Lumens
Color Temperature	4000K (Cool White)
Input Voltage	AC-120V
Product Dimensions	11.94 x 11.94 x 39.78 cm (4.7 x 4.7 x 15.66 inches)
Item Weight	730 g
Finish Type	Painted
Base Material	Metal
Shade Material	Plastic
Switch Type	Foot (on base)
Certifications	ETL Listed

9. WARRANTY AND SUPPORT

ENERGETIC SMARTER LIGHTING is committed to providing quality products. For any questions, concerns, or issues regarding your LED Desk Lamp, please contact us directly through the Amazon message box.

Our team has over 50 years of professional knowledge and exploration in lighting to assist you.
Please retain your purchase receipt as proof of purchase for any warranty claims.

© 2023 ENERGETIC SMARTER LIGHTING. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question