



[Manuals.plus](#) /

> [vidaXL](#) /

> vidaXL Garden Planter with Trellis Instruction Manual

## vidaXL 318268

# vidaXL Garden Planter with Trellis Instruction Manual

Model: 318268

## INTRODUCTION

Thank you for choosing the vidaXL Garden Planter with Trellis. This manual provides essential information for the safe assembly, operation, and maintenance of your new planter. Please read these instructions carefully before use and retain them for future reference. This planter is designed for outdoor use to support climbing plants and enhance your garden, balcony, or terrace.

## SAFETY INFORMATION

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all components are securely fastened before use.
- Keep small parts away from children during assembly.
- Do not overload the planter with excessive weight beyond its intended capacity.
- This product is designed for outdoor use only.

## PACKAGE CONTENTS

Your vidaXL Garden Planter with Trellis package should contain the following main components:

- Planter base sections
- Trellis panels
- Connecting rods/studs
- Assembly hardware (screws, caps, etc.)


*Note: Please check all parts against the included parts list (if provided in your physical package) before beginning assembly.*

## ASSEMBLY INSTRUCTIONS


Assembly is required for this product. Follow these general steps for construction. It is recommended to have a soft mallet or rubber hammer available, as some connections may require firm pressure to ensure a secure fit.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat, and soft surface to prevent damage. Verify all parts are present.
2. **Assemble Planter Base:** Connect the side panels of the planter base. Ensure the textured (wicker-like) exterior faces outwards. The connections are designed to fit snugly; apply firm, even pressure or gently tap with a rubber mallet if needed.

3. **Attach Bottom Panel:** Secure the bottom panel to the assembled planter sides. Ensure it is fully seated to provide a stable base.
4. **Install Trellis Supports:** Insert the vertical support rods for the trellis into the designated slots on the planter base.
5. **Attach Trellis Panels:** Slide the trellis panels onto the vertical supports. Align the holes and secure them with the provided hardware (e.g., screws or clips). Ensure the trellis is upright and stable.
6. **Final Check:** Once assembled, gently shake the planter to ensure all connections are secure and the structure is stable.



**Image:** Dimensional diagram of the planter and trellis. This image illustrates the overall height of 47.8 inches (121.5 cm) and the base dimensions of 15.7 inches (40 cm) by 15.7 inches (40 cm). It also shows the internal depth of the planter box.



**Image:** Front view of the assembled vidaXL Garden Planter with Trellis. This image shows the black planter box with its woven texture and the two trellis panels above it, ready for climbing plants.

## OPERATING AND USAGE

The vidaXL Garden Planter with Trellis is designed to enhance your outdoor living spaces and support plant growth.

- **Placement:** Position the planter in your desired outdoor location, such as a garden, balcony, or terrace. Ensure it is on a stable, level surface.
- **Planting:** Fill the planter box with appropriate potting soil. Plant your desired flowers or climbing plants.
- **Trellis Support:** Guide climbing plants (e.g., tomatoes, peas, roses, ivy) to grow up the integrated trellis. The trellis provides vertical support, maximizing space and creating lush displays.

- **Watering:** Note that this planter does **not** have built-in drainage. Monitor soil moisture carefully to prevent overwatering, which can lead to root rot. Consider adding a layer of gravel at the bottom or drilling drainage holes if necessary, depending on your plant's needs and environment.



**Image:** The vidaXL Garden Planter with Trellis placed against a white brick wall, showcasing climbing plants growing up the trellis. This demonstrates typical outdoor usage.

## MAINTENANCE

The vidaXL Garden Planter with Trellis is constructed from durable, weather-resistant polypropylene (PP) for long-lasting outdoor use.

- **Cleaning:** To clean the planter, simply wipe it down with a damp cloth. Mild soap can be used for stubborn dirt, then rinse thoroughly. Avoid abrasive cleaners or harsh chemicals.
- **Weather Resistance:** The polypropylene material is designed to resist fading, cracking, and warping from sun and rain, ensuring it remains functional and aesthetically pleasing throughout the year.
- **Seasonal Care:** While weather-resistant, consider moving the planter to a sheltered location during extreme weather conditions (e.g., heavy snow, strong winds) to prolong its lifespan.



**Image:** Close-up view of the black polypropylene planter box, highlighting its woven texture and durable material.

## TROUBLESHOOTING

---

If you encounter issues during assembly or use, consider the following:

- **Difficulty with Assembly:** Some parts are designed for a very snug fit to ensure stability. If components are difficult to connect, ensure they are correctly aligned. A rubber mallet can be used to gently tap parts into place. Avoid excessive force that could cause damage.
- **Loose Connections:** If the assembled planter feels unstable, re-check all connection points. Ensure all studs and fasteners are fully inserted and secured.
- **Damaged Parts:** If any parts arrived damaged or broken, do not attempt to force them. Contact vidaXL customer support for replacement parts.
- **Water Drainage Issues:** As the planter does not have pre-drilled drainage holes, ensure you are not overwatering. If drainage is a

persistent issue, you may carefully drill small holes in the bottom of the planter for excess water to escape.

## SPECIFICATIONS

<b>Brand</b>	vidaXL
<b>Model Number</b>	318268
<b>Material</b>	Polypropylene (PP)
<b>Color</b>	Black
<b>Dimensions (W x D x H)</b>	15.75" x 15.75" x 47.83" (40 cm x 40 cm x 121.5 cm)
<b>Item Weight</b>	8.16 pounds (3.71 kg)
<b>Special Feature</b>	Weather Resistant
<b>Indoor/Outdoor Usage</b>	Outdoor Only
<b>Drainage</b>	No
<b>Included Components</b>	Planter, Trellis

## WARRANTY AND SUPPORT

For warranty information, replacement parts, or technical support, please contact vidaXL customer service directly. Refer to your purchase documentation or the official vidaXL website for contact details.

