

ROSMARINO PRO 1000

ROSMARINO NutriMax PRO 1000 Blender User Manual

Model: PRO 1000

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the ROSMARINO NutriMax PRO 1000 Blender. Failure to follow these safety guidelines may result in injury or damage to the appliance.

- **Electrical Safety:** Ensure the voltage rating on the appliance matches your local power supply before connecting. Do not immerse the motor base in water or other liquids. Unplug the blender from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- **Blade Safety:** The blades are sharp. Handle the blade assembly with extreme care to avoid injury. Never touch the blades while the appliance is plugged in or operating.
- **Hot Liquids:** When blending hot liquids, use caution. Hot liquids can scald. Do not fill the blending cup beyond the maximum fill line for hot ingredients.
- **Children:** This appliance is not intended for use by children. Close supervision is necessary when any appliance is used near children.
- **Proper Assembly:** Always ensure the blending cup and blade assembly are correctly and securely attached to the motor base before operation. Do not operate the blender with an empty cup.
- **Overload Protection:** The blender is equipped with an overload protection system. If the motor stops due to overloading, unplug the unit, remove some ingredients, and allow it to cool for 15 minutes before restarting.
- **Maintenance:** Do not attempt to repair the appliance yourself. Contact qualified service personnel for any repairs.

2. PRODUCT OVERVIEW

The ROSMARINO NutriMax PRO 1000 Blender is designed for efficient blending of various ingredients. Familiarize yourself with its components:

- **Motor Base:** Contains the 1000W motor and control mechanism.
- **Blending Cup (700ml):** The container for ingredients.

- **Blade Assembly:** Stainless steel blades for processing.
- **To-Go Lid:** For sealing the blending cup for transport.

In weniger als 60 Sekunden zu einem gesunden Blender NutriMax PRO 1000



1000 W



Edelstahlklingen



700 ml



In 60 Sekunden zu
einem Getränk



Deckel für die
Mahlzeit unterwegs



Overview of the NutriMax PRO 1000 Blender components and key features, including the 1000W motor, stainless steel blades, 700ml capacity, and to-go lid.

FÜR GENAUE ERGEBNISSE



Detail of the stainless steel blade assembly, designed for uniform consistency and a creamy effect.

3. SPECIFICATIONS

Feature	Specification
Brand	ROSMARINO
Model	PRO 1000
Motor Power	1000 Watts
Voltage	220-240V
Frequency	50-60Hz
RPM	24000
Blending Cup Capacity	700 Milliliters
Materials	ABS, PP, Stainless Steel, Aluminum

Feature	Specification
Dimensions (L x W x H)	20 x 20 x 40 cm
Weight	2.78 Kilograms
Dishwasher Safe Parts	Blending cup and to-go lid (top rack)
Warranty	2 years



Visual representation of the blender's dimensions: base height 20 cm, container height 18 cm, total height 40 cm, width 20 cm.

4. ASSEMBLY

Assembling your NutriMax PRO 1000 Blender is a simple three-step process:

- 1. Prepare Ingredients:** Add your desired ingredients into the blending cup. Do not overfill beyond the maximum fill line.
- 2. Attach Blade Assembly:** Screw the blade assembly securely onto the open end of the blending cup. Ensure it is tightened to prevent leaks.
- 3. Place on Motor Base:** Invert the blending cup with the attached blade assembly and place it onto

the motor base. Align the tabs on the cup with the slots on the base. Press down firmly and twist clockwise until it locks into place.



The image demonstrates the 'Turn, Push Down, and Blend' action for operating the blender.

5. OPERATION

Once assembled, the NutriMax PRO 1000 is ready for use. The blender operates by pressing down on the blending cup.

General Blending

- Ensure the blending cup is securely attached to the motor base.
- Plug the blender into a power outlet.
- Press down on the blending cup to activate the motor. Release pressure to stop.
- Blend until desired consistency is achieved. The blender processes ingredients in under 60 seconds.

Crushing Ice and Frozen Ingredients

The powerful motor and stainless steel blades are capable of crushing ice and frozen fruits.

- For optimal results, add a small amount of liquid (water, milk, or juice) to the blending cup along with

the ice or frozen ingredients.

- Blend in short pulses until the desired consistency is reached.



The NutriMax PRO 1000 is capable of crushing ice for refreshing beverages. Add liquid before blending ice.

Versatile Preparations

The NutriMax PRO can prepare various items including:

- Juices, smoothies, and protein shakes.
- Pesto, spice blends, and sauces.
- Pancake batter and salad dressings.
- Vegetable soups (ensure soups are partially cooled before blending).
- Baby food.




Examples of various preparations possible with the blender, including smoothies, sauces, baby food, and soups.

On-the-Go Use

The blender includes a 'to-go' lid, allowing users to blend and transport beverages in the same container.

- After blending, remove the blade assembly and replace it with the to-go lid.
- Ensure the lid is securely fastened before transport.



The convenient to-go lid allows for easy transport of blended drinks, suitable for active lifestyles.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and hygienic operation of your blender.

Quick Cleaning Method

- After use, rinse the blending cup.
- Fill the blending cup with warm water and add a small amount of dish soap.
- Attach the blade assembly and place the cup on the motor base.
- Operate the blender for a few seconds.
- Rinse thoroughly with clean water.

Detailed Cleaning

- **Blending Cup and To-Go Lid:** These parts are dishwasher safe and can be placed on the top rack of your dishwasher.
- **Blade Assembly:** Clean the blade assembly carefully under running water. Use a brush to remove any food residue. Avoid touching the sharp blades directly.

- **Motor Base:** Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid.
- Ensure all parts are completely dry before storing or reassembling.

7. TROUBLESHOOTING

If you encounter issues with your NutriMax PRO 1000 Blender, refer to the following common problems and solutions:

- **Blender does not turn on:**
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Verify that the blending cup and blade assembly are correctly and securely attached to the motor base. The blender has a safety interlock that prevents operation if not properly assembled.
 - Check if the motor has overheated due to prolonged use or overloading. Unplug the unit and let it cool down for at least 15 minutes before attempting to use it again.
- **Ingredients are not blending smoothly:**
 - Add more liquid to the blending cup.
 - Reduce the amount of ingredients to avoid overloading.
 - Cut larger ingredients into smaller pieces before blending.
 - Use short pulses to break down stubborn ingredients.
- **Blender is leaking:**
 - Ensure the blade assembly is tightly screwed onto the blending cup.
 - Do not overfill the blending cup beyond the maximum fill line.
 - Check for any damage to the blade assembly gasket or the blending cup.

If the problem persists after trying these solutions, please contact customer support.

8. WARRANTY

The ROSMARINO NutriMax PRO 1000 Blender comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

The warranty does not cover damage resulting from misuse, neglect, accident, alteration, or unauthorized repair. Please retain your proof of purchase for warranty claims.

9. CUSTOMER SUPPORT

For further assistance, product inquiries, or warranty claims, please contact ROSMARINO customer support. Refer to the product packaging or the official ROSMARINO website for contact details.