

**B0BWYVB5S7**

# 32-Piece Presser Foot Set User Manual

Model: B0BWYVB5S7

## INTRODUCTION

---

This manual provides essential information for the proper use and maintenance of your 32-piece presser foot set. This comprehensive collection of presser feet is designed to enhance the functionality of most low shank domestic sewing machines, including various Babylock, Bernina (Bernette Series), Brother, Elna, Euro-Pro, Juki, Home, Pacesetter, Pfaff, Simplicity, Singer, Viking (Huskies series), and White models.

The set includes a universal low shank snap-on adapter, making it a versatile addition to your sewing accessories. Please read this manual thoroughly before use to ensure optimal performance and longevity of your presser feet.



Image: The complete 32-piece presser foot set neatly organized within its clear plastic storage box.

## PRODUCT CONTENTS

---

Your 32-piece presser foot set comes with a variety of specialized feet, each designed for specific sewing tasks. The set is stored in a durable, clear plastic box with a foam insert for protection and organization. An instruction guide is also included.

The set consists of the following presser feet:





Image: An assortment of the 32 individual presser feet, showcasing their various designs and functions.

1. Braiding Foot
2. Fringe Foot
3. 5 Hole Cording Foot
4. 7 Hole Cording Foot
5. Edge Joining Foot
6. 1/4" Quilting Foot
7. Straight Stitch Foot
8. Open Toe Embroidery Foot
9. Round Bead Foot
10. Zig Zag Foot
11. Cording Foot
12. 1/4" Quilting Foot (another one)
13. Pintuck Foot 9 Grooves
14. Overcast Foot
15. Stitch Guide Foot

16. Pintuck Foot 5 Grooves
17. Satin Stitch Foot
18. Zig Zag Foot, JAGUAR
19. Double Welting Foot
20. Concealed Zipper Foot
21. Roller Foot
22. Blind Stitch Foot
23. Applique Foot
24. Open Toe Foot
25. Shirring Foot, Low Shank
26. Gathering / Welting Foot
27. Hemmer Foot
28. Round Hemmer Foot
29. Darning Foot, Low Shank
30. Adjustable Bias Binder Foot
31. Knit Foot
32. Zipper Foot, Low Shank
33. Universal low shank adapter

## SETUP AND INSTALLATION

---

Before installing any presser foot, ensure your sewing machine is turned off and unplugged for safety. Most domestic sewing machines utilize a low shank system, which is compatible with this set. The included universal low shank adapter allows for easy snap-on attachment of many feet.





Image: The presser foot set with the clear plastic box lid open, revealing the foam insert and organized feet.

### General Installation Steps:

1. **Identify Shank Type:** Confirm your sewing machine has a low shank. This set is not suitable for industrial, old, or mini sewing machines.
2. **Remove Current Foot:** Loosen the screw holding the current presser foot in place and carefully remove it.
3. **Attach Adapter (if needed):** If using a foot that requires the universal low shank adapter, attach the adapter to your machine's presser foot bar first. Secure it with the screw.
4. **Attach New Foot:** Align the new presser foot with the adapter or the presser foot bar (if directly attaching). Lower the presser foot lever to snap it into place or tighten the screw.
5. **Test:** Gently lower the needle to ensure it clears the foot opening without obstruction.

For detailed instructions specific to your sewing machine model, please refer to your machine's user manual.

### OPERATING INSTRUCTIONS

Each presser foot in this set is designed for a specific sewing technique. Understanding the function of each foot will help you achieve professional results. The included instruction guide provides basic guidance for each foot.

## General Usage Tips:

- **Select the Correct Foot:** Choose the presser foot that matches the specific sewing task (e.g., zipper foot for zippers, quilting foot for quilting).
- **Adjust Machine Settings:** After attaching a new foot, adjust your sewing machine's stitch type, stitch length, stitch width, and tension as recommended for the specific technique. Refer to your sewing machine's manual for guidance on these adjustments.
- **Practice:** Before working on your main project, practice with scrap fabric to familiarize yourself with the new foot and its effect on the stitch.
- **Needle Compatibility:** Ensure your needle type and size are appropriate for the fabric and the chosen presser foot.

For detailed instructions on how to use each specific presser foot, consult the instruction guide provided with the set and your sewing machine's user manual.

## MAINTENANCE AND CARE

---

Proper maintenance will extend the life of your presser feet and ensure their continued performance.

### Cleaning:

- After each use, gently wipe the presser feet with a soft, dry cloth to remove any lint, dust, or fabric fibers.
- For stubborn residue, a slightly damp cloth can be used, but ensure the feet are thoroughly dried immediately to prevent rust, as they are made of steel.
- Avoid using harsh chemicals or abrasive cleaners, which can damage the finish or material.

### Storage:

- Always store the presser feet in the provided clear plastic box with the foam insert. This protects them from damage, dust, and keeps them organized.
- Store the box in a dry environment to prevent moisture buildup, which could lead to corrosion.

## TROUBLESHOOTING

---

Most issues encountered when using presser feet can be resolved by checking basic settings and proper installation.

### Common Issues and Solutions:

- **Stitch Irregularities:**
  - Ensure the correct presser foot is selected for the stitch type.
  - Verify that the presser foot is securely attached and not loose.
  - Check your sewing machine's tension, stitch length, and stitch width settings.
- **Needle Hitting Foot:**
  - Confirm the presser foot is correctly aligned and fully attached.
  - Ensure the needle is the correct type and size for your machine and fabric.
  - Adjust the needle position or stitch width if your machine allows.
- **Fabric Not Feeding Properly:**
  - Check if the presser foot is appropriate for the fabric thickness and type.
  - Ensure the feed dogs are engaged (not dropped).
  - Verify presser foot pressure is correctly set on your machine (if adjustable).

If you continue to experience issues, consult your sewing machine's user manual or contact a qualified sewing machine technician.

## SPECIFICATIONS

Material	Steel
Use	Sewing
Type	Sewing Machine Parts
Compatibility	Most low shank domestic sewing machines (e.g., Babylock, Bernina (Bernette Series), Brother, Elna, Euro-Pro, Juki, Home, Pacesetter, Pfaff, Simplicity, Singer, Viking (Huskies series), White)
Quantity	32 presser feet + 1 universal low shank adapter (33 pieces total)
Storage	Clear plastic box with foam insert
Origin	Made in Taiwan
ASIN	B0BWYVB5S7
Manufacturer	Generic
Date First Available	Feb. 27 2023

## WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or technical support for your 32-piece presser foot set, please refer to the seller or manufacturer directly. Contact details are typically available on your purchase receipt or the product listing page.

As this product is manufactured by "Generic," specific warranty terms may vary depending on the retailer from whom it was purchased. It is recommended to retain your proof of purchase for any warranty claims or support inquiries.