

Luxform 20191.000.00

Luxform Amsterdam Solar Wall Lamp Instruction Manual

Model: 20191.000.00

INTRODUCTION

This manual provides essential information for the safe and efficient installation, operation, and maintenance of your Luxform Amsterdam Solar Wall Lamp. Please read these instructions carefully before installation and retain them for future reference.

The Luxform Amsterdam wall lamp is designed to illuminate houses, sheds, garages, summer pavilions, and other outbuildings. With a light output of 30 lumens, it provides sufficient light for various outdoor areas. Its sleek and square design makes it an ideal addition to modern gardens.

SETUP AND INSTALLATION

1. Unpacking

- Carefully remove all components from the packaging.
- Verify that all parts are present and undamaged. The package should include the lamp fixture and a wall bracket.

2. Choosing a Location

- Select a location on a wall that receives direct sunlight for at least 6-8 hours daily. This is crucial for the solar panel to charge the battery effectively.
- Avoid locations under eaves, trees, or other obstructions that might shade the solar panel.

3. Mounting the Lamp

The lamp can be easily attached to the wall using the included wall bracket.

1. Mark the desired mounting points on the wall using the wall bracket as a template.

2. Drill pilot holes at the marked points.
3. Insert appropriate wall plugs (if necessary for your wall type).
4. Secure the wall bracket to the wall using screws.
5. Attach the Luxform Amsterdam Solar Wall Lamp to the secured wall bracket. Ensure it is firmly seated.



Image: Luxform Amsterdam Solar Wall Lamp mounted on a wall, showcasing its design and installation.

4. Initial Charge

Allow the lamp to charge in direct sunlight for at least 24-48 hours before its first use. This ensures the internal battery reaches its full capacity.

OPERATING INSTRUCTIONS

The Luxform Amsterdam Solar Wall Lamp operates automatically. It features a built-in light sensor that detects ambient light levels.

- **Daytime:** During daylight hours, the solar panel converts sunlight into electricity, which is stored in the internal rechargeable battery. The lamp will remain off.
- **Nighttime:** As dusk falls and ambient light decreases, the light sensor will activate the lamp, causing it to illuminate automatically. It will remain lit until dawn or until the battery charge is depleted.



Image: Luxform Amsterdam Solar Wall Lamps illuminated at night.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your solar wall lamp.

- **Cleaning the Solar Panel:** Periodically wipe the solar panel with a soft, damp cloth to remove dust, dirt, and debris. A clean solar panel ensures maximum sunlight absorption and efficient battery charging.
- **Cleaning the Lamp Housing:** Clean the lamp's metal housing and glass panels with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Battery:** The lamp contains an integrated rechargeable battery. Do not attempt to replace the battery yourself unless specified by the manufacturer. Improper handling can damage the product or cause injury.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not light up at night.	Insufficient solar charge.	Ensure the solar panel receives 6-8 hours of direct sunlight daily. Clean the solar panel if dirty. Allow 24-48 hours for initial charge.
Lamp lights up dimly or for a short duration.	Partial solar charge or environmental factors.	Relocate the lamp to an area with more direct sunlight. Ensure the solar panel is clean. Cold weather can affect battery performance.

Problem	Possible Cause	Solution
Lamp remains on during the day.	Light sensor obstructed or faulty.	Check if anything is covering the light sensor. Ensure the lamp is not installed near other bright light sources that might interfere with the sensor.

PRODUCT SPECIFICATIONS

- **Brand:** Luxform
- **Model Number:** 20191.000.00
- **Dimensions:** 12 cm (L) x 12 cm (W) x 24 cm (H)
- **Material:** Metal
- **Light Output:** 30 lumens
- **Mounting Type:** Wall mounting
- **Components Included:** Lamp fixture, wall bracket




Image: Dimensions of the Luxform Amsterdam Solar Wall Lamp.

WARRANTY INFORMATION

This product is covered by the manufacturer's standard warranty. Please refer to the warranty documentation provided with your purchase or contact Luxform directly for specific warranty terms and conditions. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Luxform Amsterdam Solar Wall Lamp, please contact Luxform customer service. Contact details can typically be found on the product packaging or the official Luxform website.

© 2023 Luxform. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question