

Razor Razor A, Razor A2

Razor A and A2 Kick Scooter User Manual

Model: Razor A, Razor A2

1. IMPORTANT SAFETY INFORMATION

Before operating your Razor A or A2 Kick Scooter, please read and understand all instructions and warnings. Scooter riding can be a hazardous activity. Always wear appropriate safety gear, including a helmet, knee pads, and elbow pads. Adult supervision is recommended for young riders.

- Always wear a helmet when riding.
- Do not ride at night.
- Avoid riding on wet surfaces, uneven terrain, or loose debris.
- Maintain a safe distance from vehicles and pedestrians.
- Check all components before each ride to ensure they are securely fastened and in good working order.
- The Razor A2 scooter includes a wheelie bar for tricks; however, always practice tricks in a safe, open area away from traffic and obstacles.

2. SETUP AND ASSEMBLY

Your Razor A or A2 Kick Scooter comes mostly assembled. Follow these steps to prepare your scooter for use.

2.1 Unfolding the Scooter

The scooter features an original folding mechanism for quick and easy transport and storage. To unfold:

1. Place the scooter on a flat surface.
2. Locate the folding mechanism near the front wheel.
3. Release the quick-release lever or button as per the specific model's design.
4. Carefully pull the handlebar stem upwards until it locks into place. Ensure the locking mechanism is fully engaged before riding.



Image: The folding mechanism allows for compact storage and easy transport.

2.2 Adjusting the Handlebars

The adjustable handlebars can be set to the perfect ride height for the user.

1. Locate the quick-release clamp on the handlebar stem.
2. Open the clamp.
3. Slide the handlebar T-bar up or down to the desired height. The handlebar should be approximately at waist level when standing on the scooter.
4. Close the quick-release clamp securely. Ensure there is no wobble in the handlebars before riding.



Image: The quick-release clamp for adjusting handlebar height.

3. OPERATING INSTRUCTIONS

Familiarize yourself with the scooter's controls and proper riding techniques.

3.1 Riding the Scooter

1. Place one foot firmly on the deck of the scooter, near the front.
2. Push off with your other foot to gain momentum.
3. Once moving, place your pushing foot behind the front foot on the deck.
4. Steer by leaning gently in the desired direction and turning the handlebars.



Image: A child demonstrating the correct riding posture on the scooter.

3.2 Braking

The scooter features a rear braking system.

1. To slow down or stop, gently press your heel down on the rear fender brake.
2. Apply pressure gradually to avoid sudden stops, which can cause loss of balance.



Image: The rear fender brake mechanism for stopping.

3.3 Razor A2 Specific Features

The Razor A2 model includes additional features:

- **Vibration Dampening Front Suspension:** This system provides a smoother ride by absorbing impacts from uneven

surfaces.

- **Wheelie Bar:** Located at the rear, this bar is designed for performing tricks. Use with caution and in appropriate environments.



Image: The front suspension system on the Razor A2 scooter for enhanced comfort.

4. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your scooter.

- **Cleaning:** Wipe down the scooter with a damp cloth after use. Avoid harsh chemicals.
- **Wheel Check:** Periodically inspect wheels for wear and tear. Replace worn wheels promptly.
- **Bearings:** Ensure wheel bearings spin freely. If they are stiff or noisy, they may need cleaning or replacement.
- **Fasteners:** Regularly check and tighten all nuts, bolts, and quick-release mechanisms.
- **Brake:** Ensure the rear brake functions correctly and is not excessively worn.

5. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Scooter does not fold/unfold easily:** Check for obstructions in the folding mechanism. Ensure the quick-release lever is fully disengaged.
- **Handlebars wobble:** Tighten the quick-release clamp on the handlebar stem. If wobble persists, inspect the internal locking mechanism.
- **Wheels are noisy or do not spin freely:** Inspect for debris caught in the wheels or bearings. Clean or replace bearings if necessary.
- **Brake is ineffective:** Check the rear fender brake for wear. Ensure it makes proper contact with the wheel.

6. SPECIFICATIONS

Feature	Detail
Brand	Razor
Model Name	Razor A, Razor A2
Frame Material	Aluminum

Number of Wheels	2
Wheel Material	Polyurethane
Wheel Type	Solid
Handlebar Type	Adjustable
Brake Style	Rear Braking
Special Feature	Lightweight (Razor A), Lightweight, Front Suspension, Wheelie Bar (Razor A2)
Recommended Use	Kid's transportation

7. WARRANTY INFORMATION

This Razor A and A2 Kick Scooter comes with a Limited Warranty. For specific details regarding coverage, duration, and claims process, please refer to the warranty card included with your product or visit the official Razor website.

8. CUSTOMER SUPPORT

For further assistance, replacement parts, or any questions not covered in this manual, please contact Razor Customer Service:

- **Website:** www.razor.com
- **Phone:** Refer to the contact information on the Razor website for your region.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question