



Manuals.plus /

› KOOKOO /

› KOOKOO MoriMori Design Lamp with Loudspeaker (Model MM1013GB) Instruction Manual

## KOOKOO MM1013GB

# KOOKOO MoriMori Design Lamp with Loudspeaker (Model MM1013GB) Instruction Manual

## 1. PRODUCT OVERVIEW

---

The KOOKOO MoriMori Design Lamp with Loudspeaker, Model MM1013GB, combines the aesthetic of a classic gas lamp with modern LED lighting and Bluetooth speaker technology. This portable device is designed for both indoor and outdoor use, offering dimmable light and integrated audio functionality.



Image 1.1: The KOOKOO MoriMori Design Lamp with Loudspeaker, showcasing its classic lantern design and green-black finish.

### Key Features:

- Integrated LED lamp with dimmable light.
- Built-in loudspeaker for audio playback.
- Rechargeable battery providing up to 10 hours of operating time.
- Micro-USB charging interface.
- Splash-proof design for versatile use.

## 2. PACKAGE CONTENTS

---

Please verify that all items are present in the package:

- 1 x KOOKOO MoriMori Design Lamp with Loudspeaker
- 1 x Glass Shade
- 1 x Micro-USB Charging Cable (not explicitly listed but implied by charging port)
- 1 x Instruction Manual (this document)



Image 2.1: The MoriMori lamp displayed alongside its original cylindrical packaging.

### 3. SETUP

---

#### 3.1 Initial Charging

1. Locate the Micro-USB charging port on the base of the lamp.
2. Connect the provided Micro-USB cable to the lamp's charging port.
3. Connect the other end of the USB cable to a compatible USB power adapter (5V-1A recommended) or a computer USB port.
4. Allow the lamp to charge fully before first use. The charging indicator light (if present) will change color or turn off once charging is complete.



Image 3.1: Detail of the Micro USB 5V-1A charging port on the base of the lamp.

### 3.2 Attaching the Glass Shade

Carefully place the glass shade over the LED light source, ensuring it sits securely on the lamp's base.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Light Operation

1. **Power On/Off:** Locate the power button or switch, typically on the base of the lamp. Press and hold or toggle to turn the light on or off.
2. **Dimming:** The lamp features a dimmer function. Rotate the designated knob or press the appropriate button to adjust the brightness level of the LED light.



Image 4.1: Several MoriMori lamps demonstrating their illuminated state.

## 4.2 Loudspeaker Operation (Bluetooth)

1. **Power On Speaker:** Ensure the lamp is powered on. The speaker function is usually activated simultaneously or via a separate button. A sound or indicator light will confirm the speaker is active.
2. **Pairing Mode:** The speaker will automatically enter Bluetooth pairing mode when first turned on or if no device is connected. An indicator light (often blue) will flash, and an audible prompt may be heard.
3. **Connect Device:** On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings. Search for available devices and select "MoriMori" or a similar name.
4. **Confirmation:** Once successfully paired, the indicator light will typically become solid, and an audible confirmation will sound.
5. **Audio Playback:** Play audio from your connected device. Volume can be controlled via your device or, if available, a volume control on the lamp itself.



Image 4.2: A detailed view of the speaker grille located at the base of the lamp.

## 5. CHARGING

---

To recharge the internal battery:

1. Connect the Micro-USB cable to the lamp's charging port and a 5V-1A USB power source.
2. The charging process will begin automatically.
3. A full charge provides approximately 10 hours of combined light and speaker operation, though actual duration may vary based on brightness and volume levels.

## 6. MAINTENANCE

---

### 6.1 Cleaning

- Ensure the device is turned off and unplugged before cleaning.
- Wipe the exterior surfaces with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.
- For the glass shade, carefully remove it and clean with a mild glass cleaner if necessary, then dry thoroughly before reattaching.

### 6.2 Water Resistance

The lamp is splash-proof. This means it can withstand light splashes of water but should not be submerged in water or exposed to heavy rain. Ensure the Micro-USB port cover is securely closed when not charging to maintain splash resistance.

## 7. TROUBLESHOOTING

---

- **Light not turning on:**
  - Ensure the battery is charged. Connect the lamp to a power source.
  - Check if the power button/switch is correctly engaged.
- **Speaker not connecting via Bluetooth:**
  - Ensure the lamp's speaker is in pairing mode (indicator light flashing).
  - Turn off and on your device's Bluetooth, then try searching again.
  - Make sure the lamp is within range of your device (typically 10 meters).
  - Disconnect any other devices currently paired with the lamp.
- **Battery not charging:**
  - Verify the Micro-USB cable is securely connected to both the lamp and the power source.
  - Try a different USB cable or power adapter.
  - Ensure the power source is functional.
- **Low audio quality or distortion:**
  - Reduce the volume on both the lamp and your connected device.
  - Ensure there are no obstructions between the lamp and your Bluetooth device.
  - Check for interference from other electronic devices.

## 8. SPECIFICATIONS

Feature	Specification
Model Number	MM1013GB
Dimensions (L x W x H)	13.39 x 5.91 x 6.06 inches (34 x 15 x 15.4 cm)
Item Weight	1.1 pounds (0.5 Kilograms)
Power Source	Battery Powered
Battery Type	1 Lithium Polymer battery required
Operating Life	Up to 10 hours
Charging Interface	Micro USB (5V-1A)
Light Type	LED
Special Features	Dimmable, Energy Efficient, Splash Proof
Shade Material	Glass
Color	Green-Black
Manufacturer	KooKoo GmbH

## 9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the contact details provided with your purchase documentation or visit the official KOOKOO website. Keep your proof of purchase for warranty claims.

