

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [SoBuy](#) /
- › [SoBuy FSR66-DG Storage Bench Instruction Manual](#)

SoBuy FSR66-HG

SoBuy FSR66-DG Storage Bench Instruction Manual

1. PRODUCT OVERVIEW

The SoBuy FSR66-DG Storage Bench is a versatile and modern furniture piece designed to enhance your hallway, living room, or bedroom. It features a comfortable, removable seat cushion, two spacious fabric baskets, and two convenient drawers, offering ample storage solutions for various items.

This bench is ideal for sitting comfortably while putting on or taking off shoes, organizing footwear, linens, toys, keys, and other small essentials, helping to keep your space tidy and organized.



Image 1.1: The SoBuy FSR66-DG storage bench in a hallway setting, showcasing its design and functionality.

2. ASSEMBLY INSTRUCTIONS

Your SoBuy FSR66-DG Storage Bench is delivered in a flat-pack format and requires assembly. Please follow the detailed instructions provided in the packaging carefully. Ensure all components are present before beginning assembly.

1. **Unpack all components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify all parts and hardware:** Compare the contents with the parts list in your instruction manual to ensure nothing is missing.
3. **Follow the step-by-step diagrams:** Assemble the bench according to the numbered steps and diagrams provided in your specific assembly guide.
4. **Tighten all fasteners:** Once assembled, ensure all screws and connectors are securely tightened for stability. Do not overtighten.
5. **Attach the seat cushion:** Place the removable seat cushion on top of the bench.

For optimal stability and safety, it is recommended to have two people for assembly.



Image 2.1: The assembled SoBuy FSR66-DG storage bench in an entryway, ready for use.

3. USAGE GUIDELINES

The SoBuy FSR66-DG Storage Bench is designed for practical use in various home environments.

- **Seating:** The bench provides a comfortable seating area with its removable cushion. It is suitable for one adult or two children. The maximum weight capacity for seating is 150 kg.
- **Fabric Baskets:** The two fabric baskets are fully removable and ideal for storing shoes, small blankets, toys, or other household items. Simply slide them in and out of their compartments as needed.
- **Drawers:** The two integrated drawers offer additional enclosed storage for smaller items such as keys, wallets, shoe polish, or accessories. Pull the handles to open and push to close.



Image 3.1: Demonstrating the removable seat cushion for easy access or cleaning.



Image 3.2: A close-up of a fabric storage basket, highlighting its capacity for various items.



Image 3.3: An open drawer, illustrating the additional storage space for smaller essentials.

4. CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your SoBuy FSR66-DG Storage Bench.

- **Cleaning the Frame:** Wipe the wooden frame with a dry, soft cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Cushion Care:** The fabric cushion can be spot cleaned with a mild detergent and a damp cloth. Allow to air dry completely. Do not machine wash or tumble dry the cushion.
- **Basket Care:** The fabric baskets can be spot cleaned. For deeper cleaning, they may be gently hand washed and air dried.
- **Regular Checks:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the wood and fabric.

5. TROUBLESHOOTING

If you encounter any issues with your storage bench, please refer to the following common troubleshooting tips:

- **Bench feels wobbly:** Check all assembly screws and ensure they are tightened securely. Make sure the bench is placed on a flat, even surface.
- **Drawers are stiff or not sliding smoothly:** Ensure the drawer runners are correctly aligned and free from obstructions. Check if any items inside the drawer are preventing it from closing properly.
- **Fabric baskets are misshapen:** Gently reshape the baskets by hand. If they become soiled, follow the cleaning instructions in Section 4.
- **Scratches or minor damage to the frame:** For minor scratches, a furniture repair pen or touch-up paint matching the grey finish can be used.

6. PRODUCT SPECIFICATIONS

Feature	Specification
Model Number	FSR66-HG
Brand	SoBuy
Dimensions (L x W x H)	100 x 35 x 50 cm
Weight	20 kg
Maximum Weight Recommendation	150 kg
Material	MDF, Particle Board, Fabric
Frame Material	Engineered Wood
Color	Grey
Style	Modern
Seat Height	50 cm
Care Instructions	Wipe with a dry cloth




Image 6.1: Detailed dimensions of the SoBuy FSR66-DG storage bench.

7. WARRANTY AND SUPPORT

SoBuy products are manufactured to high-quality standards. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For technical support, missing parts, or any other inquiries regarding your SoBuy FSR66-DG Storage Bench, please contact SoBuy customer service through their official website or the retailer from whom you purchased the product. Provide your model number (FSR66-HG) and purchase details to assist with your inquiry.