

[Manuals.plus](#) /

> [Philips Lighting](#) /

> Philips Meranti 4x35W Spotlight Bar User Manual

Philips Lighting 46535000

Philips Meranti 4x35W Spotlight Bar User Manual

Model: 46535000 | Brand: Philips Lighting

1. INTRODUCTION

The Philips Meranti 4 ceiling spotlights are designed to blend effortlessly into any room with their timeless and high-quality design. Featuring four flexible spotlights, the lighting can be individually adjusted to create a pleasant ambiance. This manual provides essential information for the safe and efficient use of your Philips Meranti spotlight bar. Please read it thoroughly before installation and operation.

2. SAFETY INFORMATION

Always follow basic safety precautions when installing and operating electrical products.

- Ensure power is disconnected at the main circuit breaker before installation, maintenance, or bulb replacement.
- Installation should be performed by a qualified electrician if you are unsure about electrical wiring.
- Do not exceed the specified maximum wattage of 35W per bulb.
- Keep the fixture away from water and excessive moisture.
- For light bulb recycling information, refer to official local recycling guidelines.
- For information on cleaning up broken or damaged lamps, refer to relevant safety protocols for glass and electrical components.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x Philips Meranti 4x35W Spotlight Bar (Leuchte)
- Mounting Bracket
- User Manual (this document)

Note: GU10 bulbs are sold separately. The manufacturer recommends four Philips LED GU10 spotlights, each with 5.5W.

4. SETUP AND INSTALLATION

Follow these steps for proper installation of your Meranti ceiling spotlight:

1. **Preparation:** Ensure the power supply to the installation area is turned off at the main circuit breaker.
2. **Mounting the Bracket:** Secure the mounting bracket to the ceiling using appropriate screws and anchors (not included, but standard for ceiling light installations).
3. **Wiring:** Connect the electrical wires from the ceiling to the fixture's wiring terminals according to local electrical codes. Ensure proper grounding.
4. **Attaching the Fixture (ClickFix):** Thanks to the innovative ClickFix function, the light fixture can be easily attached to the mounted bracket with a simple click. Align the fixture with the bracket and push firmly until it locks into place.
5. **Installing Bulbs:** Insert GU10 bulbs (sold separately) into each of the four spotlight sockets. Ensure they are securely twisted into place.
6. **Final Check:** Once installed, restore power and test the light fixture.



Image: The Meranti spotlight bar, showing the four adjustable spotlights ready for installation.




Image: Technical drawing illustrating the dimensions of the Meranti spotlight bar (Length: 67.4 cm, Width: 8 cm, Height: 15 cm).

5. OPERATING INSTRUCTIONS

The Meranti spotlight bar is designed for simple operation.

- **Power On/Off:** Control the light fixture using a standard wall switch connected to the circuit.
- **Adjusting Spotlights:** Each of the four spotlights can be individually swiveled and tilted to direct light precisely where needed. Gently adjust the spotlight heads to achieve your desired lighting effect.



Image: The Meranti spotlight bar installed on a ceiling, casting light onto a wall, demonstrating its illumination capabilities in a room setting.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Meranti spotlight bar, follow these maintenance guidelines:

- **Cleaning:** Disconnect power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, harsh chemicals, or solvents.
- **Bulb Replacement:** Ensure power is off and bulbs have cooled before replacing. Replace with GU10 bulbs of the specified wattage (max 35W per bulb).
- **Inspection:** Periodically check for any loose connections or visible damage. If any issues are found, consult a qualified electrician.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power supply; Loose wiring; Faulty bulb.	Check circuit breaker. Ensure all electrical connections are secure. Replace bulb.
Light flickers.	Loose bulb; Incompatible bulb; Voltage fluctuations.	Tighten bulb. Ensure bulb type is GU10 and compatible. Consult electrician if voltage issues persist.
Spotlight head is stiff to adjust.	Dust or debris accumulation; Mechanism wear.	Gently clean around the swivel mechanism. Do not force adjustment. If issue persists, contact support.

8. SPECIFICATIONS

Brand	Philips Lighting
Model Number	46535000 (Item model number: 929003253801)
Manufacturer	Signify
Product Dimensions (L x W x H)	67.4 x 8 x 15 cm
Item Weight	670 g
Material	Metal (Meranti)
Voltage	230 Volts (AC)
Max Wattage per Bulb	35W
Socket Type	GU10
Recommended Bulb Type	LED
Special Features	Energy Efficient, Swivel Spot Head, ClickFix Installation

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Philips Lighting website or contact their customer service directly.

Online Support: Visit the [Philips Store on Amazon](#) for product information and support resources.

Manufacturer: Signify

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BX479RQR>

More documents and user manuals: **<https://manuals.plus/>**