Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok AR-JW1 AR-JW3

Azwok AR-JW1 AR-JW3 Remote Control User Manual for Fujitsu Air Conditioners


Model: AR-JW1 AR-JW3

1. Introduction

This manual provides comprehensive instructions for the Azwok AR-JW1 AR-JW3 replacement remote control, designed for use with various Fujitsu Air Conditioner models. This remote control is ready to use without any programming; simply install batteries, and it will function immediately.

Compatible Fujitsu Air Conditioner Models:

- AR-DB3/DB4/DB7
- AR-JW17
- AST9RSGCW
- AR-DB1
- AWT24LBAJ
- AWT30LBAJ
- AOT24LMADL
- AOT30LMADL
- AR-DL1
- AR-DB5
- AR-DL2
- AR-HG2
- AR-JW19
- AR-JW2
- AR-BB1
- BB9




MASTER CONTROL
SET TEMP.
SET TIME
FAN CONTROL
SET
SWING
SET
SWING
TIME ADJUST ACL
START/STOP

Figure 1: Front view of the Azwok AR-JW1 AR-JW3 remote control, showing the display and main control buttons.

2. Setup: Battery Installation

To begin using your remote control, you must first install the batteries.

1. **Locate the Battery Compartment:** Turn the remote control over. The battery compartment is located on the back, typically at the bottom section.
2. **Open the Cover:** Slide the battery compartment cover downwards or press the release tab (if present) and lift the cover.
3. **Insert Batteries:** Insert two (2) AAA batteries into the compartment. Ensure that the positive (+) and negative (-) ends of the batteries align correctly with the markings inside the compartment. Incorrect polarity can prevent the remote from functioning.
4. **Close the Cover:** Slide the battery compartment cover back into place until it clicks securely.

Important Battery Information:

- Do not mix old and new batteries.
- Do not mix different types of batteries (e.g., alkaline and rechargeable).
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.


(-) polarities correctly.
MODEL :
OPEN



Figure 2: Back view of the remote control, illustrating the battery compartment and proper battery insertion.

3. Operating Instructions

Familiarize yourself with the buttons and their functions for optimal control of your Fujitsu Air Conditioner.



Figure 3: Angled view of the remote control, showing the layout of the operational buttons.

Button Name	Function
START/STOP	Powers the air conditioner on or off.
SLEEP	Activates or deactivates the sleep mode, which adjusts temperature for comfortable sleep.
TIMER	Used to set the automatic on/off timer for the air conditioner.
MASTER CONTROL	Cycles through various operating modes such as Cool, Heat, Fan, Dry, or Auto.
SET TEMP (+/-)	Increases or decreases the desired temperature setting.
SET TIME (+/-)	Adjusts the time for timer settings.
FAN CONTROL	Adjusts the fan speed (e.g., Low, Medium, High, Auto).

Button Name	Function
SET SWING	Controls the horizontal movement of the air conditioner's louvers.
SWING (Vertical Icon)	Controls the vertical movement of the air conditioner's louvers.
TIME ADJUST ACL	Typically a recessed button used for time adjustment or resetting certain settings. Use a thin, pointed object to press.

4. Maintenance

Proper maintenance ensures the longevity and reliable operation of your remote control.

- **Battery Replacement:** Replace batteries when the remote's performance degrades, the display becomes dim, or the remote stops responding. Always replace both batteries simultaneously with new AAA batteries.
- **Cleaning:** Clean the remote control with a soft, dry cloth. Do not use liquid cleaners, solvents, or abrasive materials, as these can damage the remote's surface or internal components.
- **Storage:** Store the remote in a dry place, away from direct sunlight and extreme temperatures.

5. Troubleshooting

If you encounter issues with your remote control, refer to the following common solutions:

- **Remote Not Responding:**
  - Check if the batteries are inserted with correct polarity (+ and -).
  - Replace the batteries with a fresh pair of AAA batteries.
  - Ensure there are no obstructions between the remote control's infrared emitter and the air conditioner's receiver.
  - Verify that your air conditioner model is listed as compatible in the Introduction section.
- **Limited Operating Range:**
  - Replace the batteries, as low battery power can reduce the remote's effective range.
  - Ensure the infrared emitter on the front of the remote is clean and unobstructed.
- **Air Conditioner Model Not Listed:** If your specific Fujitsu air conditioner model is not explicitly listed as compatible, please contact Azwok customer support for assistance in confirming suitability.

6. Specifications

Feature	Detail
Product Dimensions	6.1 x 2.17 x 0.59 inches
Item Weight	2.11 ounces
Batteries Required	2 AAA batteries (not included)

Feature	Detail
Connectivity Technology	Infrared
Max Number of Supported Devices	1
Special Feature	No Programming Required

7. Warranty and Support

Azwok is committed to providing reliable products and customer satisfaction.

- **Warranty:** This remote control is covered by a 12-month replacement warranty from the date of purchase.
- **Returns/Exchanges:** Returns are accepted for refund or exchange if the remote control does not function with your specified devices.
- **Customer Support:** If you have any questions regarding compatibility, operation, or require assistance, please contact Azwok customer service. We are available to help you choose the correct remote or resolve any issues you may encounter.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BX5C32T2

More documents and user manuals: **https://manuals.plus/**