

Zyyini Zyyiniadye30vfou

Zyyini MP3 Player User Manual

Model: Zyyiniadye30vfou

1. INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your Zyyini MP3 Player. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your user experience.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x MP3 Player
- 1 x Headphones
- 1 x Charging Cable

6 Worth buying Key selling points



Video playing



Music's play



E-Book



Radio



Record



File
management

Image: The Zyyini MP3 Player shown with its included headphones and charging cable.

3. PRODUCT FEATURES

The Zyyini MP3 Player offers a range of functionalities designed for a versatile multimedia experience:

- **HiFi Stereo Sound:** Equipped with HD speakers and advanced sound decoding chips for clear audio.
- **Bluetooth 5.0 Connectivity:** Provides faster speeds, longer connection distances, and enhanced anti-interference capabilities. *Note: This device acts as a Bluetooth transmitter and cannot pair with phones or computers.*
- **Compact Design:** Features a 1.77-inch TFT color display, making it portable and easy to read.
- **Expandable Memory:** Supports memory card expansion up to 64GB (memory card not included).
- **Multi-functional:** Includes music playback, e-book reader, picture viewer, video player, voice recorder, FM radio, and alarm clock functions.
- **External Speaker:** Features a dual magnetic external speaker, allowing music playback without headphones.

Smart ebook

Comfortable reading experience

1.77-inch TFT display screen, no reflection, no dead Angle
Save bookmarks, extract bookmarks support automatic
playback reading more convenient




Image: An illustration highlighting the MP3 player's core functions: Video playing, Music playback, E-Book reading, Radio, Recording, and File management.

Dual magnetic external speaker

You don't need headphones to listen to music
Electronic/rock/funk/jazz and other 7 sound effects are available



Image: The rear view of the MP3 player, emphasizing its dual magnetic external speaker for audio output without headphones.

4. SETUP

4.1. Charging the Device

Before initial use, fully charge the MP3 player. Connect the included charging cable to the device's charging port and a compatible USB power source (e.g., computer USB port, USB wall adapter).

4.2. Installing a Memory Card

The MP3 player requires a memory card for storing media files. It supports expansion cards up to 64GB.

1. Locate the memory card slot on the side of the device.
2. Gently insert the memory card into the slot until it clicks into place. Ensure the card is oriented correctly.
3. To remove, push the card inward slightly until it springs out.

Display text content synchronously

Lyrics/English words/articles can
be displayed synchronously

More 8-speed transmission play
smart A-B replay two big assistant



Image: A visual representation of the MP3 player's TF card interface, showing a 64GB memory card being inserted, indicating support for expanded storage.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off

Press and hold the power button (location may vary, typically on the side) to turn the device on or off.

5.2. Basic Navigation

Use the touch screen or physical buttons (if present) to navigate through the menus. The 1.77-inch TFT color screen displays icons for various functions such as Music, Video, E-Book, FM Radio, and Recorder.

5.3. Music Playback

Select the "Music" icon from the main menu. You can browse your music by artist, album, genre, or all songs. The player supports MP3, WMA, FLAC, WAV, and APE audio formats.

5.4. Bluetooth Connection

To connect to Bluetooth headphones or speakers:

1. Go to the Bluetooth settings menu on your MP3 player.
2. Enable Bluetooth.
3. The player will search for nearby Bluetooth devices. Select your desired device from the list to pair.

Important: This MP3 player functions as a Bluetooth transmitter only. It cannot connect to smartphones or computers via Bluetooth.

5.5. FM Radio

Select the "FM Radio" icon. You can auto-scan for stations or manually tune to a specific frequency. Ensure headphones are connected as they often act as the antenna.

5.6. Recording

Select the "Recorder" icon to access the voice recording function. You can start, pause, and save recordings. Recordings are typically saved to the memory card.

5.7. E-Book Reader

Select the "E-Book" icon. The player supports TXT file format. You can save bookmarks and utilize automatic playback reading features for convenience.



Image: The MP3 player screen showing text from an e-book, demonstrating its comfortable reading experience with a

5.8. Video Playback

Select the "Video" icon. The player supports AMV and AVI video formats. For other video formats, a conversion tool may be required on a computer to convert them to a compatible format before transferring to the device.




Image: The MP3 player displaying a video, illustrating its clear video playback capability and the need for a video conversion tool for unsupported formats.

5.9. Image Viewer

Select the "Pictures" icon to view images. The player supports JPEG, BMP, and GIF formats.

5.10. Learning English Features

The device includes features to assist with language learning, such as:

- **Eight-speed Play:** Adjust playback speed for audio content.
- **A-B Restudy:** Loop a specific section of audio for repeated listening.
- **Subtitle Synchronization:** Display lyrics or text content synchronously with audio/video playback.

TF card interface design

Storing more data

Big capacity big wonderful
64 gb memory card extension is supported



Image: The MP3 player screen displaying a music icon, surrounded by text indicating features like eight-speed play, A-B restudy, and subtitle synchronization, useful for language learning.



Image: The MP3 player screen showing synchronized text content (lyrics/articles) with an audio playback progress bar, demonstrating the A-B replay function for learning.

6. MAINTENANCE

- Keep the device dry. Moisture can damage electronic components.
- Clean the screen and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Avoid extreme temperatures. Do not expose the device to direct sunlight or very cold environments.
- Handle with care. Do not drop or subject the device to strong impacts.

7. TROUBLESHOOTING

7.1. Device does not power on.

- Ensure the battery is charged. Connect the device to a power source and allow it to charge for at least 30 minutes before attempting to power on again.
- Check the charging cable and adapter for damage.

7.2. No sound from headphones or speaker.

- Check the volume level.
- Ensure headphones are properly plugged in.
- If using Bluetooth, ensure the device is correctly paired and connected to the audio output device.
- Test with different headphones to rule out faulty headphones.

7.3. Cannot transfer files to the device.

- Ensure a memory card is inserted and properly recognized by the device.
- Connect the MP3 player to your computer using the provided USB cable. The device should appear as a removable disk.
- Check if the memory card is full. Delete unnecessary files or replace the card if needed.

7.4. Bluetooth pairing issues.

- Ensure the target Bluetooth device is in pairing mode.
- Keep the MP3 player and the Bluetooth device within close proximity.
- Restart both the MP3 player and the Bluetooth device.
- Remember, this MP3 player is a Bluetooth transmitter only and cannot pair with phones or computers.

8. SPECIFICATIONS

Item Type	MP3 Player
Material	Plastic
Dimensions	Approx. 52.5x40.5x11.5mm / 2.07x1.59x0.45in
Screen Size	1.77 inch TFT Color Screen
Screen Resolution	128x160 Pixels
Bluetooth Version	5.0
Supported Audio Formats	MP3, WMA, FLAC, WAV, APE
Supported Video Formats	AMV, AVI (Requires Conversion Tool Support)
Supported Image Formats	JPEG, BMP, GIF
Supported E-Book Format	TXT
FM Radio	Yes
External Memory	Supports Memory Card up to 64GB (Not Included)
Battery	250mAh Lithium Battery

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.