

[Manuals.plus](#) /

› [UPBRIGHT](#) /

› UpBright 5.7V AC/DC Adapter Instruction Manual for Roland Aerophone PRO AE-10, AE-20, AE-30

UPBRIGHT PSD-120

UpBright 5.7V AC/DC Adapter Instruction Manual

MODEL: PSD-120

Introduction

This manual provides essential instructions for the safe and effective use of your UpBright 5.7V AC/DC Adapter, Model PSD-120. This power supply is designed to provide reliable power to compatible Roland Aerophone Digital Wind Synthesizers, including models AE-10, AE-20, and AE-30.



Image: The UpBright 5.7V AC/DC Adapter, showing the main unit with foldable prongs and the attached DC barrel connector cable.

Safety Information

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or damage to the product or connected devices.

- **Input Voltage:** This adapter supports a worldwide input voltage range of 100-240VAC, 50/60Hz. Ensure your wall outlet voltage is within this range.
- **Protection Features:** The adapter is equipped with OVP (Over Voltage Output Protection), OCP (Over Current Output Protection), and SCP (Short Circuit Output Protection) to safeguard your devices.
- **Indoor Use Only:** This adapter is intended for indoor use in dry locations. Do not expose to water or excessive humidity.
- **Proper Ventilation:** Ensure adequate ventilation around the adapter during use to prevent overheating.

- **Disconnect When Not in Use:** Unplug the adapter from the power outlet when not in use for extended periods.

Setup

1. **Verify Compatibility:** Ensure your device is a Roland Aerophone PRO AE-10, AE-20, AE-30, or another device requiring a 5.7V DC power input with a compatible barrel connector.
2. **Connect to Device:** Insert the DC barrel connector of the UpBright adapter firmly into the power input port of your Roland Aerophone.
3. **Connect to Power Outlet:** Plug the AC prongs of the adapter into a standard wall power outlet.

UpBright Power Supply Adapter Compatible with:



Image: The UpBright adapter shown alongside various Roland Aerophone models (AE-10, AE-20, AE-30), illustrating compatibility.

Operating Instructions

Once properly connected, the UpBright 5.7V AC/DC Adapter will supply power to your compatible Roland Aerophone. The device should power on as usual. No additional configuration is required for the adapter itself.

- Always ensure the adapter is securely connected to both the device and the power outlet.
- Avoid bending or crimping the power cord excessively.

Maintenance

- **Cleaning:** Disconnect the adapter from the power source and the device before cleaning. Use a soft, dry cloth to wipe

the exterior. Do not use liquid cleaners or solvents.

- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid extreme temperatures.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use immediately.

Troubleshooting

If your device is not powering on or charging:

- **Check Connections:** Ensure the adapter is fully plugged into both the wall outlet and your device.
- **Test Outlet:** Try plugging another device into the wall outlet to confirm it is functioning correctly.
- **Inspect Adapter:** Look for any visible damage to the adapter or its cable. If damaged, do not use.
- **Device Issue:** If the adapter appears to be working correctly, the issue may lie with the device itself. Consult your device's manual.

Specifications

Feature	Specification
Model Number	PSD-120
Input Voltage	100-240VAC, 50/60Hz
Output Voltage	5.7V DC
Special Features	OVP, OCP, SCP Protection
Color	Black
Product Dimensions	4 x 3 x 2 inches
Item Weight	4 ounces

Warranty and Support

UpBright offers the following for this product:

- **30-Day Refund:** If you are not satisfied with your purchase, you may be eligible for a refund within 30 days.
- **24-Month Exchange:** The product is covered by a 24-month exchange policy for manufacturing defects.

For further assistance or warranty claims, please contact UpBright customer support through their official channels or visit the [UPBRIGHT Store on Amazon](#).

Come With A Suitable Outlet Adapter (Only One) to Fit Your Country/Area For International Order



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UPBRIGHT® LIMITED WARRANTY



Image: A visual representation of the UpBright Limited Warranty Certificate and examples of international outlet adapters (AU, EU, UK) that may be included with international orders.

© 2023 UpBright. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

