

MAS CARNEY M1

MAS CARNEY Wireless Earbuds M1

USER MANUAL



INTRODUCTION

Thank you for choosing the MAS CARNEY M1 Wireless Earbuds. These earbuds are designed to provide a comfortable, high-quality audio experience with advanced features like Bluetooth 5.3 connectivity, smart touch controls, and long battery life. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new earbuds to ensure optimal performance.


Key Features:

- **Lightweight & Mini Size:** Ergonomically designed for a comfortable and secure fit, weighing only 3.2g per earbud.
- **Smart Touch Control:** Intuitive controls for music playback, calls, and voice assistant.
- **One-Step Pairing:** Automatic connection upon opening the charging case.
- **Long Battery Life:** Up to 4 hours of use per charge, with the charging case providing an additional 20 hours (5 charges).
- **Bluetooth 5.3:** Ensures higher speed, less latency, and a longer connection range.

PRODUCT OVERVIEW



Front view of the MAS CARNEY M1 Wireless Earbuds.



The MAS CARNEY M1 Earbuds inside their charging case.

Components:

- Left Earbud (L)
- Right Earbud (R)
- Charging Case
- USB Charging Cable
- User Manual (this document)

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge both the earbuds and the charging case. The charging case has a 240mAh battery, and each earbud has a 25mAh battery.

- Place the earbuds into the charging case. Ensure they are correctly seated.
- Connect the USB charging cable to the charging port on the case and plug the other end into a USB power source (e.g., computer, wall adapter).
- The indicator lights on the case will show the charging status. Once fully charged, the lights will indicate completion or turn off.



Internal view of earbuds in charging case, illustrating battery components.

2. Pairing Your Earbuds

The M1 earbuds feature one-step pairing for convenience.

1. Ensure your earbuds are charged.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your mobile device, go to Bluetooth settings and turn on Bluetooth.
4. Look for "MAS CARNEY M1" in the list of available devices and select it to connect.
5. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.




Illustration of the one-step pairing process with a smartphone.

Your browser does not support the video tag.

Video demonstrating the features of MAS CARNEY M1 True Wireless Bluetooth Earbuds, including mini size, Bluetooth 5.3, easy pairing, smart touch, long battery life, and ergonomic design.

OPERATING INSTRUCTIONS

1. Wearing the Earbuds

The M1 earbuds are designed for a comfortable and secure fit.

- Identify the Left (L) and Right (R) earbuds.
- Gently insert each earbud into the corresponding ear canal.
- Adjust the earbud until it feels snug and comfortable, ensuring the sound is clear and balanced.




Image showing the ergonomic design and comfortable fit of the earbud in a user's ear.

2. Smart Touch Controls

The M1 earbuds feature intuitive touch controls on each earbud. The touch-sensitive area is located on the outer surface of the earbud.

Action	Control
Play/Pause Music	Double-tap (either earbud)
Next Track	Triple-tap Right earbud
Previous Track	Triple-tap Left earbud
Answer/End Call	Double-tap (either earbud)
Reject Call	Press and hold for 1 second (either earbud)
Activate Voice Assistant (Siri/Google Assistant)	Press and hold for 2 seconds (either earbud)



Visual guide to the smart touch controls on the earbuds.

3. Power On/Off

- **Power On:** The earbuds automatically power on when removed from the charging case.
- **Power Off:** Place the earbuds back into the charging case to automatically power them off and begin charging.

MAINTENANCE

1. Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Gently clean the charging contacts on both the earbuds and the case to ensure proper charging.

2. Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.

- Store in a cool, dry place away from extreme temperatures and direct sunlight.

3. Battery Care

- To prolong battery life, avoid fully discharging the earbuds and charging case frequently.
- Charge the device regularly, even if not in frequent use, to prevent deep discharge.

TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing with device.	Ensure earbuds are charged and out of the case. Turn off and on Bluetooth on your device. Forget "MAS CARNEY M1" from your device's Bluetooth list and try pairing again. Ensure earbuds are within range (10 meters) of your device.
No sound from one or both earbuds.	Check the volume level on your device. Ensure earbuds are properly connected to your device. Re-pair the earbuds. Clean any debris from the earbud speakers.
Earbuds not charging.	Ensure the charging cable is securely connected. Try a different USB port or power adapter. Clean the charging contacts on both the earbuds and the case. Ensure earbuds are correctly seated in the charging case.
Touch controls not responding.	Ensure your fingers are clean and dry. Try restarting the earbuds by placing them back in the case and taking them out.

SPECIFICATIONS

Feature	Detail
Model	M1
Connectivity Technology	Bluetooth 5.3
Earbud Battery Capacity	25mAh (each)
Charging Case Battery Capacity	240mAh
Music Playtime (Earbuds)	Approx. 4 hours (at 60% volume)
Total Playtime with Charging Case	Approx. 20 hours (5 charges)
Product Dimensions (Case)	45 x 22.3 x 46 mm
Earbud Weight	3.2g (each)
Total Product Weight	35g

Feature	Detail
Control Type	Smart Touch Control
Noise Control	Passive Noise Cancellation
Material	Plastic

WARRANTY AND SUPPORT

MAS CARNEY provides standard Amazon after-sales service for your M1 Wireless Earbuds. We conduct thorough checks on the appearance and function of all earbuds before shipping.

- **Product Replacement/Resend:** In the event of any damage, original defect, or transportation defect, we offer free product replacement or resend support.
- **Customer Service:** If you have any questions regarding your product or purchase, please do not hesitate to contact us through the Amazon platform. Our team is ready to assist you.

© 2023 MAS CARNEY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

