Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beurer HC25

Beurer HC25 Travel Hair Dryer User Manual

Model: HC25

Introduction

The Beurer HC25 Travel Hair Dryer is designed for versatile use, offering powerful drying with ionic technology in a compact, travel-friendly design. This manual provides essential information for safe and effective operation, maintenance, and troubleshooting.



Image: The Beurer HC25 Travel Hair Dryer, showcasing its sleek black design with rose gold accents and the attached concentrator nozzle.

Important Safety Information

Please read all instructions carefully before first use and keep them for future reference.

- Do not use the appliance near water (e.g., in a bathtub, shower, or washbasin).
- Always unplug the hair dryer immediately after use.
- Ensure the voltage switch is set correctly for your region before plugging in the device.
- Keep the air inlet and outlet grilles clear of obstructions.
- This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.

Product Features

- **Ionic Technology:** Features a negative ion function to reduce frizz and enhance hair shine.

- **Dual Voltage Switch:** Equipped with a voltage switch (110/220-240 V) for worldwide use.
- **Powerful Performance:** 1600 watts of power for fast drying.
- **Multiple Settings:** Two heat and fan settings, plus a lockable cool setting.
- **Foldable & Lightweight:** Compact design with a folding handle for easy storage and portability.
- **Concentrator Nozzle:** Includes a detachable concentrator nozzle for precise styling.



Image: A woman using the Beurer HC25 hair dryer, illustrating the effect of negative ion technology on hair, reducing frizz and adding shine.

Setup

1. Setting the Voltage Switch

Before first use, it is crucial to set the voltage switch on the handle to match the voltage of the country you are in. For the US, set it to 110-120V. For European countries, use 220-240V. Failure to do so may damage the appliance.



Image: A detailed view of the dual voltage switch located on the handle of the Beurer HC25, indicating settings for 220-240V (up) and 100-120V (down).

2. Attaching the Nozzle

The hair dryer comes with a detachable concentrator nozzle. Align the nozzle with the front of the dryer and push it firmly into place until it clicks. To remove, gently pull it off.



Image: The Beurer HC25 hair dryer alongside its included accessories, which are the narrow nozzle, storage bag, and instruction manual.

Operating Instructions

Power and Heat Settings

The Beurer HC25 offers two heat/fan settings and a cool shot button for versatile styling:

1. **Setting 0:** Off
2. **Setting 1:** Gentle airflow with warm heat. Ideal for delicate drying or styling.
3. **Setting 2:** Powerful airflow with hot heat. For fast drying of thicker hair.

Use the cool shot button (indicated by a snowflake icon) to set your hairstyle with a burst of cold air after drying with warm or hot air.



Image: A close-up view of the rose gold cold air button on the handle of the Beurer HC25 hair dryer, marked with a snowflake icon.

Drying Your Hair

Plug the hair dryer into a suitable power outlet after ensuring the voltage switch is correctly set. Select your desired heat and fan setting. For best results, start with a warm setting to remove excess moisture, then switch to the cool shot to lock in your style and add volume.



Image: A woman using the Beurer HC25 hair dryer to style her hair, demonstrating its ergonomic design and ease of use for professional results.

Maintenance

Cleaning the Safety Filter

To maintain optimal performance and prevent overheating, regularly clean the removable safety filter located at the back of the hair dryer. Ensure the appliance is unplugged and cool before cleaning. Gently twist or pull off the filter cover, remove any accumulated dust or hair, and then reattach the cover securely.

Storage

The Beurer HC25 features a foldable handle for convenient storage. After use, allow the dryer to cool down completely. Fold the handle towards the body of the dryer. Store it in a dry place, away from direct sunlight and moisture. The integrated hanging loop allows for easy storage on a hook.



Image: The Beurer HC25 hair dryer with its handle folded, being placed into a suitcase, illustrating its portable and compact design for travel.

Troubleshooting

Problem	Possible Cause	Solution
Hair dryer does not turn on.	Not plugged in correctly; power outage; voltage switch incorrect.	Check power connection; verify power supply; ensure voltage switch matches local voltage.
Hair dryer overheats and shuts off.	Air inlet/outlet blocked; prolonged use.	Unplug and allow to cool down; clean the air inlet filter; ensure proper ventilation during use. The device has automatic overheating protection.
Weak airflow.	Air inlet filter is dirty.	Clean the removable air inlet filter.

Specifications

Feature	Detail
Model Number	HC25
Power	1600 watts
Voltage	110/220-240 V (switchable)
Dimensions	6.2 x 3.1 x 1.1 inches (folded)
Weight	1.13 Pounds
Material	Plastic
Color	Black
Manufacturer	Beurer
UPC	810110200029

Warranty and Support

For warranty information and customer support, please refer to the official Beurer website or contact their customer service directly. Keep your proof of purchase for any warranty claims.
Manufacturer: Beurer
Website: www.beurer.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BX75SJ2N

More documents and user manuals: **https://manuals.plus/**