**NEWABWN Peach Blossom Pond**

# NEWABWN Peach Blossom Pond Micro Mini Building Blocks Set Instruction Manual

Brand: **NEWABWN** | Model: **Peach Blossom Pond**

## Introduction

This manual provides detailed instructions for assembling and maintaining your NEWABWN Peach Blossom Pond Micro Mini Building Blocks Set. This set allows for the construction of a detailed Chinese architectural model featuring a cherry bonsai tree, a pond, and string lights. The set contains 3320 micro-sized building blocks, offering a challenging and rewarding building experience.
Please read all instructions carefully before beginning assembly to ensure a smooth building process.

## Components List

Before starting, verify that all components are present. The set includes:

- Approximately 3320 Micro Building Blocks
- Instruction Manual (this document)
- String Lights Kit

Individual block types and quantities are detailed within the step-by-step assembly instructions.




*Image 1: Fully assembled NEWABWN Peach Blossom Pond model. This image provides an overview of the completed structure, showcasing the intricate details of the Chinese architecture, cherry blossom tree, waterfall, and pond.*

## Setup and Assembly

Assembly of the Peach Blossom Pond set requires patience and attention to detail due to the micro-sized nature of the blocks. It is recommended to work on a clean, well-lit surface.

1. **Preparation:** Unpack all bags of building blocks. It is advisable to sort the blocks by color and shape to facilitate easier assembly. Note that these are micro blocks, significantly smaller than standard building blocks.




*Image 2: Visual comparison of micro blocks versus normal blocks, illustrating the smaller size of the components in this set. Also displays the overall dimensions of the assembled model.*

2. **Follow the Instruction Manual:** Refer to the included paper instruction manual for step-by-step guidance. Each step will illustrate which blocks to use and where to place them.
3. **Base Construction:** Begin by assembling the base structure, which forms the foundation of the pond and the elevated architectural elements.
4. **Architectural Elements:** Proceed with building the main house, the gazebo, and the surrounding landscape features such as the plank path, river side, and waterfall. Pay close attention to the orientation of each piece.





*Image 3: Close-up views highlighting key structural details such as the plank path, river side, waterfall, and boat, providing visual reference during assembly.*

5. **Cherry Blossom Tree:** Assemble the cherry blossom tree branches and attach them to the designated points on the model.
6. **String Lights Installation:** Carefully integrate the string lights into the model as indicated in the instruction manual. Ensure wires are neatly tucked away to maintain the aesthetic. The lights are designed to illuminate the waterfall and other features.



*Image 4: The completed model illuminated by the integrated string lights, emphasizing the glowing waterfall effect and overall ambiance.*

7. **Final Touches:** Place any remaining decorative elements, such as small flowers or plants, to complete the scene.

## Operating the String Lights

The Peach Blossom Pond set includes a string light kit to enhance its visual appeal. To operate the lights:

- Ensure the light string is properly connected to its power source (e.g., battery pack, USB).
- Activate the lights using the switch provided with the light kit.
- Position the model in a suitable location to best appreciate the illuminated features.

## Maintenance

To ensure the longevity and appearance of your building block set:

- **Cleaning:** Gently dust the model regularly with a soft brush or a can of compressed air. For stubborn dirt, a slightly

damp cloth can be used, but avoid excessive moisture, especially near electrical components (string lights).

- **Storage:** If disassembling or storing, keep all blocks in a secure container to prevent loss, especially given their micro size. Store in a cool, dry place away from direct sunlight to prevent color fading.
- **Handling:** Handle the assembled model with care to prevent accidental disassembly, particularly when moving it.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Missing pieces | Blocks may be overlooked due to small size or manufacturing discrepancy. | Carefully re-check all packaging and sorting areas. If pieces are genuinely missing, contact customer support. |
| Model is unstable or falls apart | Blocks not fully pressed together, incorrect placement, or structural weakness. | Ensure each block is firmly connected. Double-check the instruction manual for correct placement and structural integrity. Reassemble problematic sections. |
| String lights not working | Loose connection, depleted batteries (if applicable), or switch is off. | Verify all connections are secure. Replace batteries if necessary. Ensure the power switch is in the 'ON' position. |

## Specifications

- **Product Dimensions (Assembled):** 8.9 x 8.27 x 8.11 inches (22.6 cm x 21 cm x 20.7 cm)
- **Item Weight:** 2.72 pounds (1.23 kg)
- **Number of Pieces:** Approximately 3320 Micro Building Blocks
- **Recommended Age:** 6 years and up (Note: Due to micro-sized blocks, adult supervision or assistance may be beneficial for younger builders.)
- **Manufacturer:** Shantou Yichao Technology Co., LTD
- **Model Number:** Peach Blossom Pond (ASIN: B0BX87V8K9)

## Warranty and Support

For any questions, concerns, or assistance with your NEWABWN Peach Blossom Pond Micro Mini Building Blocks Set, please contact the seller or manufacturer directly. While specific warranty details are not provided in this manual, most products come with a standard return or replacement policy for manufacturing defects.
Please retain your proof of purchase for any warranty claims or support inquiries.

© 2025 NEWABWN. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**