

[Manuals.plus](#) /

› [Zspeed](#) /

› Zspeed Stylus Pen User Manual

Zspeed Zspeed iPad Pencil

Zspeed Stylus Pen User Manual

Model: Zspeed iPad Pencil

PRODUCT OVERVIEW

The Zspeed Stylus Pen is designed to enhance your iPad experience, offering precise control for drawing, note-taking, and navigation. It features wireless charging, palm rejection, tilt sensitivity, and convenient shortcut functions.



Figure 1: Zspeed Stylus Pen with included accessories (Type-C charging cable and two replacement tips).

Key Features:

- **Wireless & Type-C Charging:** Convenient charging options for continuous use.
- **Palm Rejection:** Rest your hand naturally on the screen without interference.
- **Tilt Function:** Adjust line thickness and shading by tilting the pen.
- **Shortcut Functions:** Quick access to home screen, task manager, and screenshots.
- **Bluetooth Connectivity:** Monitor battery percentage directly on your iPad.

SETUP GUIDE

1. Compatibility Check

Ensure your iPad model is compatible with the Zspeed Stylus Pen. This stylus is designed for specific iPad models from 2018 onwards. It is **not compatible** with iPhones, Android phones, Android tablets, or Microsoft devices.

- **Compatible iPad Models:** iPad 10th/9th/8th/7th/6th Gen, iPad Air M2/5th/4th/3rd Gen, iPad Pro 13" M4, iPad Pro 12.9" 6th/5th/4th/3rd Gen, iPad Pro 11" M4/4th/3rd/2nd/1st Gen, iPad Mini 6/5th Gen.

Designed for iPad 2018 Versions or Later

⊗ Please note that the underlined models do not support wireless charging, you can use the Type-C cable included for charging.



iPad Air 3/4/5 Gen & M2 11"/13"

A2152 A2123 A2153 A2154 A2316 A2325 A2324 A2072 A2588
A2589 A2591 A2902 A2903 A2904 A2898 A2899 A2900



iPad 6/7/8/9/10 Gen

A1954 A1893 A2197 A2198 A2200 A2270 A2428 A2429
A2430 A2602 A2603 A2604 A2605 A2232



iPad Pro 11"

A1980 A2013 A1934 A1979 A2228 A2068 A2030 A2231
A2460 A2301 A2459 A2377 A2836 A2837 A3006



iPad Pro 12.9"

A1876 A2014 A1895 A1983 A2229 A2233 A2069 A2232
A2462 A2379 A2461 A2378



iPad Pro 13"

A2925 A2926 A3007



iPad Mini 5/6 Gen

A2133 A2124 A2126 A2125 A2567 A2569 A2568



Figure 2: Detailed compatibility chart for the Zspeed Stylus Pen.

2. Initial Charging

Before first use, fully charge your Zspeed Stylus Pen. You have two charging options:

- **Type-C Charging:** Connect the included Type-C cable to the pen's charging port and a power source. A full charge takes approximately 90 minutes.
- **Magnetic Wireless Charging:** Attach the pen magnetically to the side of your compatible iPad. This method provides a full charge in 2-4 hours.

Note: Magnetic charging is available only for iPad Pro 12.9" (3rd/4th/5th/6th Gen), iPad Pro 11" (1st/2nd/3rd/4th Gen), iPad Air (4th/5th Gen), and iPad Mini (6th Gen). It does not magnetically attach to iPad Pro M4 13"/11", iPad Air M2

Magnetic Wireless Charging or Type-C Charging



Figure 3: The stylus can be charged via the included Type-C cable or magnetically attached to compatible iPads for wireless charging.

Your browser does not support the video tag.

Video 1: Demonstration of the Zspeed Stylus Pen's charging methods and key features. This video illustrates both Type-C and magnetic charging, as well as basic operation.

3. Bluetooth Pairing

To view the stylus's battery percentage on your iPad, connect it via Bluetooth:

1. Go to your iPad's **Settings**.
2. Select **Bluetooth**.
3. Ensure Bluetooth is turned **On**.
4. Long press the top of the Zspeed Stylus Pen for 3 seconds to turn it on.
5. Look for "SKY-PEN" or a similar name under "Other Devices" and tap to pair.

6. Once connected, the battery percentage will appear in your iPad's status bar.



Figure 4: Steps for connecting the stylus via Bluetooth to display battery status on your iPad.

OPERATING INSTRUCTIONS

Power On/Off

To turn the stylus **On** or **Off**, long press the top of the pen for 3 seconds.

Shortcut Functions

The Zspeed Stylus Pen features intuitive shortcut controls:

- **One-Click:** Tap the top of the pen once to return to the main home screen.
- **Double-Click:** Tap the top of the pen twice to open the APP selection page (task manager).
- **Swipe from Lower Left Corner:** Swipe from the bottom-left corner of the iPad screen towards the center to instantly take a screenshot.
- **Swipe from Bottom Right Corner:** Swipe from the bottom-right corner of the iPad screen towards the center to quickly open a new memo.

Easy to Use Shortcut Function







Figure 5: Visual guide to the stylus's shortcut functions for efficient iPad navigation.

Palm Rejection & Tilt Function

The stylus supports palm rejection, allowing you to rest your hand comfortably on the iPad screen while writing or drawing without creating unwanted marks. The tilt function enables you to vary line thickness and shading by simply tilting the pen, mimicking a traditional pencil.

Palm Rejection Design



No need to wear gloves,
feel free to rest your hand on screen.




Figure 6: The stylus offers a natural writing and drawing experience with palm rejection and responsive input.

MAINTENANCE

Replacing Pen Tips

The Zspeed Stylus Pen comes with two replacement tips. If your current tip becomes worn or damaged, follow these steps to replace it:

1. Gently twist the old pen tip counter-clockwise to remove it.
2. Align a new replacement tip with the pen's thread.
3. Twist the new tip clockwise until it is securely fastened. Do not overtighten.



Figure 7: Instructions for replacing the stylus pen tip.

TROUBLESHOOTING

If you encounter issues with your Zspeed Stylus Pen, try the following solutions:

- **Pen Not Responding:**

- Ensure the pen is powered on (long press top for 3 seconds).
- Check if the pen is charged. Recharge if necessary.
- Verify Bluetooth connection in your iPad settings. If not connected, try re-pairing.
- Ensure your iPad model is compatible (refer to Compatibility Check section).

- **Magnetic Charging Not Working:**

- Confirm your iPad model supports magnetic wireless charging for this stylus (iPad Pro 12.9" 3rd-6th Gen, iPad Pro 11" 1st-4th Gen, iPad Air 4th/5th Gen, iPad Mini 6th Gen).
- Ensure the pen is correctly aligned and securely attached to the magnetic strip on your iPad.
- Remove any thick iPad cases that might interfere with magnetic contact.

- **Inaccurate or Skipping Input:**

- Check if the pen tip is securely tightened. A loose tip can cause inconsistent input.
- Replace the pen tip if it appears worn or damaged.
- Ensure your iPad screen is clean and free of debris.

- **Battery Percentage Not Displaying:**

- Confirm the stylus is successfully paired via Bluetooth (refer to Bluetooth Pairing section).
- Restart your iPad and try re-pairing the stylus.

SPECIFICATIONS

Feature	Detail
Model Number	Zspeed iPad Pencil
Product Dimensions	6.5 x 0.35 x 0.35 inches
Item Weight	0.459 ounces (13 Grams)
Battery Type	1 Lithium Polymer battery (included)
Battery Average Life Standby	365 days
Material	Aluminum
Color Options	White, Black, Pink, Purple, Blue, Green, Grey
Manufacturer	Zspeed
Country of Origin	China

WARRANTY AND SUPPORT

Zspeed is committed to providing high-quality products and excellent customer service.

- **Returns:** Enjoy 30-day free returns from the date of purchase.
- **Manufacturer Replacement:** A 12-month manufacturer replacement support is provided for defective items.

For further assistance or to claim warranty support, please contact Zspeed customer service through the retailer where you purchased the product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

My Zspeed iPad Pencil is about 12 months old and has suddenly stopped working; it will not charge or turn on, and there is no blue light. Can you advise on how to fix this?

It is possible that your Zspeed Stylus Pen has experienced a battery or hardware failure, especially if it shows no indicator lights when connected to power. Please try the following troubleshooting steps to rule...

[Read full answer](#)