

ZOUKAI F3

ZOUKAI Bone Conduction Bluetooth 5.3 Open Ear Clip Headphones User Manual

Model: F3

1. INTRODUCTION

Thank you for choosing the ZOUKAI Bone Conduction Bluetooth 5.3 Open Ear Clip Headphones. This manual provides essential information for the proper use, setup, and maintenance of your new headset. Please read it thoroughly before use to ensure optimal performance and longevity.

2. PRODUCT OVERVIEW

2.1 Key Features

- **Open Ear Design:** Allows you to enjoy audio while remaining aware of your surroundings, enhancing safety during outdoor activities.
- **Bone Conduction Technology:** Delivers sound through vibrations to your cheekbones, bypassing the eardrum.
- **Bluetooth 5.3 Connectivity:** Ensures stable and efficient wireless connection with compatible devices.
- **Comfortable Ear Clip Design:** Lightweight (4.5g per earbud) and ergonomic for pain-free, secure wearing, even with glasses.
- **Automatic Pairing:** Simplifies connection after initial setup.
- **Intuitive Controls:** Easy single-hand operation for music playback, calls, and voice assistant.
- **ENC Noise Reduction:** Enhances call clarity.
- **Waterproof Design:** Suitable for use during exercise and in wet conditions.
- **Long Battery Life:** Up to 72 hours music time (with charging case), 30 days standby, 1 hour fast charging.

2.2 Package Contents

The ZOUKAI Bone Conduction Bluetooth 5.3 Open Ear Clip Headphones package includes:

- ZOUKAI Bone Conduction Bluetooth 5.3 Open Ear Clip Headphones (Left and Right Earbuds)

- Charging Case
- Charging Cable
- User Manual (this document)

2.3 Product Diagram



Image: ZOUKAI Bone Conduction Bluetooth 5.3 Open Ear Clip Headphones with their charging case. The earbuds are white and have an open-ear clip design. The charging case is also white with a green indicator light.

EAR CLIP HEADPHONES

ACS 360° Air
Conduction
Stereo



HD Calls



Anti-noise design



HIFI sound quality



Comfortable to wear

Image: A detailed diagram showing the internal components of the ZOUKAI ear clip headphones, including the bone conduction driver, coil, and other sound elements. Also shows the headphones in their charging case.

3. SETUP

3.1 Initial Charging

Before first use, ensure the headphones and charging case are fully charged. Connect the provided charging cable to the charging case and a compatible USB power source. The indicator light on the case will show charging status.

- A full charge takes approximately 1 hour.
- The charging case provides multiple charges for the earbuds.



Image: An illustration highlighting the long battery life of the ZOUKAI headphones, showing 72 hours music time, 30 days standby time, and 1 hour fast charging, with the charging case and earbuds in the background.

3.2 Pairing with a Bluetooth Device

1. Ensure the headphones are charged and inside the charging case.
2. Open the lid of the charging case. The headphones will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices. Select "ZOUKAI F3" (or similar name) from the list.
5. Once connected, the headphones will indicate successful pairing (e.g., a voice prompt or indicator light change).

Note: After the first successful pairing, the headphones will automatically connect to the last paired device when the charging case lid is opened, provided Bluetooth is enabled on the device.



Image: An illustration demonstrating the broad compatibility of the ZOUKAI headphones with Bluetooth 5.3 enabled devices, including smartphones and tablets. It also shows the ear clip design being comfortable even for users wearing glasses.

4. OPERATING INSTRUCTIONS

4.1 Wearing the Headphones

Gently clip the headphones onto your earlobe. The open-ear design ensures comfort and allows ambient sound awareness. Adjust for a secure and comfortable fit.



Comfortable
HEADSET WEIGHT

4.5g



Ear Clip Bluetooth earphone
Bluetooth earphones of the fourth generation, open-style earphones

Image: A man wearing the white ZOUKAI ear clip headphones, demonstrating their comfortable and discreet fit.



Image: Close-up illustrations showing how the ZOUKAI ear clip headphones are worn, highlighting their secure and comfortable placement on the earlobe for sports and daily use.

4.2 Basic Controls (Touch Sensitive)

The headphones feature touch controls for easy operation:

Action	Function
Single Tap	Play/Pause Music, Answer/End Call
Double Tap (Left Earbud)	Volume Down
Double Tap (Right Earbud)	Volume Up
Triple Tap (Left Earbud)	Previous Song
Triple Tap (Right Earbud)	Next Song
Long Press (2 seconds)	Reject Call, Activate Voice Assistant

5. MAINTENANCE

5.1 Cleaning

Regular cleaning helps maintain the performance and hygiene of your headphones.

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Do not submerge the headphones or charging case in water, despite their waterproof rating, to prevent damage to charging contacts or internal components.

5.2 Storage

When not in use, store the headphones in their charging case to protect them from dust, dirt, and physical damage.

- Store in a cool, dry place, away from extreme temperatures and direct sunlight.
- Avoid storing in highly humid environments.

5.3 Battery Care

- Charge the headphones regularly, even if not used frequently, to prolong battery life.
- Avoid completely draining the battery before recharging.
- Use only the provided charging cable or a certified equivalent.

6. TROUBLESHOOTING

If you encounter issues with your ZOUKAI headphones, refer to the following common solutions:

Problem	Possible Cause / Solution
Headphones do not turn on.	Battery is low. Place headphones in the charging case and charge fully.
Cannot pair with device.	Ensure Bluetooth is enabled on your device. Make sure headphones are in pairing mode (open charging case lid). Move headphones closer to your device. Forget "ZOUKAI F3" from your device's Bluetooth list and try pairing again. Restart both your device and the headphones (by placing them in the case and closing/opening the lid).
No sound or low volume.	Adjust volume on both the headphones and your connected device. Ensure headphones are properly connected to your device. Check if the audio source is playing.
Intermittent connection / audio drops.	Move closer to your connected device (within 10 meters/33 feet). Avoid strong electromagnetic interference. Ensure there are no physical obstructions between the headphones and the device.
Microphone not working during calls.	Ensure the headphones are selected as the audio input device on your phone. Check for any mute functions activated on your phone or the headphones.

7. SPECIFICATIONS

Feature	Detail
Model Name	F3
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Audio Driver Type	Bone Conduction Driver

Feature	Detail
Ear Placement	Open Ear
Form Factor	Ear-Clip
Control Type	Volume Control, Voice Control, Noise Control (Touch)
Noise Control	Active Noise Cancellation (ENC for calls)
Water Resistance Level	Waterproof
Frequency Range	20 Hz to 20,000 Hz
Material	Plastic
Item Weight	4.2 ounces (total package)
Color	White
Included Components	Cable
Manufacturer	ZOUKAI
UPC	768399192675

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the purchase platform or contact ZOUKAI customer service directly. Keep your proof of purchase for warranty claims.

Online Support: Visit the official ZOUKAI website or the product page on the retailer's website for FAQs and additional support resources.