Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WANAI D-153

WANAI Chest Freezer D-153 User Manual

Model: D-153-black-M

1. Important Safety Instructions

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance is intended for household use only.
- Do not use extension cords.
- Unplug the freezer before cleaning or performing any maintenance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

2. Setup and Installation

2.1 Unpacking

Carefully remove all packaging materials. Ensure all components listed in the 'What's in the Box' section are present.

2.2 Placement

Place the freezer on a flat, stable surface. Ensure adequate ventilation around the unit. This is a freestanding appliance.

Product Dimensions: 21.7"D x 30.8"W x 30.1"H



Image: The WANAI Chest Freezer showing its dimensions (30.7"W x 21.7"D x 30.0"H) and highlighting the included storage basket.

2.3 Initial Power-On

After placing the freezer, allow it to stand upright for at least 24 hours before plugging it in. This allows the refrigerant to settle. Once plugged in, wait another 24 hours before loading food items to ensure the freezer reaches its optimal operating temperature.

Your browser does not support the video tag.

Video: This video demonstrates the interior capacity of the WANAI Chest Freezer, showing various frozen food items stored inside, including the use of the removable basket. It highlights the practical storage space available.

3. Operating Instructions

3.1 Temperature Control

The freezer features a 7-grade adjustable thermostat. The temperature regulation range is -11.2°F to 50°F, allowing for both deep freezing and refrigeration.

- Setting '0' turns the unit off.
- Settings '1' to '3' are suitable for refrigeration (32-50°F).
- Settings '4' to '7' are for freezing, with '7' being the coldest setting (down to -11.2°F).



Image: A close-up of the 7-grade adjustable thermostat on the WANAI Chest Freezer, illustrating the temperature range from -11.2°F to 50°F and explaining that '1' is cold, '7' is the coldest, and '0' is off.



Image: A visual guide showing recommended temperature settings for various food types (Freezer, Deep Freezer, Fridge, MAX) with the central thermostat dial.

3.2 Energy Saving Features

The freezer is designed for energy efficiency, utilizing an R600a compressor and good thermal insulation foam with an aluminum liner to maintain coldness and block external heat.



Image: Diagram illustrating cold air circulation within the WANAI Chest Freezer, highlighting its energy-saving and environmentally friendly design, along with an estimated annual electricity bill of $21.

3.3 Quiet Operation

The freezer operates quietly, with a noise level not exceeding 40 dB, ensuring minimal disturbance in your home or office environment.

4. Maintenance

4.1 Defrosting

This is a manual defrost freezer. Regular defrosting is necessary to maintain efficiency and prevent excessive ice buildup. To defrost:

1. Unplug the freezer from the power outlet.
2. Remove all food items and store them in another freezer or cooler.
3. Open the drain plug located at the bottom of the freezer to allow water to escape.
4. Allow ice to melt naturally. Do not use sharp objects to remove ice.

5. Once defrosted, clean and dry the interior thoroughly before plugging it back in and reloading food.

Your browser does not support the video tag.

Video: This video demonstrates the interior capacity of the WANAI Chest Freezer, showing various frozen food items stored inside, including the use of the removable basket. It also briefly shows the drain plug at the bottom of the freezer, which is used for manual defrosting.

4.2 Cleaning

Clean the interior and exterior of the freezer regularly with a mild detergent and warm water. Avoid abrasive cleaners or solvents. Ensure the freezer is unplugged before cleaning.

5. Troubleshooting

If your freezer is not operating correctly, check the following common issues before contacting customer service:

- **Freezer not operating:** Check if the power cord is securely plugged into a working outlet. Verify the circuit breaker has not tripped.
- **Temperature is not cold enough:** Ensure the temperature control dial is set to an appropriate freezing setting (e.g., 4-7). Avoid frequent opening of the lid. Check for excessive ice buildup requiring defrosting.
- **Excessive noise:** Ensure the freezer is on a level surface. Check if any items inside are vibrating against the walls.
- **Lid not closing properly:** Check if the lid gasket is clean and free of obstructions. Ensure the freezer is level.

6. Specifications

Brand	WANAI
Model Name	D-153-black-M
Product Dimensions (D x W x H)	21.7" x 30.8" x 30.1"
Item Weight	55 Pounds
Capacity	7.0 Cu.Ft
Temperature Range	-11.2°F to 50°F
Wattage	70 watts
Voltage	110 Volts
Noise Level	Less than 40 dB
Installation Type	Freestanding
Defrost Type	Manual Defrost
Door Material Type	PCM

6.1 Energy Information




Image: The U.S. Government EnergyGuide label for the WANAI Compact Chest Freezer, indicating an estimated yearly energy cost of $21 and 211 kWh estimated yearly electricity use. This label is for a 7.0 CU.FT Manual Defrost model.

7. Warranty Information

WANAI provides a one-year warranty for all parts of the machine, effective from the date of purchase. Please retain

your proof of purchase for warranty claims.

8. Customer Support

For any questions, technical assistance, or warranty claims, please contact WANAI customer service. Refer to the contact information provided in the packaging or on the official WANAI website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BX9FKXHP

More documents and user manuals: **https://manuals.plus/**