

[Manuals.plus](#) /

› [ZJYWSCH](#) /

› ZJYWSCH Grill Cover Instruction Manual

ZJYWSCH WC090

ZJYWSCH Grill Cover Instruction Manual

Model: WC090 | Brand: ZJYWSCH

PRODUCT OVERVIEW

The ZJYWSCH Grill Cover is designed to provide robust protection for your outdoor grill. Crafted from durable materials, it offers comprehensive defense against various environmental elements, ensuring the longevity and pristine condition of your appliance.

- **Custom Fit:** Specifically designed to fit Pit Boss Savannah Onyx Edition Wood Pellet Grill Smoker PB1500NX.
- **Heavy Duty Construction:** Made with 600D heavy-duty PVC-lined oxford material, providing exceptional waterproof, UV-resistant, and tear-resistant properties. This material is engineered to withstand harsh weather conditions without fading or cracking.
- **Secure Design:** Features an adjustable drawstring for a snug fit, preventing the cover from blowing away in strong winds. A waterproof zipper is integrated to facilitate easy removal and installation while protecting against leaks and tears.
- **All-Weather Protection:** The polyester PVC blend ensures the cover can endure extreme temperatures and diverse weather events, safeguarding your grill year-round.

SETUP AND INSTALLATION

Proper installation of your ZJYWSCH Grill Cover ensures maximum protection for your grill. Follow these steps for optimal fit and security.

Step 1: Ensure Grill is Cool and Clean

Before placing the cover, ensure your grill is completely cool and free from any debris or food residue. This prevents heat damage to the cover and keeps the grill clean underneath.

Step 2: Position the Cover

Carefully drape the grill cover over your Pit Boss Savannah Onyx Edition Wood Pellet Grill. Align the cover so that the smoke stack and side components are properly enclosed within their designated sections of the cover.

GRILL COVER SIZE

For Pit Boss Savannah Onyx Edition Wood Pellet Grill



Image: The ZJYWSCH Grill Cover precisely fitted over a Pit Boss Savannah Onyx Edition Wood Pellet Grill, highlighting its custom design for this model.

Step 3: Secure with Zipper and Drawstring

Locate the waterproof zipper on the side of the cover. Zip it up completely to ensure a secure closure and prevent water ingress. Then, tighten the adjustable drawstring located at the bottom edge of the cover. This drawstring helps to cinch the cover tightly around the base of the grill, preventing it from being dislodged by wind.




Image: A close-up view of the quick zipper feature on the grill cover, designed for easy application and removal.



Image: Detail of the adjustable drawstring at the base of the grill cover, used to tighten and secure the cover in place.

Ensure the drawstring is pulled taut and secured to prevent the cover from flapping or lifting in windy conditions.

OPERATING INSTRUCTIONS

The ZJYWSCH Grill Cover is designed for straightforward use to protect your grill. Its primary function is passive protection.

- **Daily Use:** Place the cover over your grill when it is not in use and has completely cooled down.
- **Removal:** To use your grill, simply loosen the drawstring, unzip the cover, and carefully lift it off. Fold the cover neatly for storage to prevent creases and prolong its life.
- **Weather Protection:** The cover is designed to protect against rain, snow, UV rays, dust, and debris. Ensure it is properly secured during adverse weather conditions.

CARE AND MAINTENANCE

Regular cleaning and proper care will extend the life and effectiveness of your ZJYWSCH Grill Cover.

Cleaning Instructions:

- **Spot Cleaning:** For minor dirt or stains, wipe the affected area with a damp cloth.
- **Thorough Cleaning:** For more extensive cleaning, hose down the cover with water. Dirt and debris should easily rinse off due to the waterproof coating.
- **Drying:** After cleaning, allow the grill cover to air dry completely in the sun before storing or placing it back on the grill. Ensure it is fully dry to prevent mildew.
- **Avoid Harsh Chemicals:** Do not use harsh detergents, bleach, or abrasive cleaners, as these can damage the material and its protective coatings.



Image: Water droplets forming beads on the surface of the grill cover, illustrating its heavy-duty waterproof PVC coating.



Image: A detailed view showcasing the 600D Oxford Fabric on the exterior and the waterproof PVC coating on the interior of the grill cover, highlighting its dual-layer protection.

Storage:

When not in use for extended periods, store the clean, dry cover in a cool, dry place away from direct sunlight to preserve its material integrity.

TROUBLESHOOTING

While the ZJYWSCH Grill Cover is designed for durability and ease of use, here are some common issues and their solutions.

Issue	Possible Cause	Solution
Cover does not fit snugly.	Drawstring not tightened sufficiently.	Ensure the adjustable drawstring at the bottom is pulled taut and secured.

Issue	Possible Cause	Solution
Water pooling on top of cover.	Improper positioning or lack of tension.	Ensure the cover is evenly draped and the drawstring is tight to create a taut surface, allowing water to run off.
Zipper or drawstring gets stuck.	Material caught in zipper; drawstring knot.	Gently pull the material away from the zipper as you operate it. For the drawstring, ensure it is untangled before tightening or loosening.
Cover appears dirty or stained.	Accumulation of dust, pollen, or environmental debris.	Clean the cover as per the "Care and Maintenance" section.

Important Note: The provided video content from the manufacturer is created by an "Influencer" and does not meet the criteria for official product video embedding. Therefore, it is not included in this manual.

PRODUCT SPECIFICATIONS

Brand	ZJYWSCH
Model Number	WC090
Material	Polyester, Polyvinyl Chloride (600D Oxford Fabric with PVC lining)
Color	Black
Product Dimensions (Approx.)	9"L x 9"W x 2"H (packaged dimensions)
Closure Type	Adjustable Drawstring, Zipper
Compatible Grill Models	Pit Boss Savannah Onyx Edition Wood Pellet Grill Smoker PB1500NX (also listed as PIT BOSS 10989)
Manufacturer	Shenzhen ZJYWSCH
Item Weight	4.49 pounds
UPC	735209760645

WARRANTY INFORMATION

Specific warranty details for the ZJYWSCH Grill Cover are not provided in the product information. Please refer to the seller's or manufacturer's official website for any applicable warranty policies or contact their customer service directly for more information.

CUSTOMER SUPPORT

For any questions, concerns, or assistance regarding your ZJYWSCH Grill Cover, please contact the seller or manufacturer

through the platform where the product was purchased. You may also visit the official ZJYWSCH Store for additional resources and contact options.

[Visit the ZJYWSCH Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question