



Manuals.plus /

- › Casaria /
- › Casaria Polyrattan Lounger with Cushions and Wheels - Instruction Manual

Casaria Sonnenliege Polyrattan

Casaria Polyrattan Lounger with Cushions and Wheels - Instruction Manual

Model: Sonnenliege Polyrattan | Brand: Casaria

1. INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Casaria Polyrattan Lounger. Please read it thoroughly before using the product and retain it for future reference.



Image 1: The Casaria Polyrattan Lounger in an outdoor setting, featuring dark polyrattan weave and grey cushions.

2. SAFETY INSTRUCTIONS

- Ensure the lounger is placed on a stable, level surface before use.
- Do not exceed the maximum load capacity of 160 kg for the frame and 60 kg for the backrest.
- Regularly check all connections and fasteners to ensure they are secure.
- Keep children and pets away from the lounger during assembly and adjustment.
- Avoid sharp objects that could damage the polyrattan weave or cushions.
- Follow all usage and maintenance instructions to ensure product safety and longevity.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- 1 x Casaria Polyrattan Lounger Frame
- 1 x Main Cushion (7 cm thick)
- 1 x Head Cushion (40x20x3 cm)
- 2 x Wheels (pre-attached or requiring minimal attachment)

4. SETUP

The Casaria Polyrattan Lounger is designed for minimal setup. It typically arrives largely pre-assembled. Follow these general steps:

1. Carefully remove all packaging materials.
2. Unfold the lounger if it arrived in a folded state.
3. Ensure the wheels are securely attached. If not, attach them according to the visual guide below.
4. Place the main cushion onto the lounger frame.
5. Attach the head cushion to the backrest using the integrated ties or straps.



Image 2: Visual representation of the lounger's dimensions (193 cm length, 90 cm width, 43 cm height) and overall structure.



Image 3: Detail of the smooth-running wheels for easy transport.

5. OPERATING INSTRUCTIONS

5.1 Adjusting the Backrest

The lounger features a 5-position adjustable backrest for optimal comfort.

1. To adjust, lift the backrest slightly.
2. Select your desired reclining position by engaging the support mechanism into one of the five available notches.
3. Ensure the backrest is securely locked in place before applying full weight.



Image 4: Illustration of the 5-fold adjustable backrest mechanism.

5.2 Transporting the Lounger

The integrated wheels allow for easy relocation of the lounger.

1. Ensure the lounger is empty and no one is sitting on it.
2. Slightly lift the end opposite the wheels.
3. Roll the lounger to your desired location.

6. MAINTENANCE

To ensure the longevity and appearance of your Casaria Polyrattan Lounger, follow these maintenance guidelines:

- **Cleaning:** Wipe clean the polyrattan frame with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- **Cushions:** The cushions are weather-resistant. For deeper cleaning, refer to the care label on the cushions. Store cushions indoors during prolonged periods of rain or cold weather to extend their lifespan.
- **Weather Resistance:** The lounger is UV-resistant and designed for year-round outdoor use. However, covering it during extreme weather conditions is recommended.
- **Frame Inspection:** Periodically inspect the powder-coated steel frame for any signs of rust or damage. Touch up any scratches to prevent corrosion.



Image 5: Detail of the comfortable, thick cushions and head cushion.



Image 6: Close-up showing the water-resistant fabric of the cushion, the durable polyrattan weave, and the Casaria brand logo.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Backrest does not stay in position.	Mechanism not fully engaged.	Lift the backrest slightly and ensure it clicks firmly into the desired notch. Do not exceed 60 kg load on the backrest.
Lounger feels unstable.	Uneven surface or loose connections.	Move the lounger to a level surface. Check and tighten all frame connections.
Wheels are stiff or difficult to move.	Debris in wheel mechanism or loose axle.	Clean any debris from the wheels. Check if the wheel axles are securely fastened.

8. SPECIFICATIONS

Feature	Detail
Brand	Casaria
Model Name	Sonnenliege Polyrattan
Color	Black Anthracite
Material	Polyrattan (weave), Alloy Steel (frame)
Product Dimensions (L x W x H)	193D x 90B x 43H centimeters
Item Weight	17.5 Kilograms
Maximum Weight Recommendation	160 Kilograms (frame), 60 Kilograms (backrest)
Adjustable Positions	5 (for backrest)
Special Features	Armrest, Cushion included, Wheels for transport
Care Instructions	Wipe clean
Recommended Use	Outdoor, Patio/Garden, Reading
Assembly Required	No (minimal setup expected)

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Casaria customer service through their official website or the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

You can visit the [Casaria Store on Amazon](#) for more information.