

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Pipishell](#) /

› [Pipishell UL Listed Tilt and Full-Motion TV Wall Mount Instruction Manual](#)

Pipishell PILTK4, PILF8

Pipishell TV Wall Mount Instruction Manual

Models: PILTK4 (Tilt Mount) & PILF8 (Full-Motion Mount)

INTRODUCTION

This instruction manual provides detailed guidance for the safe and proper installation, operation, and maintenance of your Pipishell TV Wall Mount. This product is designed to securely hold most 37-75 inch flat or curved televisions. Please read this manual thoroughly before beginning installation and retain it for future reference.

The manual covers two distinct models: the PILTK4 Low Profile Tilt TV Wall Mount and the PILF8 Full-Motion TV Wall Mount. Ensure you identify your specific model to follow the correct instructions.

IMPORTANT SAFETY INFORMATION

Failure to read and follow all instructions may result in personal injury, property damage, or voiding of warranty. If you have any questions, please contact Pipishell customer support.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 132 lbs for PILTK4 or 100 lbs for PILF8.
- **TV Size:** Compatible with TVs from 37 to 75 inches.
- **Wall Type:** Mount only on 16" to 24" wood studs, concrete, or brick walls. Do not install on drywall alone.
- **Professional Installation:** If you are unsure about the installation process, consult a qualified professional.
- **Component Check:** Before installation, ensure all components are present and undamaged. Do not use damaged parts.

PACKAGE CONTENTS

Verify that all parts are included in your package. Refer to the parts list provided in your physical manual for specific quantities and identifiers.



This image displays both the low-profile tilt mount (top) and the full-motion articulating mount (bottom), along with included accessories such as cable ties and a small level. The tilt mount is a simpler, fixed-position bracket, while the full-motion mount features multiple arms for greater adjustability.

SETUP AND INSTALLATION

Pre-Installation Checklist

- Ensure your TV's weight and VESA pattern are within the mount's specifications.
- Identify your wall type (wood stud, concrete, or brick).
- Gather necessary tools (e.g., drill, stud finder, level, screwdriver).
- Have at least two people for installation, especially for larger TVs.

Step 1: Determine TV Compatibility (VESA Pattern)

Locate the four mounting holes on the back of your TV. Measure the horizontal and vertical distance between these holes to determine your TV's VESA pattern. This mount supports VESA patterns from 200x100mm to 600x400mm.

Handy Pull Cords

Easily lock or release your TV.



This diagram illustrates how to measure the horizontal and vertical distances between the mounting holes on the back of a television to determine its VESA pattern. It highlights the importance of checking VESA compatibility before installation.

Step 2: Attach TV Brackets to TV

Carefully place your TV face down on a soft, clean surface. Attach the vertical TV brackets to the back of your TV using the appropriate screws, washers, and spacers from the hardware kit. Ensure the brackets are centered and securely fastened.




This image shows the full-motion TV mount, highlighting its robust construction and articulating arms. This type of mount allows for significant extension and retraction from the wall, as well as swivel and tilt adjustments.

Step 3: Install Wall Plate

For Wood Studs: Use a stud finder to locate the center of your wood studs. Mark the drilling locations. Drill pilot holes and secure the wall plate using the provided lag bolts and washers. Ensure the wall plate is level.

For Concrete/Brick Walls: Mark the drilling locations. Drill pilot holes using a masonry drill bit. Insert concrete anchors into the holes, then secure the wall plate using the provided lag bolts and washers. Ensure the wall plate is level.

Wide Compatibility



VESA Patterns

600 × 400mm	400 × 300mm	200 × 400mm
600 × 300mm	400 × 200mm	200 × 300mm
600 × 200mm	300 × 300mm	200 × 200mm
400 × 400mm	300 × 200mm	200 × 100mm

This diagram illustrates the compatibility of the TV mount with different wall types: wood studs (16" to 24" spacing), concrete walls, and brick walls. It emphasizes that the mount should not be installed on drywall alone.

Step 4: Hang TV on Wall Plate

With assistance, carefully lift the TV with the attached brackets and hook them onto the wall plate. Ensure the TV is securely seated on the wall plate. For the PILTK4 tilt mount, engage the pull cords to lock the TV in place. For the PILF8 full-motion mount, secure the safety screws.

Certified for Reliability

132 lbs



This image displays the low-profile tilt TV mount, highlighting its slim design and the vertical brackets that attach to the TV. This mount allows for a fixed, close-to-wall installation with a slight tilt capability.

OPERATING YOUR TV WALL MOUNT

PILTK4 (Tilt Mount) Adjustments

- **Tilt Adjustment:** This mount allows for a downward tilt of up to 7 degrees to reduce glare. Loosen the tilt knobs on the side of the TV brackets, adjust to the desired angle, and then tighten the knobs to secure.
- **Security Locks:** The integrated pull cords allow you to easily lock or release the TV from the wall plate for added security or removal.

Perfect for Large TVs

TV Size: **37"—75"**

Max Load: **132 lbs**




This image highlights the "Anti-Drop Edges" feature of the tilt mount, which are designed to prevent the TV from accidentally sliding off the wall plate, enhancing safety and stability.

VESA Pattern Compatibility

Min: **200 x 100mm**


Max: **600 x 400mm**



This image demonstrates the "Handy Pull Cords" feature, which allows users to easily lock or release the TV from the wall mount, simplifying installation and removal.

Locate TV Ports

Brackets may block connections



This image emphasizes the "Strong Security Locks" feature, which ensures the TV is securely engaged with the mount, providing peace of mind after installation.

PILF8 (Full-Motion Mount) Adjustments

- **Swivel:** The articulating arms allow for a smooth ± 45 degree swivel, enabling you to adjust the TV's viewing angle from various positions in the room.
- **Tilt:** Adjust the tilt from $+5$ degrees to -15 degrees to optimize viewing and reduce glare. Loosen the tilt bolts, adjust, and re-tighten.
- **Leveling:** After installation, a ± 3 degree leveling adjustment is possible to ensure the TV is perfectly horizontal.
- **Extension/Retraction:** The mount can extend up to 15.4 inches from the wall for maximum flexibility and retract to a slim 3.2 inches to save space.




This image illustrates a television mounted using the full-motion bracket, demonstrating its swivel capability of ± 45 degrees for optimal viewing angles from different parts of a room.



This image demonstrates the extension and retraction capabilities of the full-motion TV mount, showing it can extend up to 15.4 inches from the wall for flexibility and retract to a compact 3.2 inches to save space.

Stable Support

Stronger dual arms enhance stability



This image highlights the "Stable Support" feature of the full-motion mount, emphasizing its stronger dual arms designed to enhance stability and securely hold the television.

MAINTENANCE

- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight and secure.
- **Cleaning:** Clean the mount with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Lubrication (Full-Motion Mount):** If the articulating arms become stiff, a small amount of silicone-based lubricant can be applied to the pivot points.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
TV not level after installation.	Wall plate or TV brackets not perfectly level.	For PILF8, use the +/-3 degree leveling adjustment. For PILTK4, re-adjust the wall plate if necessary.
Mount feels unstable or wobbles.	Screws are loose; incorrect wall type; TV exceeds weight capacity.	Tighten all screws. Ensure installation on appropriate wall type. Verify TV weight is within limits.
TV does not fit the mount.	Incorrect VESA pattern or TV size.	Verify your TV's VESA pattern and size against the mount's specifications (37-75 inches, VESA 200x100mm to 600x400mm).

PRODUCT SPECIFICATIONS

Feature	PILTK4 (Tilt Mount)	PILF8 (Full-Motion Mount)
TV Size Compatibility	37-75 inches	37-75 inches
Weight Capacity	Up to 132 lbs	Up to 100 lbs
VESA Compatibility	200x100mm to 600x400mm	
Tilt Angle	Down 7°	+5°/-15°
Swivel Angle	N/A (Fixed)	+/-45°
Leveling Adjustment	N/A	+/-3°
Profile from Wall	1.44 inches	3.2 inches (retracted) to 15.4 inches (extended)
Material	Alloy Steel	
Wall Type Compatibility	16"-24" Wood Studs, Concrete, Brick	




This image highlights the UL Listed certification for reliability and the maximum weight capacity of 132 lbs for the tilt mount, ensuring product safety and durability.

Mount on Any Wall

Concrete
Walls

Wood Studs

Brick
Walls



This image visually represents the wide compatibility of the TV mount, indicating it fits TVs from 37 to 75 inches and lists various supported VESA patterns, from 200x100mm up to 600x400mm.

WARRANTY INFORMATION






Pipishell products typically come with a manufacturer's warranty covering defects in materials and workmanship. For specific warranty terms and duration, please refer to the warranty card included with your product or visit the official Pipishell website. Keep your purchase receipt as proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you encounter any issues during installation or operation, or if you have questions about your Pipishell TV Wall Mount, please contact our customer support team. You can usually find contact information (email, phone, or website) on the product packaging or the official Pipishell website.


For more information and support, visit the [Pipishell Store on Amazon](#).

Related Documents - PILTK4, PILF8

<p>INSTRUCTION MANUAL</p> <p>Rev020A</p> <p>PILFK1</p>  <p>Full-Motion TV Wall Mount</p> <p>USA/CA 1-800-808-8829 UK 0044-1452-355-144-3588</p> <p>support@pipishell.com www.pipishell.com</p>	<p>Pipishell PILFK1 Full-Motion TV Wall Mount Instruction Manual</p> <p>Comprehensive installation guide for the Pipishell PILFK1 full-motion TV wall mount. Covers VESA compatibility, weight limits, wall type requirements, parts list, step-by-step assembly, safety information, and FAQs for TVs up to 132 lbs.</p>
<p>INSTRUCTION MANUAL</p> <p>Rev03</p> <p>PIMF7</p>  <p>Full-Motion TV Wall Mount</p> <p>USA/CA 1-800-808-8829 (US/CA) UK 0044-1452-355-144-3588 (UK)</p> <p>support@pipishell.com www.pipishell.com</p>	<p>Pipishell PIMF7 Full-Motion TV Wall Mount Instruction Manual</p> <p>Comprehensive instruction manual for the Pipishell PIMF7 full-motion TV wall mount, covering installation, safety, compatibility, and adjustment for TVs up to 77 lbs.</p>
<p>Pipishell</p> <p>Installation Instruction</p>  <p>PISF1</p> <p>Thank you for choosing our product! We strive to provide the highest quality and service for our customers. Should you have any questions, please contact us. If you are a retailer, please contact your distributor. If you are a customer, please contact us directly. We are committed to providing the best service possible. Please contact us at the following phone numbers or email addresses. We are committed to providing the best service possible. Please contact us at the following phone numbers or email addresses.</p> <p>USA/CA 1-800-808-8829 (US/CA) UK 0044-1452-355-144-3588 (UK)</p> <p>support@pipishell.com www.pipishell.com</p>	<p>Pipishell PISF1 TV Wall Mount Installation Guide</p> <p>Comprehensive installation instructions for the Pipishell PISF1 TV wall mount, covering VESA measurement, hardware selection, wall plate mounting (concrete and wood studs), and TV attachment. Includes safety warnings and parts list.</p>
<p>INSTRUCTION MANUAL</p> <p>Rev03</p> <p>PISF1</p>  <p>Full-Motion TV Wall Mount</p> <p>USA/CA 1-800-808-8829 (US/CA) UK 0044-1452-355-144-3588 (UK)</p> <p>support@pipishell.com www.pipishell.com</p>	<p>Pipishell PISF1 Full-Motion TV Wall Mount Installation Guide</p> <p>Detailed installation guide for the Pipishell PISF1 Full-Motion TV Wall Mount. Covers safety, parts, and step-by-step assembly for VESA 200x200mm, 44 lbs capacity TVs.</p>
<p>Full Motion TV Wall Mount Instruction Manual</p>  <p>Model: PIMFK3</p> <p>Thank you for choosing the product! We strive to provide you with the best quality products and services in the industry. Should you have any questions, please contact us. If you are a retailer, please contact your distributor. If you are a customer, please contact us directly. We are committed to providing the best service possible. Please contact us at the following phone numbers or email addresses. We are committed to providing the best service possible. Please contact us at the following phone numbers or email addresses.</p> <p>USA/CA 1-800-808-8829 (US/CA) UK 0044-1452-355-144-3588 (UK)</p> <p>support@pipishell.com www.pipishell.com</p>	<p>Pipishell PIMFK3 Full Motion TV Wall Mount Instruction Manual</p> <p>Comprehensive instruction manual for the Pipishell PIMFK3 Full Motion TV Wall Mount. Learn how to safely install and adjust your TV mount for optimal viewing.</p>

FAQ

Question: It's too hard to adjust the swivel angle or extension of the TV Wall Mount.
Answer: Make sure to use the correct size of the adjustment screw. For the swivel, use the 1/4" hex head screw. For the extension, use the 1/8" hex head screw. Do not point on the screw or the TV.
A If you have the Option 1, the adjustment is still too hard, by loosening the anti-rattle lock, it will be easier to adjust.



001-01000-01 Rev02


Pipishell TV Wall Mount Adjustment Troubleshooting Guide

Troubleshoot common issues with your Pipishell full-motion TV wall mount, including how to adjust swivel angle and extension. Learn step-by-step solutions for stiff joints and movement problems.

Documents - Pipishell – PILTK4, PILF8

FAQ

Question: How can I raise/lower the TV if the TV Wall Mount is already fixed on the wall?
1. Remove the TV from the TV Wall Mount.
2. Remove the TV brackets from the TV and reattach according to instructions A or B in the picture below (A for lifting up the TV or B for lowering the TV).
3. Hang the TV on the TV Wall Mount and secure.
A To raise the TV by a few inches, reattach the TV brackets using the upper holes in the brackets.
B To lower the TV by a few inches, reattach the TV brackets using the lower holes in the brackets.




01

[pdf] Instructions Frequently Asked Questions Troubleshooting Guide Guide
PILTK4 C FAQs Troubleshooting Guide Amazon Pipishell UL Listed Tilt TV Wall Mount Bracket Low Profile for Most 37 75 Inch LED LCD OLED Plasma Flat Curved TVs Large Tilting Fits 16 24 Wood Studs Max VESA 600x400mm Holds up to 132lbs Electronics A1NZFPFleqL m media amazon images I |||
FAQ Question: How can I raise/lower the TV if the TV Wall Mount is already fixed on the wall 1. Remove the TV from the TV Wall Mount. 2. Remove the TV brackets from the TV and reattach according to instructions A or B in the picture below A for lifting up the TV or B for lowering the TV . 3. Hang...
lang:fr score:19 filesize: 1.28 M page_count: 2 document date: 2023-08-25

FAQ

Question: How can I raise/lower the TV if the TV Wall Mount is already fixed on the wall?
1. Remove the TV from the TV Wall Mount.
2. Remove the TV brackets from the TV and reattach according to instructions A or B in the picture below (A for lifting up the TV or B for lowering the TV).
3. Hang the TV on the TV Wall Mount and secure.
A To raise the TV by a few inches, reattach the TV brackets using the upper holes in the brackets.
B To lower the TV by a few inches, reattach the TV brackets using the lower holes in the brackets.




[pdf] Frequently Asked Questions Troubleshooting Guide Guide
listing PILTK4 FAQ Troubleshooting guide Pipishell Tilt TV Wall Mount Bracket Low Profile for Most 37 75 Inch LED LCD OLED Plasma Flat Curved TVs Large Tilting Fits 16 24 Wood Studs Max VESA 600x400mm Holds up to 132lbs UL Listed Amazon ca Electronics A172 nv 6fL m media amazon images I |||
...
lang:fr score:17 filesize: 1.15 M page_count: 1 document date: 2024-01-09

INSTRUCTION
MANUAL

Rev04


PILF8



Full-Motion TV Wall Mount

1-800-556-9829 (US/CA)
44-808-196-3885 (UK)
support@pipishell.net
www.pipishellav.com

[pdf] User Manual
860 00470 00 Rev04 PILF8 Manual XS 2023 12 13 zq 1 800 556 9829 US CA 44 808 196 3885 UK
support@pipishell net Attach extension brackets to the TV Wall Mount If you have any questions
about C1cle4DvaeLm media amazon images I C1cle4DvaeL |||
...
lang:fr score:16 filesize: 7.32 M page_count: 20 document date: 2023-12-15



[Pipishell PILTK4 Tilting TV Wall Mount Instruction Manual](#)

Comprehensive instruction manual for the Pipishell PILTK4 Tilting TV Wall Mount, covering installation, safety information, and compatibility for various TV types and wall constructions.

lang:fr score:14 filesize: 5.85 M page_count: 19 document date: 2024-02-01



[\[pdf\] User Manual](#)

860 02431 00 Rev00 PILTK4 N1 Manual LZS 2023 10 27 listing zq User Pipishell Tilt TV Wall Mount Bracket Low Profile for Most 37 75 Inch LED LCD OLED Plasma Flat Curved TVs Large Tilting Fits 16 24 Wood Studs Max VESA 600x400mm Holds up to 132lbs UL Listed Amazon ca Electronics C1q1F5y2ftL m media amazon images I |||

...

lang:fr score:13 filesize: 5.85 M page_count: 19 document date: 2024-01-09