

[Manuals.plus](#) /

> [AirNmore](#) /

> AirNmore Comfort Buddy Space Heater User Manual

## AirNmore YD-909-CBA

# AirNmore Comfort Buddy Space Heater User Manual

Model: YD-909-CBA



## INTRODUCTION

---

The AirNmore Comfort Buddy Space Heater is designed to provide efficient and reliable heating for various indoor spaces. Its compact design, advanced safety features, and user-friendly controls make it an ideal solution for supplemental heating in bedrooms, basements, garages, and other areas. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Comfort Buddy heater.



Figure 1: AirNmore Comfort Buddy Space Heater with its handheld remote control.

## IMPORTANT SAFETY INSTRUCTIONS

### READ ALL INSTRUCTIONS BEFORE USING THIS HEATER.

- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use handles when moving this heater.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Return heater to authorized service facility for examination, electrical or mechanical adjustment, or repair.

- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable vapors or liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- This heater includes a PTC heating element with built-in overheat protection, a high limit safety sensor, and a tip-over safety sensor for enhanced safety.
- Equipped with a heavy-duty grounded AC cord for secure power connection.

## **PRODUCT COMPONENTS**

---

Familiarize yourself with the main components of your Comfort Buddy heater:



Figure 2: **Top Control Panel and Digital Display** - Used for manual operation and viewing temperature settings.



Figure 3: **Handheld Remote Control** - Allows convenient operation from a distance. Requires 2 AAA batteries (not included).



Figure 4: **Rear Air Intake Vent** - Where air is drawn into the heater. Ensure it is not obstructed.



Figure 5: **Removable Air Filter** - Located behind the rear intake vent for air purification.



Figure 6: **Compact Design with Recessed Handles** - Features built-in handles for easy relocation and high-quality casters for mobility.

## SETUP

1. **Unpack the Heater:** Carefully remove the heater from its packaging. Retain packaging for future storage or transport.

2. **Position the Heater:** Place the heater on a firm, level surface. Ensure there is at least 3 feet (0.9 m) of clear space around the front, sides, and rear of the heater to allow for proper airflow and to prevent fire hazards. Do not place on soft surfaces like carpets that may block air intakes.
3. **Power Connection:** Plug the heavy-duty grounded AC cord directly into a 110V wall outlet. Do not use extension cords, power strips, or surge protectors.
4. **Remote Control Batteries:** Open the battery compartment on the back of the remote control and insert 2 AAA batteries, observing the correct polarity.

## OPERATING INSTRUCTIONS

---

### Control Panel and Remote Control

The Comfort Buddy heater can be operated using the digital control panel on top of the unit or the included handheld remote control. Both offer similar functionalities.

- **Power Button:** Turns the heater ON or OFF.
- **Temperature Controls (Up/Down Arrows):** Adjusts the desired temperature setting from 40°F to 90°F (4°C to 32°C). The digital display will show the set temperature.
- **Quiet Mode Button:** Activates a quieter operating mode, reducing fan speed.
- **Timer Button:** Sets the 12-hour start/stop timer. Press repeatedly to cycle through timer settings.
- **Purifier Button:** Activates the air purification function (requires optional HEPA filter and PCO air purifier, sold separately).

### Basic Operation

1. **Turn On:** Press the Power button on the control panel or remote. The digital display will illuminate.
2. **Set Temperature:** Use the Up/Down arrow buttons to set your desired room temperature. The heater will automatically cycle on and off to maintain this temperature.
3. **Activate Quiet Mode (Optional):** Press the Quiet button for reduced fan noise.
4. **Set Timer (Optional):** Press the Timer button to set an automatic shut-off or turn-on time.
5. **Turn Off:** Press the Power button again to turn off the heater. The fan may continue to run for a short period to cool down the heating elements.

## MAINTENANCE

---

Regular maintenance ensures optimal performance and longevity of your Comfort Buddy heater.

### Cleaning

- Always unplug the heater from the wall outlet and allow it to cool completely before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use abrasive cleaners or solvents.
- Gently vacuum the air intake and exhaust vents to remove dust and debris.

### Filter Replacement/Cleaning

The Comfort Buddy heater features a removable air filter for easy cleaning.

1. Ensure the heater is unplugged and cool.
2. Locate the filter cover on the rear of the unit (refer to Figure 5).
3. Remove the filter cover and carefully slide out the air filter.

4. Clean the filter using a vacuum cleaner or by rinsing it under lukewarm water. If rinsing, ensure the filter is completely dry before reinserting.
5. Slide the clean filter back into its slot and replace the filter cover.

## TROUBLESHOOTING

If you experience issues with your Comfort Buddy heater, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Heater does not turn on.	No power, power button not pressed, tip-over switch activated, overheat protection activated.	Ensure unit is plugged into a live outlet. Press power button. Check if heater is on a stable, level surface. Unplug, wait 10 minutes, then plug back in to reset overheat protection.
No heat output.	Temperature setting too low, air intake/exhaust blocked.	Increase the temperature setting above the current room temperature. Check for and remove any obstructions from air vents.
Remote control not working.	Dead batteries, remote not aimed at sensor.	Replace AAA batteries in the remote. Ensure remote is aimed at the front of the heater.
Heater cycles on/off frequently.	Room temperature reached set temperature, sensor obstruction.	This is normal operation as the heater maintains the set temperature. Ensure nothing is blocking the temperature sensor.

## SPECIFICATIONS

Feature	Detail
Brand	AirNmore
Model Number	YD-909-CBA
Color	Black
Form Factor	Cabinet
Product Dimensions (D x W x H)	15.13" x 11.5" x 9.63"
Item Weight	15 Pounds
Heating Coverage	Up to 1000 square feet

Feature	Detail
Fuel Type	Electric
Voltage	110 Volts
Amperage	12.5 Amps
Temperature Range	40-90°F (4-32°C)
Special Features	PTC Heating Element, Built-In Overheat Protection, High Limit Safety Sensor, Tip-Over Safety Sensor, Heavy-Duty Grounded AC Cord, 12 Hour Start/Stop Timer, Quiet Mode, Digital Display, Handheld Remote Control, Optional HEPA filter and PCO air purifier capability.
Manufacturer	Better living with air & more, Inc
UPC	851977008014

## WARRANTY AND SUPPORT

---

The AirNmore Comfort Buddy Space Heater comes with a 2-Year Manufacturer's Warranty. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or inquiries about optional accessories (such as HEPA filters or PCO air purifiers), please contact AirNmore customer service directly. Refer to the contact information provided with your product packaging or visit the official AirNmore website.

**Manufacturer:** Better living with air & more, Inc

