

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AUSDOM](#) /

› [AUSDOM E7 Noise Cancelling Headphones User Manual](#)

AUSDOM E7

AUSDOM E7 Noise Cancelling Headphones User Manual

Model: E7

Brand: AUSDOM

INTRODUCTION

Thank you for choosing the AUSDOM E7 Noise Cancelling Headphones. These headphones are designed to provide a superior audio experience with advanced Active Noise Cancelling (ANC) technology, Hi-Fi sound, and comfortable over-ear design. This manual will guide you through the setup, operation, and maintenance of your new headphones.



Image: AUSDOM E7 Noise Cancelling Headphones, showcasing their modern black and silver design.

WHAT'S IN THE BOX

Your AUSDOM E7 package includes the following items:

- 1 x Wireless Noise Cancelling Headphones (AUSDOM E7)
- 1 x Type C Charging Cable
- 1 x Carry Bag
- 1 x User Manual

Your browser does not support the video tag.

Video: An unboxing demonstration of the AUSDOM E7 Noise Cancelling Headphones, showing all included accessories.

PRODUCT OVERVIEW

Familiarize yourself with the various components and controls of your AUSDOM E7 headphones:

- **Power Button:** Used to turn the headphones on/off and initiate Bluetooth pairing.
- **Volume Up/Down Buttons:** Adjusts the audio volume.
- **ANC Switch:** Toggles Active Noise Cancelling feature on or off.
- **3.5mm Audio Jack:** For wired connection to audio devices.
- **USB-C Charging Port:** For charging the headphones.
- **Microphone:** Built-in for calls and voice commands.



Image: Detail of the headphone ear cup, highlighting the ANC switch and other control buttons.

SETUP

Charging the Headphones

1. Connect the provided USB-C charging cable to the charging port on the headphones.
2. Connect the other end of the cable to a USB power source (e.g., computer, wall adapter).
3. The LED indicator will show charging status. A full charge provides up to 50 hours of playtime (ANC off) or 35 hours (ANC on). A 5-minute quick charge provides 2 hours of listening time.

TYPE C QUICK CHARGE

5 minutes of charging time offers you 2 hours of playtime.



Image: The AUSDOM E7 headphones connected to a USB-C charger, emphasizing the quick charge capability.

Bluetooth Pairing

1. Ensure the headphones are fully charged.
2. Press and hold the Power button until the LED indicator flashes red and blue, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "AUSDOM E7" from the list of devices.
5. Once connected, the LED indicator will turn solid blue or flash slowly.

Multipoint Connectivity

The AUSDOM E7 supports connecting to two Bluetooth devices simultaneously:

1. Pair the headphones with the first device as described above.
2. Disable Bluetooth on the first device.
3. Put the headphones back into pairing mode and pair with the second device.
4. Re-enable Bluetooth on the first device. The headphones should now be connected to both devices, allowing seamless switching between audio sources.



Image: Visual representation of the headphones connected to multiple devices via Bluetooth.

OPERATING INSTRUCTIONS

Active Noise Cancelling (ANC)

To activate or deactivate the Digital Active Noise Cancelling feature, use the dedicated ANC switch located on one of the ear cups. When ANC is on, the headphones will filter out up to 92% of ambient noise, providing a more immersive audio experience. Note: ANC functions even when audio is not playing.



ACTIVE NOISE CANCELLATION

Enhanced Active NC technology reduces 92% of unwanted low-frequency ambient noise.

Image: A user enjoying quiet on an airplane with AUSDOM E7 headphones, highlighting the ANC feature.

Audio Playback and Calls

- **Play/Pause:** Press the Multi-function button once.
- **Next Track:** Press and hold the Volume Up button.
- **Previous Track:** Press and hold the Volume Down button.
- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button.
- **Volume Adjustment:** Use the Volume Up/Down buttons.



50 HOURS PLAYTIME

Listen to your favorite audio content from dawn to dusk.

700 Folk Songs | **600** Rock Songs

Image: The AUSDOM E7 headphones next to a phone, illustrating the 50-hour playtime.

MAINTENANCE

- Clean the headphones regularly with a soft, dry cloth.
- Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight.
- Store the headphones in the provided carry bag when not in use to protect them from dust and scratches.
- Do not attempt to disassemble or modify the headphones, as this will void the warranty.

COMFORT OVER EAR DESIGN

Better fit achieves steady awesome comfort and less leak sound.



Image: Detailed view of the comfortable over-ear design and adjustable features of the headphones.

TROUBLESHOOTING

If you encounter any issues with your AUSDOM E7 headphones, please refer to the following common solutions:

- **No Power:** Ensure the headphones are fully charged.
- **Cannot Pair:** Make sure the headphones are in pairing mode (LED flashing red and blue) and within range of your device. Try restarting both the headphones and your device.
- **No Sound:** Check the volume levels on both the headphones and your connected device. Ensure the headphones are correctly paired. If using a wired connection, ensure the 3.5mm cable is fully inserted.
- **ANC Not Working:** Verify the ANC switch is in the 'On' position.
- **Poor Sound Quality:** Ensure there are no obstructions between the headphones and your device. Try moving closer to your device to reduce interference.

SPECIFICATIONS

Feature	Detail
Model Name	E7
Brand	AUSDOM
Connectivity Technology	Wired, Wireless (Bluetooth 4.0)
Noise Control	Active Noise Cancellation
Battery Life	Up to 50 Hours (ANC off), 35 Hours (ANC on)
Charging Time	5 minutes for 2 hours playtime
Audio Driver Size	40 Millimeters
Earpiece Shape	Over-Ear
Material	Leather, Plastic, Stainless Steel
Special Features	Adjustable Headband, Rechargeable Battery, Multipoint Pairing, Volume Control, Call Control
Item Weight	1.19 pounds

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official AUSDOM website. Keep your proof of purchase for any warranty claims.