

Skywin SW-LSS-BEIGE

Skywin TidyFriend Liquid Laundry Detergent Holder Stand

MODEL: SW-LSS-BEIGE - INSTRUCTION MANUAL

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your Skywin TidyFriend Liquid Laundry Detergent Holder Stand. Designed for ease and efficiency, this stand helps organize your laundry area and simplifies the dispensing of liquid detergents and fabric softeners. Please read these instructions carefully before use.

Setup and Installation

The TidyFriend Liquid Laundry Detergent Holder Stand is designed for quick and easy assembly. Follow these steps to set up your stand:

- Unpack Components:** Carefully remove all parts from the packaging. You should have the main stand body and an adjustable strap.
- Assemble the Stand:** The stand typically consists of interlocking plastic pieces. Gently slide the pieces together until they securely click into place. No tools are required for assembly.
- Position the Container:** Place your liquid laundry detergent or fabric softener container onto the top of the assembled stand. Ensure the dispenser spout of the container aligns with the opening on the stand.
- Secure with Strap:** Fasten the adjustable strap around the detergent container and the stand. Make sure the strap is snug enough to hold the container firmly in place, preventing it from rolling or shifting during use. The strap features rubber grips on the inside for enhanced stability.
- Place Drip Tray:** Insert the molded drip tray into its designated slot at the front of the stand, directly beneath the container's spout. This tray will catch any drips and can also hold the measuring cup.

The Original Laundry Soap Station



Drip catch shelf + Angled Slope

Image: The assembled stand with a detergent bottle, highlighting the securing strap and drip tray.

Video: A demonstration of how to place a detergent bottle onto the stand and secure it, showing the angled design for easy dispensing.

Operating Instructions

The TidyFriend stand is designed for hands-free, easy pouring:

- 1. Prepare for Dispensing:** Ensure the measuring cup is placed on the drip tray directly under the container's spout.
- 2. Dispense Liquid:** Press the button or open the tap on your detergent container's spout. The angled platform of the stand uses gravity to facilitate a smooth, effortless flow of liquid into the measuring cup.
- 3. Stop Dispensing:** Release the button or close the tap once the desired amount of liquid is dispensed. Any residual drips will fall into the drip tray.

4. **Use and Store Cup:** Use the dispensed liquid as needed. The measuring cup can be left on the drip tray to catch any further drips and keep your counter clean.



Image: The stand accommodates various detergent bottle sizes, making dispensing simple and mess-free.

Features and Benefits

- **Universal Fit:** Designed to fit most detergent and softener bottles (7.9" L x 12.2" W x 5.5" H), providing a seamless addition to your laundry setup without taking up unnecessary space.
- **Effortless Pouring:** The downward-angled platform eliminates the need to lift or tilt heavy containers, allowing gravity to deliver smooth, easy soap flow.
- **Mess-Free Operation:** Non-slip rubber feet and a molded drip tray catch every drop, keeping your counters spotless and slip-free.

- **Secure Placement:** An adjustable strap locks your detergent bottle in position, ensuring stable and secure storage without sliding or falls.
- **Integrated Organization:** Functions as an all-in-one station for your detergent bottle and measuring cup, also suitable for fabric softener.




Image: The secure design of the stand prevents messy leaks and spills.

Maintenance

To ensure the longevity and hygiene of your TidyFriend Liquid Laundry Detergent Holder Stand, regular cleaning is recommended:

- **Clean the Drip Tray:** The molded drip tray is removable for easy cleaning. Simply slide it out, rinse with warm water, and wipe clean with a cloth.

- **Wipe Down the Stand:** Use a damp cloth to wipe any spills or dust from the main body of the stand. Mild soap can be used for tougher stains.
- **Check Rubber Feet:** Periodically inspect the rubber-grip feet for wear and tear to ensure continued stability.
- **Strap Care:** If the adjustable strap becomes soiled, it can be wiped clean with a damp cloth.



Image: The removable drip tray simplifies cleaning and maintenance.

Troubleshooting

- **Slow Dispensing:** If the detergent dispenses slowly, ensure the container's cap (if applicable) is slightly loosened to allow air to enter and prevent a vacuum.
- **Stand Instability:** Verify that the adjustable strap is securely fastened around the detergent

container and the stand. Check that all rubber-grip feet are present and making full contact with the surface.

- **Drips Outside Tray:** Ensure the detergent container's spout is positioned correctly over the drip tray. Clean the spout regularly to prevent residue buildup that might cause misdirected drips.

Specifications

Feature	Detail
Brand	Skywin
Model Number	SW-LSS-BEIGE
Color	Beige
Material	Plastic
Product Dimensions (L x W x H)	12.2 x 7.9 x 5.5 inches
Item Weight	1.3 pounds (0.59 Kilograms)
Special Features	Adjustable Straps Lock, Angled Dispensing Design, Easy Organization, Hands-Free Drip Catching Capability, Spill-Proof Drip Tray System
Assembly Required	No

Warranty and Support

For any questions regarding your Skywin TidyFriend Liquid Laundry Detergent Holder Stand, or for information on warranty and support, please refer to the contact information provided with your purchase or visit the official Skywin website. Keep your proof of purchase for warranty claims.