ONN 100012589

ONN 32-inch Roku Smart TV User Manual

Model: 100012589

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your ONN 32-inch Roku Smart TV. Please read this manual thoroughly before using your television to ensure proper and safe operation. Keep this manual for future reference.



Image: The ONN 32-inch Roku Smart TV shown with its display and the included wall mount components below it.

Package Contents

Verify that all items are present in your package:

- ONN 32-inch Roku Smart TV
- TV Stand (2 pieces)
- Remote Control (batteries not included)
- Power Cord
- Quick Start Guide
- Wall Mount Kit



Image: A detailed view of the wall mount kit components, including the main bracket, hanging straps, screws, anchors, and a small level.

Setup

1. Attaching the TV Stand

1. Carefully place the TV face down on a soft, clean surface to prevent screen damage.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure the stands with the provided screws.

2. Wall Mount Installation (Optional)

If you choose to wall mount your TV, use the included wall mount kit. Ensure the wall can support the TV's weight and follow all instructions provided with the wall mount kit for safe installation.



Image: An illustration demonstrating the installation process for the ultra-slim TV wall mount, highlighting how to pull down the cord to release the bracket.

3. Connecting Peripherals

Your TV features multiple connection ports:

- **HDMI:** 3 ports for connecting devices like cable boxes, game consoles, or Blu-ray players.
- **Composite:** 1 port for older devices.
- **USB:** 1 port for media playback.
- **Optical:** 1 port for digital audio output.
- **Coaxial/Cable:** 1 port for antenna or cable TV connection.
- **Headphone:** 1 port for private listening.

Connect the power cord to the TV and then to a power outlet.

Operating Your TV

1. Initial Setup and Roku OS

Upon first power-on, the TV will guide you through the initial setup process, including connecting to Wi-Fi and activating your Roku account. The Roku OS provides access to over 500,000 movies and TV episodes.



Image: The ONN Roku TV home screen displaying icons for various streaming services such as Netflix, Disney+, Apple TV, Peacock, Roku Channel, and HBO Max.

2. Voice Control Integration

This TV is compatible with popular voice assistants, including Amazon Alexa, Google Assistant, and Apple HomeKit. You can use voice commands to find content, launch apps, change channels, and switch inputs.



Image: A graphic illustrating the TV's compatibility with various smart home ecosystems, including Apple AirPlay, Apple Home, Amazon Alexa, and Google Home.

3. Roku Mobile App

Download the free Roku mobile app for iOS or Android to control your TV. The app allows for quick search, voice control, private listening via headphones, and casting photos or videos from your phone to the TV.




Image: Three smartphone screens displaying the Roku mobile app interface, showing remote control functions, channel browsing, and voice search capabilities.

4. Streaming Content

Access a wide array of streaming services directly from your TV. The Roku platform offers a massive selection of free, live, and premium TV channels.



Image: The ONN Roku TV screen showcasing a selection of popular streaming app icons, including Netflix, Disney+, Apple TV, Peacock, Roku Channel, and Paramount+.

Maintenance

To ensure the longevity and optimal performance of your TV, follow these maintenance guidelines:

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, dampen the cloth slightly with water or a screen-specific cleaning solution. Avoid harsh chemicals.
- **Cleaning the Cabinet:** Use a soft, dry cloth to clean the TV cabinet.
- **Ventilation:** Ensure the ventilation openings on the TV are not blocked. Do not place the TV in an enclosed space without adequate airflow.
- **Power Cord:** Regularly check the power cord for any damage. If damaged, replace it immediately.
- **Unplugging:** Unplug the TV from the power outlet during lightning storms or when it will be left unattended for long periods.

Troubleshooting

Refer to the table below for common issues and their solutions:

Problem	Possible Solution
No Power	Ensure the power cord is securely plugged into both the TV and a working electrical outlet. Test the outlet with another device.
No Picture/Sound	Check all cable connections (HDMI, composite). Ensure the correct input source is selected on the TV. For sound, check volume levels and mute settings.
Remote Control Not Working	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.
Wi-Fi Connection Issues	Restart your router and modem. Go to the TV's network settings and re-scan for networks. Ensure you are entering the correct Wi-Fi password.
App Not Loading/Crashing	Restart the TV. Check for system updates in the TV's settings. Reinstall the problematic app if necessary.

SPECIFICATIONS

Feature	Detail
Brand	ONN
Model Number	100012589
Screen Size	32 Inches (82 cm diagonal)
Display Technology	LED
Resolution	720p HD
Refresh Rate	60 Hz
Aspect Ratio	1.78:1
Product Dimensions (with stand)	7.1"D x 29"W x 18.7"H
Item Weight	13.37 pounds
Speaker Type	Built-In (2x 8W speakers)
Connectivity	3 HDMI, 1 Composite, 1 USB, 1 Optical, 1 Coaxial/Cable, 1 Headphone
Special Features	Works with Alexa & Google Assistant, Apple HomeKit compatible, Wi-Fi Connectivity



Image: A circular graphic highlighting "720P HD" resolution, indicating the display quality of the television.




Image: The ONN TV mounted on a vibrant orange wall in a modern living room setting, demonstrating its aesthetic integration when wall-mounted.

Warranty and Support

This product is sold as a Renewed item. Please refer to the specific warranty terms provided by Amazon Renewed or the seller, "Exclusive Bulbs", at the time of purchase. Typically, Amazon Renewed products come with a 90-day refund or replacement policy.
For technical support or warranty claims, please contact the seller directly or refer to the Amazon Renewed support page. You may also find assistance through the Roku support website for software-related inquiries.

- **Seller:** Exclusive Bulbs
- **Amazon Renewed Support:** Amazon Renewed Help Page
- **Roku Support:** Roku Support Website

© 2025 ONN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question