

TARKARI W3

TARKARI W3 Free Standing Heavy Duty Garment Rack Instruction Manual

Model: W3

INTRODUCTION

Thank you for choosing the TARKARI W3 Free Standing Heavy Duty Garment Rack. This instruction manual provides detailed guidance for the assembly, operation, and maintenance of your new clothing organizer. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Do not overtighten screws during initial assembly; tighten fully only after all components are in place.
- Distribute weight evenly across the hanging rods and shelves to maintain stability.
- Do not exceed the maximum load capacity of 135 pounds.
- Keep small parts and packaging materials away from children.
- For added stability, consider securing the unit to a wall, especially if heavily loaded or placed in an area with potential for tipping.

PACKAGE CONTENTS

Please verify that all components listed below are included in your package:

- **Metal Frames:**
 - Top Tubes (Parts 1, 3, 5)
 - Bottom Tubes (Parts 2, 4, 6)
 - Cross Bars (Part 7)
 - Clothesline (Part 10)
 - Large Clothesline (Part 11)

- Diagonal Cross Bar (Part 12)

- **Wooden Boards:**

- Small Boards (Part 8)
- Large Boards (Part 9)

- **Hardware & Tools:**

- Allen Wrenches (A, B)
- Connectors (C)
- Screws (D, E, F, G, H)
- Adjusting Feet (I)
- Hooks (J)
- Anti-tip Kit (K)

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your TARKARI W3 Garment Rack. Refer to the included diagrams for visual guidance.

Your browser does not support the video tag.

Video: Detailed assembly guide for the TARKARI W3 Garment Rack. This video demonstrates each step of the installation process, from attaching the feet to securing the shelves and hanging rods.

1. **Install Adjusting Feet:** Install the adjusting feet (I) onto the bottom tubes (2, 4, 6) separately.
2. **Connect Frame Sections:** Install the top tubes (1, 3, 5) and the bottom tubes (2, 4, 6) together using the connectors (C). Ensure a snug fit.
3. **Attach Cross Bars:** Attach the cross bars (7) to the iron frame using screws (G). It is recommended to attach the top cross bars first to help maintain alignment. Do not fully tighten all screws until the entire frame is assembled.
4. **Attach Small Boards:** Secure the small boards (8) to the top and bottom sections of the iron frame using screws (D). Insert one screw halfway, then the second, and alternate tightening them to ensure the board sits flush.
5. **Fix Clothesline (Short):** Fix the clothesline (10) to the iron frame using screws (F).
6. **Secure Large Clothesline:** Secure the large clothesline (11) to the designated ears on the rack with screws (F).
7. **Fix Diagonal Cross Bar:** Fix the diagonal cross bar (12) to the iron frame using screws (E). Ensure the bar faces outward for proper stability.
8. **Lock Connections:** Once all components are in place and aligned, fully tighten all screws (H) to secure the upper and lower tube connections.

OPERATING INSTRUCTIONS

The TARKARI W3 Garment Rack is designed for versatile clothing storage. Here are some tips for optimal use:

- **Hanging Clothes:** Utilize the multiple hanging rods for various garment lengths. The taller section is ideal for long coats and dresses, preventing creases.
- **Shelf Storage:** Use the wooden shelves for folded clothes, shoes, bags, or storage boxes. The top shelf can accommodate luggage or other larger items.

- **Accessory Hooks:** The movable hooks (J) can be placed in various positions on the frame to hang bags, hats, scarves, or other accessories.
- **Weight Distribution:** Always distribute the weight of your items evenly across the rack to maintain balance and prevent tipping.



Image: A detailed diagram of the TARKARI W3 Garment Rack showing its dimensions and individual weight capacities for different sections, including hanging rods and shelves.



Image: A close-up view of the TARKARI W3 Garment Rack highlighting the specially designed tall section for hanging long garments like coats and dresses without wrinkling.



Image: A detailed view of the movable hooks on the TARKARI W3 Garment Rack, demonstrating their versatility for hanging various accessories like bags and hats.

Your browser does not support the video tag.

Video: A general overview of the TARKARI W3 Free Standing Garment Rack, showcasing its design and various storage capabilities in a home setting.

MAINTENANCE

- **Cleaning:** Wipe down the metal frame and wooden shelves with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Rust Prevention:** The rack features a rust-proof coating. To maintain this, avoid prolonged exposure to moisture.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.
- **Adjusting Feet:** Use the adjustable feet to level the rack on uneven surfaces, preventing wobbling.



165LBS TOP SHELF STORAGE

The top of the hanger can accommodate luggage and other items, making it easy for you to save space.

Image: A close-up view of the adjustable feet on the TARKARI W3 Garment Rack, illustrating how they can be used to stabilize the unit on uneven flooring.

TROUBLESHOOTING

- **Wobbling/Instability:**
 - Ensure all screws are fully tightened.
 - Adjust the leveling feet (I) on the bottom of the frame to compensate for uneven floors.
 - Verify that the diagonal cross bar (12) is correctly installed and tightened, as it provides crucial stability.
- **Parts Not Fitting:**
 - Double-check the part numbers against the instruction manual to ensure you are using the correct components for each step.
 - Ensure screws are not overtightened prematurely, which can misalign holes. Loosen screws slightly, adjust the parts, and then retighten.
- **Insufficient Hanging Space:**
 - Utilize the movable hooks (J) for additional hanging options for accessories.
 - Consider folding bulkier items for shelf storage to maximize hanging rod space.

SPECIFICATIONS

Feature	Detail
Model Number	W3
Product Dimensions	15.75"D x 47.24"W x 71.65"H
Material	Iron, Metal, Wood
Load Capacity	135 Pounds (Total)

Number of Shelves	1
Special Feature	Rust-Proof, Adjustable Feet
Installation Type	Free Standing
Item Weight	42.8 Pounds

WARRANTY AND SUPPORT

TARKARI takes pride in delivering exceptional customer service and providing satisfactory guarantees for our products. While a specific warranty period is not detailed, if you encounter any issues with your garment rack, please do not hesitate to reach out to our customer service team. We are committed to resolving any problems to your satisfaction. For support, please visit the TARKARI Store on Amazon or contact our customer service directly through your purchase platform.

© 2023 TARKARI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question