

DOGNESS F10

DOGNESS F10 Automatic Pet Feeder with 1080P Camera User Manual

Model: F10

[Introduction](#)[Product Overview](#)[Setup](#)[Operation](#)[Maintenance](#)[Troubleshooting](#)[Specifications](#)[Warranty &](#)[Support](#)

1. INTRODUCTION

Thank you for choosing the DOGNESS F10 Automatic Pet Feeder with 1080P Camera. This device is designed to provide a convenient and reliable feeding solution for your pets, allowing you to manage their meal schedules and monitor them remotely via a smartphone application. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. PRODUCT OVERVIEW

The DOGNESS F10 feeder integrates smart technology with practical design to ensure your pet is fed on time and in appropriate portions. Key features include a 1080P wide-angle camera, app control, dual power supply, and an anti-jamming system.

2.1 Components



Image: DOGNESS F10 Automatic Pet Feeder with its various parts labeled, including the desiccant storage, WiFi indicator, microphone, RGB rainbow light, ultra wide-angle HD night vision camera, food outlet, reset & manual feeding button, low food detection light, stainless steel bowl, and rubber anti-slippery pad.


- **Food Hopper:** Stores dry pet food (up to 4L/16 cups).
- **1080P HD Camera:** Provides live video feed with night vision for remote monitoring.
- **Stainless Steel Bowl:** Removable for easy cleaning.
- **Control Panel:** Includes a manual feeding button and indicator lights.
- **Desiccant Storage:** Helps keep food fresh.
- **Dual Power Supply:** Supports both USB power and D-cell batteries for backup.

3. SETUP

3.1 Powering the Feeder

1. Connect the USB power cable to the feeder and a power outlet.
2. For backup power, open the battery compartment at the bottom of the feeder and insert three (3) D-cell batteries (not included).

Dual Power Supply



USB charging


3XD Batteries
(Not Included)

Image: The DOGNESS F10 Automatic Pet Feeder demonstrating its dual power supply options: USB charging and a compartment for 3x D-cell batteries (not included).

3.2 App Download and Connection

1. Download the "DOGNESS" app from the App Store (iOS) or Google Play Store (Android).
2. Register an account and log in.
3. Plug in the feeder to power it on. Wait for the WiFi indicator light to flash.
4. In the app, tap the "+" button to add a device. Select "Bluetooth searching" or "Add manually" to find "Dogness Wide-view Cam Feeder F10".
5. Press and hold the "Reset" button on the feeder for 6 seconds until you hear a "beep" sound and the WiFi signal light flashes slowly.
6. Follow the in-app instructions to connect to your 2.4Ghz WiFi network. (Note: The app is not compatible with 5Ghz WiFi networks).

How to Connect the DOGNESS App Feeder?



STEP 1: Download App

- Search and download the DOGNESS APP
- Open the App, register your account
- Log in your account



STEP 2: Add Device in the APP

- Plug in to power on the device
- Click the "+" button
 - a) "Bluetooth searching" or
 - b) "Add manually" to find "Wide-view Cam Feeder F10"



Dogness Wide-view Cam Feeder F10

"Reset" Button for 6 seconds



STEP 3: Connect the Feeder

- After plugging in the power, please wait for about 10 seconds until the wifi signal light flashes slowly.
- Please press and hold the "Reset" button for 6 seconds until you hear the "beep" sound, and then release the button. Please wait for 10 seconds until the wifi signal light flashes slowly before connecting.
- Enter the Wifi name and password.

NOTE: Make sure your App connects to 2.4GHz wifi network during App setup (only support 2.4GHz wifi network, not compatible with 5 GHz wifi network, If the Wi-Fi router supports both 5GHz and 2.4GHz, please turn off 5GHz and keep the router only working for 2.4GHz.)

- After successful connection, it is ready to use. If you have an issue please contact customer service at support@dogness.com



Wifi indicator light in the feeder (Green):

Slow flashing -It means that the feeder is ready to connect to wifi (Configurable status);

Fast flashing -It means that the feeder is connecting to wifi network;

Solid light -It means the wifi network is connected successfully;

Image: A visual guide demonstrating the three steps to connect the DOGNESS F10 Automatic Pet Feeder to the app, including downloading the app, adding the device, and connecting to WiFi.

Your browser does not support the video tag.

Video: This video demonstrates the process of connecting the DOGNESS F10 Automatic Pet Feeder to a WiFi network using the companion app.

3.3 Filling the Food Hopper

1. Remove the top lid of the feeder.
2. Pour dry pet food into the hopper. Ensure the food size is appropriate for the feeder mechanism to prevent jamming.
3. Securely close the lid to maintain food freshness.




Image: The DOGNESS F10 Automatic Pet Feeder highlighting its patented anti-grain jamming system and a reminder feature for insufficient grain levels.

4. OPERATING INSTRUCTIONS

4.1 Scheduling Feeds via App

1. Open the DOGNESS app and select your feeder.
2. Navigate to the "Feeding Plan" section.
3. Set desired meal times and portion sizes. You can customize multiple feeding schedules per day.
4. Save your settings. The feeder will automatically dispense food according to the schedule.

4.2 Manual Feeding

- **Via App:** In the app, select "Feed now" and choose the desired portion size to dispense food immediately.
- **Via Feeder Button:** Press the manual feeding button on the feeder to dispense a single portion.

4.3 Remote Monitoring and Interaction



Image: The DOGNESS F10 Automatic Pet Feeder displaying its 1080p super wide-angle camera with night vision, alongside a smartphone screen showing a live feed of a pet.

- **Live Video Feed:** Use the app to view your pet in real-time through the 1080P HD camera. The camera features a wide-view lens and night vision.
- **Two-Way Audio:** Speak to your pet remotely and hear their responses through the built-in microphone and speaker.
- **Voice Control:** The feeder supports AI voice control for dispensing meals (e.g., via smart home assistants).

Your browser does not support the video tag.

Video: This video provides an overview of the DOGNESS Automatic Wide View Smart Camera Dog/Cat Feeder, showcasing its features and functionality.

5. MAINTENANCE

Regular cleaning ensures the longevity and hygienic operation of your pet feeder.

5.1 Disassembly and Cleaning

1. Unplug the feeder from the power source.
2. Remove the stainless steel bowl and wash it with soap and water. Rinse thoroughly and dry.

- 3. Remove the food hopper and wash it with soap and water. Ensure all food residue is removed. Rinse and dry completely before reassembling.
- 4. Wipe the main body of the feeder with a damp cloth. Do not immerse the main body in water.
- 5. Ensure all parts are completely dry before reassembling and refilling with food.

Your browser does not support the video tag.

Video: This video provides instructions on how to clean the food storage compartment of the DOGNESS F10 Automatic Pet Feeder.

6. TROUBLESHOOTING

- **Feeder not dispensing food:**
 - Check if the food hopper is empty.
 - Ensure the feeder is powered on and connected to the app.
 - Verify that the food is not jammed. Clean the food outlet if necessary.
 - Check the feeding schedule in the app.
- **App not connecting to feeder:**
 - Ensure your phone is connected to a 2.4Ghz WiFi network.
 - Restart the feeder and your router.
 - Try resetting the feeder by pressing the reset button for 6 seconds.
 - Ensure the feeder is within range of your WiFi router.
- **Camera not working:**
 - Check your internet connection speed.
 - Ensure the camera lens is clean and unobstructed.
 - Restart the feeder.
- **Food not staying fresh:**
 - Ensure the top lid is securely closed.
 - Replace the desiccant pack regularly (if applicable).

7. SPECIFICATIONS

Feature	Detail
Model Number	F10
Capacity	4L / 16 Cups
Camera Resolution	1080P HD with Night Vision
Connectivity	2.4G WiFi (not compatible with 5G WiFi)
Power Supply	USB (10 ft. cable included) and 3x D-cell batteries (backup, not included)
Dimensions (LxWxH)	8 x 9 x 13.5 inches
Item Weight	5.89 pounds

Feature	Detail
Material	Stainless Steel (bowl)
Care Instructions	Hand Wash Only (removable parts)
Target Species	Cat, Dog
Special Features	Portion Control, Speaker, Timer, Anti-jamming system

8. WARRANTY & SUPPORT

8.1 Warranty Information

DOGNESS products are manufactured with high-quality materials and craftsmanship. This product is covered by a limited warranty against defects in materials and workmanship. Please refer to the warranty card included with your purchase or visit the official DOGNESS website for detailed warranty terms and conditions.

8.2 Customer Support

If you encounter any issues or have questions regarding your DOGNESS F10 Automatic Pet Feeder, please contact our customer support team:

- **Email:** support@dogness.com
- **Online:** Visit the [DOGNESS Store on Amazon](#) or the official DOGNESS website for FAQs and further assistance.