

- Manuals.plus /
- > Superer /
 - > Superer 230W Charger Instruction Manual for Razer Blade Laptops (Model ADP195118T)

Superer ADP195118T

Superer 230W Charger Instruction Manual for Razer Blade Laptops (Model ADP195118T)

Model: ADP195118T | Brand: Superer

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Superer 230W power adapter, designed for various Razer Blade laptop models. Please read this manual thoroughly before use and retain it for future reference.



Image 1.1: The Superer 230W power adapter and its accompanying power cord.

2. SAFETY INFORMATION

The Superer 230W charger is UL Listed, meeting nationally recognized standards for high-level electronic safety. Adherence to these guidelines ensures safe operation.

- Do not expose the charger to liquids or extreme temperatures.
- Avoid dropping or subjecting the charger to severe impacts.
- Ensure proper ventilation around the charger during use.
- Use only with compatible devices as specified in this manual.
- Disconnect the power adapter from the outlet when not in use or during electrical storms.

UL CERTIFIED AND LISTED



Up to UL's nationally
recognized standards for high-level electronic safety

Superer	Safety Certifications
✓	UL Listed - passed UL safety tests for high-level electronic safety.
✓	FCC approved - meets regulated limits for ionizing radiation.
✓	CE marking - meets EU safety, health and environmental protection requirements.

Image 2.1: Visual representation of UL, FCC, and CE safety certifications for the product.

The product is UL Listed, indicating it has passed UL safety tests for high-level electronic safety. It is also FCC approved, meeting regulated limits for ionizing radiation, and carries a CE marking, signifying compliance with EU safety, health, and environmental protection requirements.

3. PACKAGE CONTENTS

Verify that your package contains the following items:

- 1 x Superer 230W Power Adapter (Model ADP195118T)
- 1 x Power Cord

4. SETUP INSTRUCTIONS

1. **Inspect the Charger:** Before connecting, visually inspect the power adapter and cables for any signs of damage. Do not use if damaged.
2. **Connect the Power Cord:** Insert the power cord into the AC input port on the power adapter. Ensure a firm connection.
3. **Connect to Laptop:** Insert the charger's output connector into your Razer Blade laptop's charging port. Ensure the connector type matches your laptop's port. This charger features a specific round connector with an L-shaped tip.
4. **Connect to Power Outlet:** Plug the power cord into a standard electrical wall outlet (100-240V).

Consistent Power Supply

Provide consistent & stable power for your device.



Image 4.1: The Superer 230W power adapter providing consistent power to a laptop on a desk setup.

5. OPERATING INSTRUCTIONS

Once properly connected, the charger will automatically begin supplying power to your laptop and charging its battery. No additional user interaction is required for basic operation.

- The charger is designed to provide a consistent and stable power supply.

- Monitor your laptop's battery indicator to confirm charging status.
- For optimal battery health, avoid frequently draining the battery completely before recharging.

6. MAINTENANCE AND CARE

- **Cleaning:** Disconnect the charger from both the power outlet and your laptop before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the charger in a cool, dry place. Avoid tightly coiling the cables to prevent damage.
- **Cable Management:** Do not bend or crimp the cables sharply. This can damage internal wires and affect performance.

7. TROUBLESHOOTING

- **Charger Not Working:**
 - Ensure all connections are secure: power cord to adapter, adapter to laptop, and power cord to wall outlet.
 - Test the wall outlet with another device to confirm it is functional.
 - Verify that the charger's specifications (voltage, amperage, wattage) match your laptop's requirements.
- **Laptop Not Charging:**
 - Confirm the charging port on your laptop is clean and free of debris.
 - Check if your laptop requires more than 11.8A. This charger is rated for 11.8A.
 - Restart your laptop.
- **Overheating:**
 - Ensure the charger is placed in a well-ventilated area and not covered.
 - If overheating persists, discontinue use and contact customer support.

8. SPECIFICATIONS

Model Number	ADP195118T
Input	100-240V
Output	19.5V 11.8A 230W
Connector Type	Round Connector (L-shaped tip)
Color	Black
Item Weight	2.21 pounds
Dimensions (L x W x H)	7.8 x 3.91 x 1.02 inches (approximate)
Safety Certifications	UL Listed, FCC Approved, CE Marking

Item Dimension



Image 8.1: Physical dimensions of the Superer 230W power adapter.

9. COMPATIBILITY

This 230W charger is compatible with various Razer Blade laptop models. Please verify your laptop's power requirements and charging port type before use. The charger features a specific round connector with an L-shaped tip.

Charging Port

Check the shape of your charging port before purchase.



Image 9.1: Illustration of the correct L-shaped charging port for compatibility (green check) versus an incompatible round port (red cross).

Compatible Razer Blade Models (2014-2022) include:

- **Razer Blade 14"**: RZ09-0370, RZ09-0427
- **Razer Blade 15"**: RZ09-02385, RZ09-02386, RZ09-02705, RZ09-02886, RZ09-02887, RZ09-02888, RZ09-0313x, RZ09-0301x, RZ09-0421x, RZ09-0330x, RZ09-0367x, RZ09-0409A, RZ09-0409B, RZ09-0409C, RZ09-03009, RZ09-03006, RZ09-0328x, RZ09-0369x, RZ09-0410x, RZ09-03135, RZ09-0330Q

- **Razer Blade 17"**: RZ09-0406
- **Razer Blade Pro 17"**: RZ09-01171E1, RZ09-01171E5, RZ09-01662, RZ09-01663, RZ09-02202, RZ09-0287x, RZ09-0314x, RZ09-02876, RZ09-02877, RZ09-02878, RZ09-0329x, RZ09-0368x, RZ09-02202
- **Other Compatible Models**: Razer Blade RC30-024801, RC30-02480100 (GTX1660, GTX1060, GTX1070, RTX2070, RTX2080, 0485x)

Important: Do not use this charger if your laptop requires more than 11.8 Amps.



COMPATIBILITY

19.5V	9.23A	180W	✓
19.5V	11.8A	230W	✓
19V	13.16A	250W	✗

10. WARRANTY AND SUPPORT

Superer provides comprehensive after-sales support for this product:

- **30-Day Return Policy:** This product is eligible for replacement or returns within 30 days of purchase.
- **12-Month Guarantee:** The manufacturer provides an additional 12-month guarantee for replacement services.

For any issues, questions, or support needs, please contact Superer customer service. Refer to your purchase documentation for contact details.

Positive Customer Support

Refund Within 30 Days of Purchase
and Replace Service Within 12 Months



12

Replace Service Within 12 Months

Worry-free after sales



**Replace Service
Within 12 Months**



**Refund Within
30 Days of Purchase**



**Quick feedback
to any problems**

Image 10.1: Overview of Superer's customer support policies, including 12-month replacement and 30-day refund.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BXJJWLP8>

More documents and user manuals: <https://manuals.plus/>