

[Manuals.plus](#) /

› [Xtrike Me](#) /

› Xtrike Me GK986P 80% Wired Mechanical Gaming Keyboard User Manual

Xtrike Me GK986P

Xtrike Me GK986P 80% Wired Mechanical Gaming Keyboard User Manual

Model: GK986P | Brand: Xtrike Me

INTRODUCTION

Thank you for choosing the Xtrike Me GK986P 80% Wired Mechanical Gaming Keyboard. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your new keyboard. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.



Image: Top-down view of the Xtrike Me GK986P mechanical gaming keyboard, showcasing its 80% layout and vibrant rainbow LED backlighting.

SETUP

Follow these steps to set up your Xtrike Me GK986P keyboard:

1. **Unpack the Keyboard:** Carefully remove the keyboard and any included accessories from the packaging.
2. **Connect to Computer:** Locate the USB cable attached to the keyboard. Plug the USB connector into an available USB 2.0 port on your computer or laptop.
3. **Driver Installation:** The keyboard is plug-and-play. Your operating system (Windows XP or newer) should automatically detect and install the necessary drivers. No additional software installation is typically required.
4. **Test Functionality:** Open a text editor or any application to test the key responsiveness. Ensure all keys are functioning correctly.

OPERATING INSTRUCTIONS

Basic Functions

The GK986P keyboard features a standard 80% layout with 87 keys.

- **Standard Typing:** Use the alphanumeric keys for regular text input.
- **Function Keys (F1-F12):** These keys perform their standard functions. Some may have secondary multimedia functions when pressed in combination with the **Fn** key.
- **Arrow Keys:** Located on the bottom right, these keys control cursor movement.
- **Navigation Keys:** Keys like Insert, Home, Page Up, Delete, End, Page Down are available for navigation.

Backlight Modes

The keyboard features a rainbow LED backlight with multiple lighting effects.

- **Changing Modes:** Use the **Fn** key in combination with specific keys (usually F-keys or dedicated lighting keys) to cycle through different backlight modes. Refer to the keyboard's keycap legends for specific combinations.
- **Adjusting Brightness:** Typically, **Fn + Up Arrow** increases brightness, and **Fn + Down Arrow** decreases brightness.
- **Adjusting Speed:** For dynamic lighting modes, **Fn + Left Arrow** or **Fn + Right Arrow** might adjust the effect speed.



Image: Close-up view of the Xtrike Me GK986P keyboard, highlighting the illuminated PBT keycaps and blue mechanical switches.

Multimedia Keys

The keyboard may feature multimedia shortcuts accessible via the **Fn** key combined with certain F-keys. Common functions include:

- **Fn + F1-F12:** (Specific functions vary by model, typically include media playback controls, volume adjustment, and application shortcuts). Refer to the keycap legends for exact functions.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your keyboard.

- **Cleaning:**
 - Disconnect the keyboard from your computer before cleaning.
 - Use a can of compressed air to remove dust and debris from between the keycaps.
 - Wipe the keycaps and keyboard surface with a soft, slightly damp, lint-free cloth. Avoid excessive moisture.
 - Do not use harsh chemicals, abrasive cleaners, or solvents.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the keyboard or exposing it to liquids. The keyboard is not water-resistant.

TROUBLESHOOTING

If you encounter issues with your keyboard, refer to the following common solutions:

- **Keyboard Not Responding:**
 - Ensure the USB cable is securely connected to both the keyboard and the computer.
 - Try plugging the keyboard into a different USB port on your computer.
 - Restart your computer.
 - Test the keyboard on another computer to determine if the issue is with the keyboard or your system.
- **Keys Not Registering:**
 - Check for any physical obstructions under the keycap.
 - Clean the area around the affected key with compressed air.
- **Backlight Not Working or Incorrect:**
 - Ensure the backlight is not turned off (check brightness settings using Fn + Arrow keys).
 - Cycle through different backlight modes to see if other modes function.

If the problem persists after trying these steps, please contact Xtrike Me customer support for further assistance.

SPECIFICATIONS

Model:	GK986P
Brand:	Xtrike Me
Keyboard Type:	Mechanical Gaming Keyboard
Layout:	80% (87 Keys)
Switch Type:	Blue Mechanical Switches (Clicky)
Switch Lifespan:	≥50 million keystrokes
Key Travel:	4.0 ± 0.5 mm
Operating Force:	60 ± 10 grams
Key Rollover:	25-key rollover support
Keycaps:	PBT Pudding Keycaps (English Only)
Backlight:	Rainbow LED with multiple modes
Interface:	USB 2.0
Connectivity:	Wired
Cable Length:	5 feet (approximately 1.5 meters)
OS Support:	Windows XP or newer
Material:	Plastic
Color:	Black
UPC:	990148209390
ASIN:	B0BXJNRMPB

WARRANTY AND SUPPORT

The Xtrike Me GK986P keyboard comes with a **30-day warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or external factors. For warranty claims or technical support, please contact your retailer or Xtrike Me customer service with your proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question