

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tokluck](#) /

› [Tokluck PS5/Slim/Pro Wall Mount Kit with Cooling Fan & Charging Station Instruction Manual](#)

Tokluck VG-P5326X-Pro

Tokluck PS5/Slim/Pro Wall Mount Kit with Cooling Fan & Charging Station Instruction Manual

Model: VG-P5326X-Pro


INTRODUCTION

This instruction manual provides comprehensive guidance for the installation, operation, and maintenance of your Tokluck PS5/Slim/Pro Wall Mount Kit. This versatile accessory is designed to securely mount all PlayStation 5 console models (Original, Slim, Pro, Disc, and Digital editions) while offering an integrated cooling system, dual controller charging, and a convenient headset holder. Please read these instructions carefully before installation and use to ensure optimal performance and safety.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x PS5 Wall Mount with Cooling Stand
- 1 x Paper with Mark Holes and Level (for installation)
- 1 x Console Fixing Screw
- 7 x Expansion Screws
- 1 x Storage Case
- 1 x Headset Hook



Package Included

- 1 x PS5 Wall Mount with Cooling Stand
- 1 x Paper with Mark Holes and Level
- 1 x Console Fixing Screw
- 7 x Expansion Screw
- 1 x Storage Case
- 1 x Headset Hook



Image: Detailed view of all components included in the Tokluck PS5 Wall Mount Kit package.

SETUP AND INSTALLATION


Follow these steps to properly install your wall mount kit:

1. Prepare the Wall

1. Select a suitable location on your wall, ensuring it is sturdy enough to support the weight of the PS5 console and the mount.
2. Use the provided paper template with marked holes and a level to accurately determine the mounting position. Mark the drill points on the wall.
3. Drill holes at each marked point. Ensure the drill bit size is appropriate for the expansion screws.
4. Insert the expansion screws into the drilled holes.


Easy to Assemble And Hang

1



Use the paper to decide mounting position

2



Drill the holes at each marked hole (Drill not included)

3



Attach the product to the wall with expansion screws

4



Secure the All PS5 console with screw

Image: Visual guide for marking drill points and attaching the wall mount to the wall.

2. Mount the Bracket and Console

5. Attach the wall mount bracket to the wall using the expansion screws. Tighten securely.
6. Remove the bottom screw cap from your PS5 console (for both Disc & Digital editions).
7. Carefully place your PS5 console onto the mounted bracket, ensuring it aligns correctly.
8. Secure the PS5 console to the bracket using the provided console fixing screw at the bottom.

Non-detachable & Integrated Design



COMPATIBLE WITH ALL PS5 CONSOLE



PS5 Slim Disc & Digital

PS5 Pro Disc & Digital

PS5 Disc & Digital

Image: The wall mount securely holding a PS5 console, demonstrating compatibility with all PS5 models.

Your browser does not support the video tag.

Video: A step-by-step guide demonstrating the installation process of the PS5 wall mount, including drilling, securing the bracket, and attaching the console.

3. Connect Charging Station and Headset Hook

9. Hang the charging station onto the designated hooks on the wall mount.
10. Connect the PS5 console to the charging station using the provided Type-C to Type-C cable.
11. Attach the headset hook to the top of the PS5 console.

Charging & Cooling in Standby Mode



Image: The fully assembled wall mount with the PS5 console, dual controllers charging, and a headset hanging on the hook.

OPERATING INSTRUCTIONS

1. Controller Charging

- The charging station is compatible with both DualSense and DualSense Edge controllers.
- Place your controllers onto the charging ports.
- Charging time is approximately 2.5 hours for a full charge.
- **LED Indicators:**
 - Orange Light: Controller is currently charging.
 - Blue Light: Controller is fully charged or in standby.

Sturdier and Ventilation Design



Humanized design



All-around heat dissipation



No looseness & movement



Avoid missing accessories



Image: Close-up of the charging station with controllers, illustrating the LED indicators for charging status.

Your browser does not support the video tag.

Video: Demonstrates placing DualSense and DualSense Edge controllers onto the charging station and observing the charging indicator lights.

2. Cooling Fan Operation

- The mount features two silent cooling fans with 3 adjustable speed settings (High, Medium, Low).
- Use the touch switch on the front of the charging station to cycle through fan speeds or turn them off.
- The cooling system helps dissipate heat from your PS5 console, extending its lifespan.

Adjustable Three Gear Powerful Cooling System

Two silent fans in the bottom can dissipate excess heat



Image: Illustration of the cooling fan system with airflow direction and the 3-gear speed adjustment options.


3. Standby Mode Charging and Cooling

To enable charging and cooling functions while your PS5 is in Rest Mode, adjust the console settings:

1. Go to **"Settings"** on your PS5.
2. Select **"System"**.
3. Choose **"Power Saving"**.
4. Navigate to **"Features Available in Rest Mode"**.
5. For **"Supply Power to USB Ports"**, select **"Always"**.


Easy to Assemble And Hang

1



Use the paper to decide mounting position

2



Drill the holes at each marked hole (Drill not included)

3



Attach the product to the wall with expansion screws

4



Grooves for PS5 Slim/Pro



Grooves for PS5 Original(2020)

Secure the All PS5 console with screw

Image: Flowchart illustrating the PS5 console settings required to enable power supply to USB ports in Rest Mode for continuous charging and cooling.

MAINTENANCE

- Regularly clean the surface of the wall mount and charging station with a soft, dry cloth to prevent dust buildup.
- Ensure the cooling fan vents are free from obstructions to maintain effective airflow.
- Avoid using abrasive cleaners or solvents, as these may damage the product's finish.

TROUBLESHOOTING

- **Controllers not charging:**

- Ensure the Type-C cable is securely connected between the PS5 console and the charging station.
- Verify that the "Supply Power to USB Ports" setting in your PS5 is set to "Always" (refer to Standby Mode section).
- Check if the controllers are properly seated on the charging contacts.

- **Cooling fan not working or noisy:**

- Confirm the PS5 is powered on or in Rest Mode with USB power enabled.
- Press the fan speed touch switch to ensure it's not turned off.
- Check for any obstructions in the fan vents.
- If unusual noise persists, ensure the console is securely mounted and not vibrating against the wall.

- **Mount feels unstable:**

- Re-check all wall screws and the console fixing screw for tightness.
- Ensure the wall material is appropriate for mounting and that expansion screws are correctly installed.

SPECIFICATIONS

Feature	Detail
Model Number	VG-P5326X-Pro
Product Dimensions	8.86 x 7.28 x 3.35 inches
Item Weight	1.65 pounds
Material	High-quality stainless steel
Compatibility	PS5 Original (Disc & Digital), PS5 Slim (Disc & Digital), PS5 Pro (Disc & Digital)
Controller Charging	DualSense & DualSense Edge (approx. 2.5 hours for full charge)
Cooling System	2 silent fans with 3-gear speed adjustment (High, Medium, Low)
Additional Ports	USB port for other devices

WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your Tokluck PS5 Wall Mount Kit, please refer to the official Tokluck website or contact their customer service directly. Keep your purchase receipt for warranty claims.

