

Manuals.plus /
› Fastrack /
› Fastrack Tick Tock Quartz Multifunction Watch NT3287SM01 User Manual

Fastrack NT3287SM01

Fastrack Tick Tock Quartz Multifunction Watch NT3287SM01
User Manual

Model: NT3287SM01 | Brand: Fastrack

1. PRODUCT OVERVIEW AND FEATURES

The Fastrack Tick Tock Quartz Multifunction Watch NT3287SM01 is designed for individuals seeking a blend of style and functionality. This timepiece offers precise quartz movement and multiple subdials for enhanced timekeeping.

- **Master Time in Every Mode:** Dedicated subdials provide instant access to 24-hour time, the day, and the date.
- **Harmonious Silver Metal Flow:** The silver metal strap creates a cohesive and confident look.
- **Organized at a Glance:** This watch provides all essential timekeeping information clearly and efficiently.
- **Two Toned Dial:** A sleek white central section framed by a metallic silver ring.
- **Your Daily Navigator:** This timepiece is designed to keep you informed and on track, every moment of the day and week.

2. PRODUCT COMPONENTS



Front view of the Fastrack Tick Tock Quartz Multifunction Watch NT3287SM01, showcasing the white dial and silver metal strap.



Side view of the Fastrack Tick Tock Quartz Multifunction Watch NT3287SM01, highlighting the crown and pushers.



Rear view of the Fastrack Tick Tock Quartz Multifunction Watch NT3287SM01, showing the stainless steel back and water resistance marking.



Angled view of the Fastrack Tick Tock Quartz Multifunction Watch NT3287SM01, displaying the dial and strap.

3. SETUP AND FIRST USE

3.1 Adjusting the Time

1. Pull the crown (the knob on the side of the watch) out to the first or second click position (depending on the model, usually the outermost position).
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Push the crown back into its normal position to start the watch.

3.2 Adjusting the Date and Day

1. Pull the crown out to the first click position.

- 2. Turn the crown to adjust the date and day subdials. Refer to the specific subdial markings for day and date.
- 3. Once set, push the crown back into its normal position.

3.3 Strap Adjustment

The metal strap on your Fastrack watch can be adjusted for a comfortable fit. It is recommended to have this adjustment performed by a professional watchmaker or an authorized Fastrack service center to prevent damage to the strap or clasp.

Video: A quick guide to understanding watch dial size and wrist measurement for optimal fit.

4. OPERATING INSTRUCTIONS

4.1 Multifunction Subdials

- **24-Hour Subdial:** This subdial displays time in a 24-hour format, useful for distinguishing AM/PM.
- **Day Subdial:** Indicates the current day of the week.
- **Date Subdial:** Shows the current date of the month.

These subdials are synchronized with the main time setting. Adjustments are made via the crown as described in the 'Setup and First Use' section.

Video: An overview of the Fastrack Tick Tock 2.0 watch features and design.

5. MAINTENANCE

5.1 Cleaning Your Watch

- Wipe the watch case and metal strap with a soft, dry cloth regularly to remove dust and dirt.
- For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- Avoid using harsh chemicals, solvents, or abrasive cleaners as they can damage the watch's finish.

5.2 Water Resistance

This watch is rated for 50 meters (5 ATM) water resistance. This means it is suitable for short periods of recreational swimming, but not for diving or snorkeling. Avoid operating the crown or pushers when the watch is wet or submerged.

5.3 Battery Replacement

The watch is powered by a Lithium Polymer battery. When the watch stops or its functions become erratic, it may be time for a battery replacement. It is highly recommended to have the battery replaced by an authorized service center to ensure proper sealing and maintain water resistance.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not running	Depleted battery	Replace battery at an authorized service center.
Incorrect time/date	Time/date not set correctly or crown is pulled out.	Refer to 'Setup and First Use' to reset time/date. Ensure crown is pushed in completely.

Problem	Possible Cause	Solution
Condensation inside watch	Exposure to extreme temperature changes or compromised water resistance.	Contact an authorized service center immediately.

7. SPECIFICATIONS

- **Brand:** Fastrack
- **Model Name:** Tick Tock
- **Item Model Number:** Casual Watch (NT3287SM01)
- **Display Type:** Analog
- **Power Source:** Battery Powered (1 Lithium Polymer battery included)
- **Special Features:** Second Hand, Multifunction (24-hour, Day, Date subdials)
- **Water Resistance:** 50 Meters (5 ATM)
- **Case Diameter:** 49.7 mm
- **Product Dimensions:** 14 x 7 x 10 cm
- **Item Weight:** 200 g
- **Country of Origin:** India
- **Manufacturer:** Titan Company Limited, Sipcot Industrial Complex, Hosur, Tamil Nadu - 635129

8. WARRANTY AND SUPPORT

Your Fastrack Tick Tock Quartz Multifunction Watch NT3287SM01 comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Fastrack website.

An optional 1-year extended warranty plan by Onsitego may be available for purchase, offering additional coverage.

For service, repairs, or any product-related inquiries, please contact an authorized Fastrack service center or the manufacturer directly:

Titan Company Limited
Sipcot Industrial Complex, Hosur, Tamil Nadu - 635129, India

9. IMPORTANT SAFETY INFORMATION

- Keep the watch away from strong magnetic fields, as this can affect the accuracy of the quartz movement.
- Avoid exposing the watch to extreme temperatures (hot or cold) for prolonged periods.
- Do not attempt to open the watch case or perform repairs yourself, as this will void the warranty and may damage the watch.
- Clean the watch regularly to prevent accumulation of dirt and sweat, which can cause skin irritation or damage to the watch.
- Ensure the crown is always pushed in completely to maintain water resistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BXKV3MFH>

More documents and user manuals: <https://manuals.plus/>