

Fastrack NT3287NL01

Fastrack Tick Tock Quartz Multifunction Watch NT3287NL01 User Manual

Model: NT3287NL01

1. INTRODUCTION

Thank you for choosing the Fastrack Tick Tock Quartz Multifunction Watch, model NT3287NL01. This manual provides essential information for the proper setup, operation, and maintenance of your watch. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece.



Image 1.1: Front view of the Fastrack Tick Tock Quartz Multifunction Watch NT3287NL01, featuring a black dial and brown leather strap.

2. PRODUCT OVERVIEW

The Fastrack Tick Tock Quartz Multifunction Watch is designed with a classic aesthetic and practical features. It includes subdials for day, date, and a 24-hour display, all housed within a durable black case and complemented by a comfortable brown leather strap.

2.1 Components

- **Crown:** Used for setting the time and date.
- **Pushers:** Buttons located on the side of the case, used to adjust multifunction subdials.
- **Main Dial:** Displays hours, minutes, and seconds.
- **Day Subdial:** Indicates the current day of the week.
- **Date Subdial:** Displays the current date.
- **24-Hour Subdial:** Provides an alternative timekeeping view in a 24-hour format.

- **Leather Strap:** Brown leather strap for comfortable wear.



Image 2.1: Side view of the watch, highlighting the crown and pushers for adjustments.



Image 2.2: Back view of the watch, showing the stainless steel case back and water resistance marking.

3. SETUP AND ADJUSTMENT

3.1 Setting the Time

1. Pull the crown out to the second click position.
2. Rotate the crown to move the hour and minute hands to the desired time.
3. Push the crown back into the normal position to start the watch.

3.2 Setting the Date and Day

1. Pull the crown out to the first click position.
2. Rotate the crown to adjust the date and day subdials.
3. Push the crown back into the normal position.

Note: Avoid setting the date and day between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.

3.3 Wrist Measurement Guide

To ensure a comfortable fit, measure your wrist size. Use a measuring tape and keep it slightly loose around your wrist where you intend to wear the watch.

Your browser does not support the video tag.

Video 3.1: A quick guide demonstrating how to measure your wrist for proper watch sizing and a dial size comparison.

4. OPERATING INSTRUCTIONS

4.1 Using Multifunction Dials

- The **Day Subdial** automatically advances with the main time.
- The **Date Subdial** automatically advances with the main time.
- The **24-Hour Subdial** synchronizes with the main time display, showing whether it is AM or PM in a 24-hour format.

4.2 Water Resistance

This watch has a water resistance depth of 50 meters (5 ATM). This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. It is **not** suitable for swimming, diving, or showering with hot water.

- Do not operate the crown or pushers when the watch is wet or submerged in water.
- Ensure the crown is fully pushed in before any contact with water.

5. MAINTENANCE

5.1 Cleaning

To maintain the appearance of your watch:

- Wipe the case and crystal with a soft, dry cloth.
- For the leather strap, avoid prolonged exposure to water, direct sunlight, and harsh chemicals. Clean with a damp cloth and allow to air dry.

5.2 Battery Replacement

The watch is powered by a quartz movement and requires a battery. When the watch stops or runs erratically, the battery may need replacement. It is recommended to have the battery replaced by an authorized service center to ensure proper sealing and maintain water resistance.

6. TROUBLESHOOTING

6.1 Watch Not Running

- Check if the crown is fully pushed in.
- The battery may be depleted. Refer to Section 5.2 for battery replacement.

6.2 Incorrect Time/Date

- Refer to Section 3.1 and 3.2 for instructions on setting the time, date, and day.

If issues persist, please contact customer support or an authorized service center.

7. SPECIFICATIONS

Feature	Specification
Model Number	NT3287NL01
Display Type	Analog
Movement Type	Quartz
Water Resistance Depth	50 Metres (5 ATM)
Band Material	Leather
Case Material	Metal
Crystal Material	Mineral Glass
Case Diameter	43 Millimetres
Band Width	20 Millimetres
Case Thickness	10 Millimetres
Band Length	24 Centimetres
Dial Colour	Black
Band Colour	Brown
Weight	200 Grams
Country of Origin	India

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Your Fastrack Tick Tock Quartz Multifunction Watch comes with a **12-month manufacturer warranty** on manufacturing defects. To avail warranty services, please present your original invoice at any authorized Titan Service Center.

Note: A physical warranty card is not required; the invoice serves as proof of purchase for warranty claims.

8.2 Customer Support

For further details or service-related queries, you may contact Titan India customer support:

- **Toll-Free Number:** 1800-266-0123 (Available 10 AM to 7 PM, all days of the week)
- **Email:** customercare@titan.co.in

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question