

PARTPHONER ZYTFL

PARTPHONER ZYTFL Floor Lamp User Manual

Model: ZYTFL

1. INTRODUCTION

Thank you for purchasing the PARTPHONER ZYTFL Floor Lamp. This minimalist standing lamp is designed to provide ambient lighting for various indoor spaces such as living rooms, bedrooms, and offices. It features an E26 bulb socket and a convenient foot switch for easy operation. Please read this manual thoroughly before assembly and use to ensure proper installation and safe operation.

2. SAFETY INFORMATION

- Ensure the power is disconnected before assembly, installation, or maintenance.
- This lamp is designed for indoor use only. Do not expose it to water or high humidity.
- Use only E26 base bulbs. Do not exceed the maximum wattage of 60 watts.
- Keep the lamp away from flammable materials.
- Do not attempt to modify or repair the lamp yourself. Contact qualified personnel for service.
- Ensure all connections are secure before plugging in the lamp.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Lamp Pole Sections (multiple)
- Lamp Base
- Lampshade (fabric)
- Socket Ring
- Power Cable with Foot Switch
- User Manual

*Note: An E26 light bulb is **not included** and must be purchased separately.*

4. ASSEMBLY INSTRUCTIONS

Assembly of the PARTPHONER ZYTFL Floor Lamp is designed to be quick and tool-free. Follow these steps:



Image: Key components of the PARTPHONER ZYTFL Floor Lamp, highlighting the fabric shade, metal pole, foot switch, and sturdy base.

1. **Step 1: Assemble the Lamp Pole.** Screw all the metal pole sections together firmly from top to bottom. Ensure each section is tightly connected.
2. **Step 2: Attach Pole to Base.** Insert the assembled pole into the lamp base and screw it clockwise until secure.
3. **Step 3: Prepare the Lampshade.** Unroll the fabric lampshade. If it comes flat, attach it to the top and bottom rings using the provided clips or Velcro, forming a cylinder.
4. **Step 4: Install the Bulb Socket Ring.** Unscrew the socket ring from the lamp holder located at the top of the assembled pole.
5. **Step 5: Secure the Lampshade.** Place the lampshade onto the lamp holder, ensuring it rests securely. Then, screw the socket ring back onto the lamp holder to fix the lampshade in place.
6. **Step 6: Insert the Light Bulb.** Carefully screw an E26 base light bulb (not included) into the lamp socket. Do not overtighten.



Image: Visual guide for the six-step assembly process of the PARTPHONER ZYTFL Floor Lamp.

5. OPERATING INSTRUCTIONS

The PARTPHONER ZYTFL Floor Lamp is designed for simple operation.

3 Color Temperature Floor Lamp (Bulb Not Included)



Image: The floor lamp showcasing different lighting effects with 2700K, 4000K, and 5000K bulbs (bulb not included).

- **Power On/Off:** Plug the lamp into a standard electrical outlet. Use the integrated foot switch on the power cord to

turn the lamp on or off. Press the switch with your foot to toggle the power.

- **Bulb Compatibility:** This lamp uses an E26 base bulb (not included). For adjustable lighting, consider using a compatible 3-color temperature bulb (e.g., ASIN: B0BZD75BM4) to switch between warm white (2700K), neutral white (4000K), and cool white (5000K) light.
- **Wall Switch Compatibility:** The lamp is compatible with wall switches. Ensure the foot switch is in the 'ON' position if you intend to control the lamp via a wall switch.

Color tones vary with bulb temperature




Image: Visual representation of how color tones vary with different bulb temperatures (2700K, 4000K, 5000K) when the lamp is on, compared to when it is off.

6. MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Wipe the metal parts with a soft, dry cloth. The fabric lampshade can be gently dusted or spot cleaned with a damp cloth if necessary. Avoid using harsh chemicals or abrasive cleaners.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled down before attempting to replace it.

Unscrew the old bulb and screw in a new E26 base bulb, not exceeding 60 watts.

- **Inspection:** Periodically check the power cord and plug for any signs of damage. If damage is found, discontinue use and contact customer support.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on	• Lamp not plugged in • Foot switch is off • Bulb is loose or burnt out • Power outlet is not working	• Ensure the lamp is securely plugged into a working outlet. • Press the foot switch to the 'ON' position. • Tighten or replace the light bulb. • Test the outlet with another device.
Light flickers	• Loose bulb connection • Incompatible bulb • Faulty bulb	• Tighten the light bulb. • Ensure the bulb is E26 base and within wattage limits. • Replace the bulb with a new one.
Lampshade is wobbly	• Socket ring is loose • Lampshade not properly seated	• Tighten the socket ring securely. • Re-seat the lampshade on the lamp holder.

8. SPECIFICATIONS

- **Brand:** PARTPHONER
- **Model:** ZYTFL
- **Product Dimensions:** 8.66"D x 8.66"W x 61.5"H (22cm D x 22cm W x 156.2cm H)
- **Item Weight:** 5.5 pounds (2.5 kg)
- **Material:** Metal (Base, Pole), Linen (Shade)
- **Finish Type:** Polished
- **Bulb Base:** E26
- **Max Wattage:** 60 watts
- **Power Source:** Corded Electric
- **Voltage:** 120 Volts (AC)
- **Switch Type:** Foot Switch
- **Indoor/Outdoor Usage:** Indoor
- **Special Feature:** Energy Efficient (with compatible bulb)



Image: Detailed dimensions of the PARTPHONER ZYTFL Floor Lamp.

9. WARRANTY AND SUPPORT

PARTPHONER products are manufactured to high-quality standards. For any questions, concerns, or issues regarding your PARTPHONER ZYTFL Floor Lamp, please contact the seller or PARTPHONER customer support. Please retain your proof of purchase for warranty claims.

© 2023 PARTPHONER. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question