

## UMUTOO MI03

# UMUTOO MI03 FM Radio User Manual

Model: MI03

## 1. PRODUCT OVERVIEW

---

The UMUTOO MI03 is a compact, portable FM radio designed for personal listening. It features digital tuning, an LCD display with backlight, and a built-in rechargeable battery. The radio is equipped with a belt clip for convenient carrying.



Front and side view of the UMUTOO MI03 FM Radio, showing the digital display, control buttons, attached earphones, and the integrated belt clip.

### Package Contents:

- UMUTOO MI03 FM Radio
- 3.5mm Stereo Earphones
- USB-C Charging Cable
- User Manual



Image displaying the items included in the product package: the MI03 FM radio, 3.5mm earphones, a USB-C charging cable, and the user manual.

## 2. SETUP

### 2.1 Charging the Battery

The MI03 radio includes a built-in rechargeable lithium-ion battery. Before first use, fully charge the device.

1. Connect the provided USB-C charging cable to the radio's charging port.
2. Connect the other end of the cable to a standard USB power adapter (not included) or a computer's USB port.
3. The charging indicator on the display will show the charging status. A full charge typically provides up to 14 hours of playback.



The MI03 FM Radio connected to a USB-C charging cable, indicating the charging port location.

### 2.2 Connecting Earphones

The 3.5mm wired earphones included with the radio serve as the FM antenna. They must be connected for proper FM reception.

1. Insert the 3.5mm jack of the earphones into the earphone port on the radio.
2. Ensure the earphones are securely connected.

# Enjoy FM Programs with No Interruption

Plug in  $\Phi 3.5\text{mm}$  headphones to play the radio, headphone cable is the FM receiving antenna.



Close-up of the MI03 FM Radio with 3.5mm wired earphones plugged in. The earphone cable functions as the FM antenna.

## 3. OPERATION

### 3.1 Power On/Off

- To power on the radio, press and hold the Power button (usually indicated by a power symbol or integrated with another button).
- To power off, press and hold the Power button again.

### 3.2 Automatic Station Search and Storage

The radio can automatically scan and store available FM stations.

1. Ensure earphones are connected.
2. Press the 'Search' button (often indicated by a magnifying glass icon). The radio will scan for stations and save them to memory.
3. Use the 'Up' and 'Down' arrow buttons to navigate through the stored stations.

### 3.3 Volume Adjustment

Adjust the listening volume using the dedicated volume buttons.

- Press the '+' button to increase volume.
- Press the '-' button to decrease volume.

### 3.4 LCD Backlight

The LCD screen features a soft backlight for improved visibility in various lighting conditions.

- The backlight typically activates automatically when a button is pressed and turns off after a short period of inactivity to conserve battery.



Comparison showing the radio's LCD screen with its soft backlight activated for visibility in low light conditions, and without the backlight.

### 3.5 Using the Belt Clip

The integrated belt clip allows for hands-free portability.

- Attach the radio securely to clothing, a belt, or a bag strap using the clip.

# Equipped with back clip

easy for you to handheld  
or clip on your clothes, handbags...



The MI03 FM Radio attached to a jacket pocket using its integrated belt clip, demonstrating its portability.

## 4. MAINTENANCE

---

### 4.1 Cleaning

- Wipe the radio with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- Avoid exposing the device to excessive dust or dirt.

### 4.2 Battery Care

- Charge the battery regularly, even if the radio is not used frequently, to maintain battery health.
- Avoid fully discharging the battery repeatedly.
- Do not expose the radio to extreme temperatures, as this can affect battery performance and lifespan.

### 4.3 Storage

- Store the radio in a cool, dry place away from direct sunlight and moisture.

## 5. TROUBLESHOOTING

If you encounter issues with your UMUTOO MI03 FM Radio, refer to the following common problems and solutions:

| <b>Problem</b>                        | <b>Possible Cause</b>   | <b>Solution</b>   |
|---------------------------------------|---|---|
| Radio does not power on.              | Battery is depleted.  | Charge the radio using the provided USB-C cable.  |
| Poor FM reception or static.          | Earphones not connected or not fully extended; weak signal area.  | Ensure earphones are fully plugged in and their cable is extended. Move to an area with stronger FM signal. |
| No sound from earphones.              | Volume too low; earphones faulty; earphones not fully plugged in. | Increase volume. Check earphone connection. Test with another pair of 3.5mm earphones if available.         |
| Volume is too loud at lowest setting. | Device characteristic.  | Adjust volume carefully. Consider using earphones with their own volume control if available.               |
| Difficulty tuning to stations.        | Weak signal; interference.  | Perform an automatic station search in a location with better reception.                                    |

## 6. SPECIFICATIONS

# Incredible Small Size



Image illustrating the compact size of the MI03 FM Radio, with dimensions of approximately 3.35 inches in length, 1.10 inches in width, and 0.75 inches in height.

| Feature                 | Detail  |
|-------------------------|---|
| Model Number            | MI03  |
| Product Dimensions      | 3.37 x 1.12 x 0.59 inches (8.56 x 2.84 x 1.5 cm)                                |
| Item Weight             | 2.89 ounces (81.9 g)  |
| Tuner Technology        | FM (76-108 MHz)   |
| Power Source            | Rechargeable Lithium-ion Battery (300mAh)                                       |
| Connectivity Technology | USB-C for charging  |
| Special Features        | Portable, Rechargeable, Mini size, Back clip, LCD Digital Tuning with Backlight |
| Included Components     | 3.5mm earphones, Charging cable, User manual                                    |

## **7. WARRANTY AND SUPPORT**

---

### **7.1 Warranty Information**

The UMUTOO MI03 FM Radio comes with a 12-month warranty from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use. It does not cover damage caused by misuse, accidents, or unauthorized modifications.

### **7.2 Customer Support**

For technical assistance, warranty claims, or any questions regarding your UMUTOO MI03 FM Radio, please contact our customer service team. Support is available 24/7.

Please refer to the contact information provided on the product packaging or the official UMUTOO website for the most current support details.