

[Manuals.plus](#) /

› [PKBD](#) /

› PKBD Portable Blender User Manual

PKBD PKBD Portable Blender

PKBD Portable Blender User Manual

MODEL: B0BXLFCW31

Product Overview

The PKBD Portable Blender is a compact and versatile personal juicer designed for convenience and efficiency. Featuring 8 stainless steel blades and a powerful motor, it can crush ice and blend ingredients for shakes, smoothies, and more in as little as 15-40 seconds. Its 12 oz capacity and USB rechargeable design make it ideal for use at home, in the office, or on the go. The blender incorporates smart safety features and is constructed from eco-friendly, non-toxic materials.

What's Included

- PKBD Portable Blender (12 oz cup with motor base)
- USB Charging Cable
- Power Adapter
- Reusable Straw
- Cleaning Brush



Figure 1: All components included with your PKBD Portable Blender.

Setup

1. **Unpack:** Carefully remove all components from the packaging. Inspect for any damage.
2. **Initial Charge:** Before first use, fully charge the blender. Connect the USB charging cable to the blender's charging port (protected by a silicone cap) and the power adapter. Plug the adapter into a wall outlet. A full charge takes approximately 4 hours and allows for up to 12 blending cycles.
3. **Assemble:** Ensure the motor base is securely twisted onto the blender cup. The blender features an intelligent lock protection system; it will only operate when the lid and cup are assembled tightly and correctly. A blue light indicates proper assembly and readiness for operation.



Figure 2: Unboxing the PKBD Portable Blender and its accessories.



The juicer will work after the lid be tightened.
(the instruction light turning blue)



Intelligent Lock Protection



Figure 3: Intelligent Lock Protection ensures safe operation when the cup is properly secured.

Type-C 4hrs Fully Charged



Laptop



Power Bank



Car Charger



Charging Plug



Figure 4: Charging the PKBD Portable Blender using the provided USB cable and adapter.

Your browser does not support the video tag.

Video 1: This video demonstrates the unboxing, assembly, and initial use of the PKBD Portable Blender, including adding ingredients and starting the blending process.

Operating Instructions


1. **Prepare Ingredients:** Cut fruits and vegetables into small pieces (approximately 1 inch or 2.5 cm). For ice, use cubes no larger than 2.5 x 2.5 x 2.5 cm.
2. **Add Ingredients:** Place your prepared ingredients into the blender cup. Do not exceed the maximum fill line indicated on the cup.
3. **Add Liquid:** Pour milk, water, or other liquids into the cup. Ensure there is enough liquid to cover the blades and allow for smooth blending.
4. **Secure Lid:** Twist the motor base onto the cup firmly until the blue indicator light illuminates, confirming the safety lock is engaged.
5. **Start Blending:** Invert the blender (turn it upside down) to ensure ingredients are near the blades. Press the power

button twice quickly to start the blending cycle. The blender will run for approximately 15-40 seconds, depending on the ingredients.

6. **Shake (Optional):** During blending, you may gently shake the blender to ensure all ingredients are thoroughly mixed.
7. **Stop Blending:** The blender will automatically stop after a cycle. To stop manually, press the power button once.
8. **Enjoy:** Unscrew the motor base from the cup. You can drink directly from the cup, use the provided straw, or pour the contents into another container.

8 Sharp blades

More powerful & faster to make juice or smoothies than 4 knives juicer



8-Edge
Sharp Blade



Figure 5: The 8-blade design ensures efficient blending and ice crushing.

Handle Design



Easy to hold and pour

Figure 6: The integrated handle design allows for easy holding and pouring.



Office



Outdoor



Home



Gym

Figure 7: The portable design makes the blender suitable for various environments.

Cleaning and Maintenance

- **Immediate Cleaning:** After each use, rinse the cup and blades immediately to prevent food residue from drying.
- **Deep Cleaning:** For thorough cleaning, add a small amount of water and a drop of dish soap to the cup. Secure the motor base and run a short blending cycle (5-10 seconds). Rinse thoroughly.
- **Cleaning Brush:** Use the provided cleaning brush to clean around the blades and hard-to-reach areas.
- **Motor Base:** Wipe the motor base with a damp cloth. Do not submerge the motor base in water.
- **Storage:** Store the blender in a clean, dry place with the lid slightly ajar to allow for air circulation.

Troubleshooting

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Blender does not start (red light)	Lid or cup not securely attached.	Ensure the motor base is twisted tightly onto the cup until the blue indicator light appears.
Blender does not start (no light)	Low battery.	Charge the blender for at least 4 hours using the provided adapter and USB cable.
Blades stop during blending	Overloaded with ingredients or large, hard pieces.	Reduce the amount of ingredients. Cut hard ingredients (like ice) into smaller pieces. Add more liquid if necessary. Restart the blending cycle.
Leaking from the cup	Lid not properly sealed or overfilled.	Ensure the motor base is tightly secured. Do not fill ingredients above the maximum fill line.

Specifications

Feature	Detail
Brand	PKBD
Model Number	B0BXLFCW31
Color	Green
Special Feature	Portable, USB Rechargeable
Capacity	12 ounces
Power Source	Battery Powered
Number of Blades	8 (304 Stainless Steel)
Voltage	7.4 Volts
Controls Type	Push Button
Material Type Free	Non-toxic, BPA-free
Product Dimensions	4.92 x 4.92 x 8.58 inches
Item Weight	1.63 pounds

Warranty and Support

For any issues or questions regarding your PKBD Portable Blender, please contact our customer support. We are available 24 hours online to assist you. Please ensure to use only the provided adapter and charging cable for your blender to maintain optimal performance and safety.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question