

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [BABYLO](#) /

> [Babylo Hi Lo Highchair and Junior Chair User Manual](#)

BABYLO BL11995

Babylo Hi Lo Highchair and Junior Chair User Manual

Model: BL11995

[Introduction](#) [Safety Information](#) [Components](#) [Setup](#) [Operating](#) [Maintenance](#)
[Troubleshooting](#) [Specifications](#)

1. INTRODUCTION

The Babylo Hi Lo Highchair is designed to be a versatile feeding companion for your child, adapting from 6 months up to 15 kg. This highchair offers 6 seat height adjustments and 3 comfortable recline positions, providing enhanced comfort for both you and your baby. Its compact folding design makes the Babylo Hi Lo Highchair easy to store and ideal for travel. The highchair seat is simple to clean, perfect for messy mealtimes. The 2-layer snack tray is easy to remove for cleaning or accessing your baby. A clever insert divides the large top tray into 2 cup holders, 2 snack compartments, and a main dish area.



Image: The Babylo Hi Lo Highchair in its full highchair configuration and converted to a junior chair, displayed side-by-side to illustrate its versatility.

2. SAFETY INFORMATION

WARNING: Always ensure your child is secured with the 5-point safety harness when using the highchair.

- Never leave your child unattended in the highchair.
- Ensure all locking mechanisms are engaged before placing your child in the highchair.
- Do not use the highchair if any parts are broken, torn, or missing.
- Keep the highchair away from open flames and other strong heat sources.
- Do not use accessories or replacement parts other than those approved by the manufacturer.
- The highchair is suitable for children from 6 months up to 15 kg.

3. COMPONENTS

Before assembly, ensure all components are present and undamaged:

- Highchair Frame (main body with legs)
- Seat Unit with integrated 5-point harness

- Removable 2-layer Tray
- Seat Cushion/Liner



Image: A front view of the Babylo Hi Lo Highchair, showcasing the seat, tray, and frame.

4. SETUP AND ASSEMBLY

Assembly is required for this product. Follow these steps carefully:

1. **Unfolding the Frame:** Gently pull the legs apart until the frame locks into place. Ensure all four legs are firmly on the ground.
2. **Attaching the Seat Unit:** Align the seat unit with the frame's attachment points and push

down until it clicks securely into place.

3. **Inserting the Seat Cushion:** Place the seat cushion onto the seat unit, ensuring the harness straps are threaded through the designated slots.
4. **Attaching the Tray:** Slide the 2-layer tray onto the armrests until it locks into position. The tray has multiple positions for adjustment.



Image: A side view of the Babylo Hi Lo Highchair in its compact folded state, demonstrating its storage capability.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Height Positions

The Babylo Hi Lo Highchair features **6 height adjustments** to suit various table heights and your convenience. To adjust the height:

1. Locate the height adjustment buttons on both sides of the frame, near the top of the legs.
2. Press both buttons simultaneously and slide the seat unit up or down to the desired height.
3. Release the buttons and ensure the seat locks securely into place at the chosen height.

Highchair to Junior Chair



Image: The highchair illustrating its 6 adjustable height positions, with arrows indicating the range of movement.

5.2 Adjusting Recline Positions

The highchair offers **3 recline positions** for your child's comfort, especially useful for younger babies or during nap times. To recline the seat:

1. Locate the recline adjustment lever at the back of the seat unit.
2. Pull the lever and gently push or pull the seat back to the desired recline angle.
3. Release the lever and ensure the seat is securely locked in the chosen position.

Suitable from
6 months to
3 years



Image: The highchair demonstrating its 3 adjustable backrest recline positions, showing the seat tilting backward.

5.3 Using the 5-Point Safety Harness

Always secure your child with the 5-point safety harness to prevent falls and ensure safety during use.

1. Place your child in the seat.
2. Bring the shoulder straps over your child's shoulders and the waist straps around their waist.

3. Connect the shoulder and waist buckles into the central buckle until they click.
4. Adjust the straps to ensure a snug, secure fit without being too tight.
5. To release, press the button on the central buckle.

5.4 Using the Removable Tray

The 2-layer tray is designed for easy cleaning and features multiple compartments.

- **Attaching the Tray:** Slide the tray onto the armrests until it clicks into place. It can be adjusted to 3 positions.
- **Removing the Tray:** Press the release levers on the underside of the tray (usually one on each side) and pull the tray forward and off.
- **Using the 2-Layer Design:** The top layer of the tray can be removed for easy cleaning, revealing a second tray underneath.
- **Snack Compartments:** The tray includes 2 cup holders and 2 snack compartments, along with a main dish area.



Image: A detailed close-up of the highchair's removable tray, highlighting its two cup holders, two snack compartments, and main dish area.

5.5 Converting to Junior Chair Mode

The Babylo Hi Lo Highchair can be converted into a junior chair for older children.

1. Remove the tray.
2. Adjust the highchair to its lowest height setting.
3. The highchair can then be used as a standalone junior chair, allowing the child to sit closer to a standard table.

5.6 Folding for Storage

The highchair features a compact fold for easy storage.

1. Ensure the tray is removed.
2. Adjust the seat to its highest position.
3. Locate the folding mechanisms (refer to the assembly diagram in the product manual for exact locations).
4. Engage the folding mechanisms and push the legs together until the highchair is in its compact folded state.
5. The tray can be stored on the rear of the highchair when folded.



Rear tray
storage

Image: The highchair demonstrating how the tray can be stored on the rear of the frame when the unit is folded for compact storage.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your highchair.

- **Seat Unit and Tray:** Wipe clean with a damp cloth and mild soap. Rinse thoroughly and air dry. The 2-layer tray can be separated for more thorough cleaning.
- **Frame:** Wipe the plastic and metal parts of the frame with a damp cloth. Do not use abrasive cleaners.
- **Harness:** The harness straps can be spot cleaned with mild soap and water. Allow to air dry

completely before use.

- **Storage:** Store the highchair in a clean, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Highchair does not lock into position when unfolded.	Frame not fully extended.	Ensure legs are fully pulled apart until a click is heard, indicating the locking mechanism is engaged.
Tray is difficult to attach or remove.	Release levers not fully pressed; tray misaligned.	Ensure both release levers are fully depressed. Align the tray properly with the armrest grooves before sliding.
Height or recline adjustment is stiff.	Mechanism might be dirty or misaligned.	Check for any obstructions. Clean the adjustment mechanisms. Apply a small amount of silicone spray if necessary (avoiding contact with child).
Harness straps are too tight or too loose.	Incorrect strap adjustment.	Adjust the straps using the buckles to achieve a snug but comfortable fit. Refer to section 5.3.

8. SPECIFICATIONS

Model Number: BL11995

Brand: Babylo

Suitable Age: 6 months +

Maximum Weight Capacity: 15 kg (33 lbs)

Material: Plastic

Height Positions: 6

Recline Positions: 3

Safety Harness: 5-point

Tray: Removable, 2-layer with snack compartments

Assembled Dimensions (L x W x H): 79 x 51 x 102 cm (31.1 x 20.1 x 40.2 inches)

Folded Dimensions (L x W x H): 52 x 34 x 90 cm (20.5 x 13.4 x 35.4 inches)

Product Weight: 7.2 kg (15.9 lbs)

Assembly Required: Yes



Image: Diagram showing the assembled dimensions of the Babylo Hi Lo Highchair: 102cm height, 79cm length, and 51cm width.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Babylo customer service. Refer to the product packaging or the official Babylo website for contact details.



Image: The Babylo brand logo with the slogan: "Devoted to creating innovative quality baby products to support modern family life."

© 2024 Babylo. All rights reserved.