Whirlpool ART 6510 SF1

Whirlpool ART 6510 SF1 Built-in Fridge-Freezer User Manual

Model: ART 6510 SF1

Introduction

Thank you for choosing the Whirlpool ART 6510 SF1 Built-in Fridge-Freezer. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your appliance. Please read these instructions carefully before using the appliance and keep them for future reference.

Safety Information

Your safety and the safety of others are paramount. This manual contains important safety messages that must be read and observed at all times. Failure to follow these instructions could result in serious injury or damage to the appliance.

- Ensure the appliance is properly grounded.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- This appliance is intended to be used in household and similar applications.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Only qualified personnel should install or repair this appliance.

Setup and Installation

The Whirlpool ART 6510 SF1 is designed for built-in installation. Proper installation is crucial for optimal performance and safety.

Unpacking and Positioning

- Remove all packaging materials.
- Place the appliance in its final built-in position, ensuring adequate ventilation around the unit as specified in the

installation guide (not provided here, but implied).

- Ensure the appliance is level to prevent vibrations and ensure proper door closure.



Figure 1: The Whirlpool ART 6510 SF1 built-in fridge-freezer with both refrigerator and freezer doors open, displaying the internal shelving and storage compartments. This image illustrates the appliance's design for integration into kitchen cabinetry.

Electrical Connection

- Connect the appliance to a properly grounded electrical outlet. The voltage requirement is 220 Volts.
- Do not use extension cords or multiple adapters.
- Ensure the power cord is not trapped or damaged during installation.

Initial Start-up

- After installation, wait at least 4 hours before plugging in the appliance to allow the refrigerant to settle.
- Once plugged in, set the temperature control to the desired setting.
- Allow the appliance to run for several hours before placing food inside to ensure it reaches the correct temperature.

Operating Instructions

This section details how to operate your fridge-freezer for optimal food preservation.

Temperature Control

The temperature inside the refrigerator and freezer compartments is controlled by a thermostat. The thermostat dial is typically located inside the refrigerator compartment.



Figure 2: A close-up view of the interior of the refrigerator compartment, highlighting the LED light and the rotary thermostat control dial. This dial is used to adjust the cooling intensity for the appliance.

- Rotate the dial to adjust the temperature. Higher numbers usually indicate colder temperatures.
- For normal use, a medium setting is often sufficient.
- Adjust the setting based on ambient temperature and how often the doors are opened.

Food Storage Guidelines

- **Refrigerator Compartment:** Store fresh foods, dairy products, fruits, and vegetables. Ensure food is covered to prevent drying out and odor transfer.
- **Freezer Compartment:** Store frozen foods. Do not place hot food directly into the freezer.
- Avoid overloading the compartments to allow for proper air circulation.

Maintenance and Care

Regular maintenance ensures the longevity and efficiency of your appliance.

Cleaning

- Always unplug the appliance before cleaning.
- Clean the interior and exterior surfaces with a soft cloth and a mild detergent solution.
- Do not use abrasive cleaners, sharp objects, or flammable liquids.
- Clean the door seals regularly to ensure a tight seal.
- Periodically clean the condenser coils at the back of the appliance (if accessible) to maintain efficiency.

Defrosting

Depending on the model, your freezer may require manual defrosting when ice buildup becomes excessive. Refer to the full product manual for specific defrosting instructions for your model.

- Remove all food items and store them in a cool place.
- Unplug the appliance.
- Allow the ice to melt naturally. Do not use sharp objects to remove ice.
- Wipe the interior dry before plugging the appliance back in.

Troubleshooting

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Appliance does not operate	No power supply; power cord not plugged in; fuse blown.	Check power connection; check household fuse/circuit breaker.
Temperature is not cold enough	Door not closed properly; frequent door opening; thermostat set too high; too much food inside.	Ensure door is sealed; avoid frequent opening; adjust thermostat to a colder setting; do not overload.
Excessive noise	Appliance not level; contact with wall/cabinet; loose parts.	Adjust leveling feet; ensure clearance; check for loose items.
Water on the floor	Drain hole blocked; drip tray overflowing.	Clear the drain hole; empty and clean the drip tray.

Specifications

Key technical specifications for the Whirlpool ART 6510 SF1 Built-in Fridge-Freezer:

- **Brand:** Whirlpool
- **Model Number:** ART 6510 SF1
- **Installation Type:** Built-in
- **Total Volume:** 273 Litres (Refrigerator: 194 L, Freezer: 79 L)
- **Voltage:** 220 Volts
- **Noise Level:** 35 Decibels
- **Annual Energy Consumption:** 283 kWh/annum
- **Energy Efficiency Class:** F
- **Cooling Method:** Compressor




Figure 3: The energy efficiency label for the Whirlpool ART 6510 SF1. It displays key performance metrics including an energy class of F, annual energy consumption of 283 kWh, freezer volume of 79 liters, refrigerator volume of 194 liters, and a noise level of 35 dB.

Warranty and Support

For detailed warranty information and customer support, please refer to the warranty card included with your appliance or visit the official Whirlpool website. Keep your purchase receipt as proof of purchase for any warranty claims.
For technical assistance or to schedule a service appointment, please contact Whirlpool customer service through their official channels.

Whirlpool ART 6510 SF1 User Manual - All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question