

Tefal FV2839E0

Tefal Express Steam Iron User Manual

Model: FV2839E0

INTRODUCTION

Thank you for choosing the Tefal Express Steam Iron, model FV2839E0. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before first use and keep it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- **Voltage Compatibility:** This appliance operates on **220 Volts at 50 Hz**. *Do not attempt to use this iron with a 110-120 Volt power supply (common in North America) without a suitable voltage converter.* Using it with an incompatible voltage will damage the appliance and may pose a fire hazard.
- Always unplug the iron from the electrical outlet when filling with water, emptying, or when not in use.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- To protect against a risk of electric shock, do not immerse the iron in water or other liquids.
- Close supervision is necessary for any appliance being used by or near children. Do not leave the iron unattended while connected or on an ironing board.
- Burns can occur from touching hot metal parts, hot water, or steam. Use caution when you turn a steam iron upside down – there may be hot water in the reservoir.
- The iron must be used and rested on a stable surface.
- Do not use the iron if it has been dropped, if there are any visible signs of damage, or if it is leaking.

PRODUCT FEATURES



Image: The Tefal Express Steam Iron FV2839E0, featuring a white body with a translucent blue water tank, a temperature control dial, and steam control buttons on the handle. The soleplate is visible at the bottom.

- **High Wattage:** Designed for rapid heating and powerful steam output.
- **Stainless Steel Soleplate:** Durable and provides smooth gliding over fabrics.
- **Integrated Water Tank:** Translucent design for easy water level monitoring.
- **Precision Tip:** Allows for easy access to difficult areas like collars and seams.
- **Ergonomic Handle:** Designed for comfortable grip during use.

SETUP

1. **Unpacking:** Carefully remove the iron and all accessories from the packaging. Retain packaging for storage or return if necessary.
2. **Initial Cleaning:** Wipe the soleplate with a damp cloth to remove any manufacturing residues.
3. **Water Filling:** Ensure the iron is unplugged. Open the water filling inlet and fill the water tank with clean tap water up to the 'MAX' level indicator. Do not overfill. Close the inlet securely.
4. **Power Connection:** Verify that your electrical outlet provides **220 Volts at 50 Hz**. Plug the iron into a grounded electrical outlet.

OPERATING INSTRUCTIONS

Dry Ironing

1. Ensure the steam control is set to the 'dry' position (no steam).

2. Plug in the iron.
3. Set the temperature dial according to the fabric type. The indicator light will illuminate.
4. Once the light turns off, the iron has reached the desired temperature and is ready for use.

Steam Ironing

1. Fill the water tank as described in the Setup section.
2. Plug in the iron.
3. Set the temperature dial to the appropriate setting for steam ironing (usually indicated on the dial). The indicator light will illuminate.
4. Wait for the indicator light to turn off, signifying the iron is hot enough to produce steam.
5. Adjust the steam control to the desired steam level.
6. Begin ironing. For an extra burst of steam, press the steam shot button.

Vertical Steaming

The iron can be used for vertical steaming of hanging garments or drapes. Hold the iron vertically a few inches away from the fabric and press the steam shot button. Ensure the iron is at maximum temperature for best results.

MAINTENANCE

Cleaning the Soleplate

- Always ensure the iron is unplugged and completely cool before cleaning.
- Wipe the soleplate with a damp cloth and a non-abrasive cleaner if necessary.
- Do not use abrasive scouring pads or harsh chemicals as they can damage the soleplate.

Descaling (Anti-Calc System)

The Tefal Express Steam Iron is equipped with an anti-calc system to reduce limescale build-up. For optimal performance, regular descaling is recommended, especially in hard water areas.

1. Refer to the specific descaling instructions provided in the separate leaflet that came with your iron, or visit the official Tefal website for detailed guidance on the anti-calc system.

Storage

- Empty the water tank after each use.
- Allow the iron to cool completely before storing.
- Store the iron upright on its heel rest to protect the soleplate.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet issue; incorrect voltage.	Check power cord connection; test outlet with another appliance; ensure 220V power supply.

Problem	Possible Cause	Solution
No steam or insufficient steam.	Water tank empty; temperature too low; steam control set to 'dry'.	Fill water tank; set temperature to steam setting; adjust steam control.
Water leaking from soleplate.	Temperature too low for steam; overfilled water tank; iron not hot enough for steam.	Increase temperature; do not overfill; wait for indicator light to turn off before using steam.
White flakes coming from soleplate.	Limescale build-up.	Perform descaling procedure as per manufacturer's instructions.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Brand: Tefal

Model Number: FV2839E0

Special Feature: High Wattage for Rapid Heating and Powerful Steam

Color: White and Blue (as pictured)

Recommended Use: Home

Base Material: Stainless Steel

Voltage: 220 Volts

Frequency: 50 Hz

Product Dimensions: 10 x 2 x 2.7 inches

Item Weight: 3.45 pounds

Date First Available: August 5, 2023

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product or visit the official Tefal website. For customer support, service, or to order replacement parts, please contact Tefal customer service through their official channels.

You can often find support contact information on the manufacturer's website: www.tefal.com