

[Manuals.plus](#) /

› [UPBRIGHT](#) /

› UpBright 12V AC/DC Adapter for Ugee UG-2150 Tablet Monitor User Manual

UPBRIGHT Ugee UG-2150 Power Supply

UpBright 12V AC/DC Adapter for Ugee UG-2150 Tablet Monitor User Manual

Model: Ugee UG-2150 Power Supply

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your UpBright 12V AC/DC Adapter. This power supply is designed to provide reliable power to compatible devices, specifically the Ugee UG-2150 21.5" HD USB LCD IPS Screen Pen Display Tablet Monitor. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, observe the following precautions:

- **Indoor Use Only:** This adapter is designed for indoor use in dry locations. Do not expose it to rain, moisture, or extreme temperatures.
- **Proper Voltage:** Ensure the wall outlet voltage matches the adapter's input voltage range (100-240VAC).
- **Avoid Overloading:** Do not connect devices that exceed the adapter's maximum output capacity (12V 3A 36W).
- **Cable Care:** Do not place heavy objects on the power cord. Avoid bending, twisting, or pulling the cord excessively.
- **Ventilation:** Ensure adequate ventilation around the adapter. Do not cover it or place it in an enclosed space that could lead to overheating.
- **Disconnection:** Always unplug the adapter from the wall outlet before cleaning or if it will be unused for an extended period.
- **Damage:** If the adapter or cable is damaged, discontinue use immediately and contact support. Do not attempt to repair it yourself.

3. PRODUCT OVERVIEW

The UpBright 12V AC/DC Adapter is a switching power supply designed to convert AC mains power to a stable 12V DC output for your compatible device.



Figure 1: UpBright 12V AC/DC Adapter. This image shows the main adapter unit, the attached DC output cable with its barrel connector, and the detachable AC input cable.

The adapter features built-in protection mechanisms including Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard your connected device.




Figure 2: DC Barrel Connector. This image provides a detailed view of the output connector that plugs into your device.

4. SETUP

Follow these steps to set up your UpBright AC/DC Adapter:

1. **Select AC Power Cord:** Identify the appropriate AC power cord for your region (US, EU, UK, AU, etc.). The product typically includes a suitable cord.

Come With A Suitable AC Power Cord (Only One) to Fit Your Country/Area



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UpBright® LIMITED WARRANTY



Figure 3: Regional AC Power Cords. This image displays different types of AC power cords compatible with the adapter, designed for various international outlets.

2. **Connect AC Cord:** Plug the selected AC power cord into the input port of the UpBright AC/DC Adapter.
3. **Connect to Device:** Insert the DC barrel connector from the adapter's output cable into the power input port of your Ugee UG-2150 Tablet Monitor. Ensure a firm and secure connection.
4. **Connect to Wall Outlet:** Plug the AC power cord into a standard wall outlet.

5. OPERATING INSTRUCTIONS

Once properly connected, the UpBright AC/DC Adapter will automatically supply power to your Ugee UG-2150 Tablet Monitor. No further user interaction is required for basic operation. The adapter is designed for continuous use within its specified operating parameters.

6. MAINTENANCE

To ensure the longevity and optimal performance of your adapter:

- **Cleaning:** Disconnect the adapter from the power source and device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cables.
- **Inspection:** Periodically inspect the adapter and cables for any signs of damage, such as frayed wires, cracks, or loose connections.

7. TROUBLESHOOTING

If you encounter issues with your UpBright AC/DC Adapter, refer to the following common problems and solutions:

- **No Power to Device:**
 - Ensure the AC power cord is securely plugged into both the adapter and the wall outlet.

- Verify that the wall outlet is functional by testing it with another device.
- Check that the DC barrel connector is fully inserted into the device's power input.
- Confirm that the device itself is powered on.
- **Adapter Overheating:**
 - Ensure the adapter is not covered and has adequate ventilation.
 - Verify that the connected device's power requirements do not exceed the adapter's specifications.
- **Device Not Charging/Functioning Properly:**
 - Double-check that the adapter is the correct model and voltage for your Ugee UG-2150 Tablet Monitor.
 - Inspect the adapter and cables for any visible damage.

If the problem persists after attempting these solutions, please contact UpBright customer support.

8. SPECIFICATIONS

Brand	UPBRIGHT
Model Number	Ugee UG-2150 Power Supply
Input Voltage	100-240VAC, 50/60Hz
Output Voltage	12V DC
Output Current	3A
Wattage	36W
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Product Dimensions	6 x 3 x 1 inches
Item Weight	8 ounces
Compatible Devices	Ugee UG-2150 21.5" HD USB LCD IPS Screen Pen Display Tablet Monitor

9. WARRANTY AND SUPPORT

UpBright products are designed for reliability and performance. This product includes:

- **30-Day Refund Policy:** If you are not satisfied with your purchase, a refund is available within 30 days.
- **24-Month Exchange Policy:** The product is covered by a 24-month exchange policy for manufacturing defects.

For technical assistance, warranty claims, or any other inquiries, please contact UpBright customer support through your retailer or the official UpBright channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BXNZKC6D>

More documents and user manuals: <https://manuals.plus/>