

[Manuals.plus](#) /

› [OUTON](#) /

› OUTON LED Floor Lamp User Manual - Model FL01

OUTON FL01

OUTON LED Floor Lamp User Manual

Model: FL01

Brand: OUTON

1. INTRODUCTION

Thank you for purchasing the OUTON LED Floor Lamp. This manual provides detailed instructions for the safe and efficient use of your new lamp. Please read this manual thoroughly before installation and operation, and retain it for future reference.

This versatile floor lamp features a powerful 27W main uplight and a flexible 7W reading lamp, both offering dimmable brightness and four adjustable color temperatures. Control your lighting experience with the included remote control or the integrated touch panel.

2. SAFETY INSTRUCTIONS

- Ensure the power supply voltage matches the lamp's requirements (230 Volts).
- Do not disassemble or modify the lamp. This may cause damage or electric shock.
- Keep the lamp away from water or other liquids.
- Do not cover the lamp with cloth or other materials while it is operating to prevent overheating.
- The lamp features a wide (9.8 inches) and weighted (6.06 lbs) base for stability. Ensure it is placed on a flat, stable surface to prevent tipping.
- This lamp is for indoor use only.
- Unplug the lamp from the power outlet before cleaning or performing any maintenance.

3. PACKAGE CONTENTS

Please check the package for the following items:

- OUTON LED Floor Lamp (Main pole sections, base, main light head, reading light arm)
- Remote Control
- User Manual

4. PRODUCT OVERVIEW



Figure 4.1: OUTON LED Floor Lamp with main light, reading light, and two remote controls. The lamp features a sleek black design with a circular main light and a smaller, flexible reading light. Two remote controls are shown below the lamp.

The OUTON LED Floor Lamp is designed for versatile illumination, featuring two independent light sources:

- **Main Uplight:** A 27W LED light providing 2400 lumens, ideal for general room illumination. It can rotate 350 degrees and tilt 85 degrees.
- **Reading Lamp:** A 7W flexible LED light providing 400 lumens, perfect for focused tasks like reading or working. It can tilt 90 degrees.

Both lights offer 4 color temperature settings (3000K Warm, 4000K Warm White, 5000K Cool White, 6000K Daylight) and stepless dimmable brightness from 5% to 100%.



Figure 4.2: Lamp dimensions and adjustability. The lamp stands 70.5 inches tall with a 9.8-inch diameter base. The main light head can rotate 350 degrees and tilt 85 degrees, while the reading light can tilt 90 degrees for optimal positioning. The power cord length is 7.3 ft.

5. SETUP AND ASSEMBLY

The OUTON LED Floor Lamp is designed for easy assembly without the need for additional tools.

1. Carefully unpack all components from the packaging.
2. Place the heavy base on a flat, stable surface.
3. Screw the main pole sections together clockwise until they are securely tightened. Ensure the power cord passes freely through the pole.
4. Attach the main light head and the reading light arm to the top of the assembled pole, screwing them clockwise until firm.
5. Plug the power cord into a standard 230V electrical outlet.

Your lamp is now ready for operation.

6. OPERATING INSTRUCTIONS

The OUTON LED Floor Lamp can be controlled via its integrated touch panel or the included remote control.

6.1 Touch Control



Figure 6.1: Touch control panel on the lamp pole. From top to bottom: Reading Lamp On/Off, Adjust Brightness (+/-), Change Color Temperature (CCT), Main Lamp On/Off.

The touch control panel is located on the main pole of the lamp. It allows for independent control of the main and reading lights.

- **Reading Lamp On/Off:** Touch the top power icon to turn the reading lamp on or off.
- **Adjust Brightness:** Touch the '+' or '-' icons to increase or decrease the brightness of the currently active lamp.
- **Change Color Temperature (CCT):** Touch the 'CCT' icon to cycle through the 4 color temperature modes (3000K, 4000K, 5000K, 6000K).
- **Main Lamp On/Off:** Touch the bottom power icon to turn the main lamp on or off.

6.2 Remote Control

The magnetic remote control offers comprehensive control over both lamps. It can be conveniently attached to the metal pole of the lamp.

- **Power On/Off:** Press the power button to turn the lamp on or off.
- **Brightness Adjustment:** Use the '+' and '-' buttons to adjust the brightness steplessly.
- **Color Temperature:** Use the 'CCT' buttons to cycle through the 4 color temperature modes.
- **Independent Lamp Control:** The remote allows for separate control of the main and reading lights. Refer to the remote's specific buttons for each lamp.

6.3 Special Functions



Figure 6.2: The lamp features a 1-hour timer and a memory function.

- **Memory Function:** The lamp remembers the last brightness and color temperature settings when it is turned off and on again.
- **1-Hour Timer:** To activate the 1-hour timer, long-press the On/Off button on the touch control panel. The lamp will

automatically turn off after one hour.

6.4 Color Temperature Options



Figure 6.3: Visual representation of the four color temperatures (Warm, Warm White, Cool White, Daylight) and the stepless dimming capability from 5% to 100%.

- **3000K (Warm):** Soft, cozy light for relaxation.
- **4000K (Warm White):** Neutral, comfortable light for general activities.
- **5000K (Cool White):** Bright, clear light for tasks and focus.
- **6000K (Daylight):** Very bright, invigorating light, simulating natural daylight.

7. MAINTENANCE

To ensure the longevity and optimal performance of your OUTON LED Floor Lamp, follow these maintenance guidelines:

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the lamp. Do not use abrasive

cleaners, solvents, or polishes as they may damage the finish.

- **LEDs:** The integrated LED lights are designed for a long lifespan (over 50,000 hours) and are not user-replaceable.
- **Storage:** If storing the lamp for an extended period, unplug it and store it in a dry, cool place.

8. TROUBLESHOOTING

If you encounter any issues with your lamp, please refer to the following troubleshooting steps:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply.	Check if the power cord is securely plugged into a working outlet. Test the outlet with another device.
Remote control not working.	Remote batteries are dead or incorrectly inserted. Obstruction between remote and lamp.	Replace the AAA batteries in the remote control. Ensure there are no obstacles between the remote and the lamp's sensor.
Brightness or color temperature cannot be adjusted.	Incorrect control method or temporary malfunction.	Ensure you are using the correct buttons on the remote or touch panel. Try unplugging the lamp for 30 seconds and plugging it back in to reset.
Lamp flickers.	Unstable power supply or loose connection.	Ensure the power cord is firmly connected. Try plugging the lamp into a different outlet.

If the problem persists after trying these steps, please contact customer support.

9. SPECIFICATIONS




Figure 9.1: EU Energy Label for OUTON MF18812. The lamp has an energy efficiency rating of E, consuming 34 kWh per 1000 hours of operation. For more details, visit eprel.ec.europa.eu/qr/1035181.

Feature	Specification
Brand	OUTON

Feature	Specification
Model Number	FL01
Product Dimensions (L x W x H)	25 x 25 x 178 cm (9.8 x 9.8 x 70.1 inches)
Item Weight	3.2 Kilograms (7.06 lbs)
Color	Black
Material	Plastic
Finish Type	Matte
Voltage	230 Volts
Light Source Type	Integrated LED
Main Light Wattage	27 Watts
Main Light Luminous Flux	2400 Lumens
Reading Light Wattage	7 Watts
Reading Light Luminous Flux	400 Lumens
Color Temperatures	3000K, 4000K, 5000K, 6000K
Control Methods	Remote Control, Touch Control
Special Features	Memory Function, 1-Hour Timer, Dimmable Brightness
Lifespan	Over 50,000 hours
Cord Length	7.3 ft
Energy Efficiency Class	E

10. WARRANTY AND SUPPORT

OUTON is committed to providing high-quality products and customer satisfaction. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For technical support, troubleshooting assistance, or any questions regarding your OUTON LED Floor Lamp, please contact OUTON customer service. We aim to provide a quick reply within 12 hours.

You can typically find contact information on the product packaging, the retailer's website, or the official OUTON brand store.

© 2023 OUTON. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BXPY8R2>

More documents and user manuals: <https://manuals.plus/>