Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEGO 6425855

LEGO City 2023 Advent Calendar (Model 60381) Instruction Manual

Official Product Guide

Introduction

This instruction manual provides comprehensive details for the LEGO City 2023 Advent Calendar, Model 60381. It describes the contents, assembly process for daily mini-builds, and how to utilize the integrated playmat for imaginative play. Designed for ages 5 and up, this set contains 258 pieces, offering a daily building experience leading up to Christmas.



Image: The complete LEGO City 2023 Advent Calendar set, showcasing the box and all 24 individual mini-builds and minifigures.

Safety Information

WARNING: CHOKING HAZARD. Toy contains small parts and a small ball. Not for children under 3 years.

Setup

1. **Unboxing:** Carefully remove the Advent Calendar box from its packaging.
2. **Prepare the Playmat:** The front panel of the Advent Calendar box folds down to reveal a festive winter wonderland playmat. Gently fold this panel down to create the scene for your daily builds.
3. **Locate Daily Doors:** The calendar features 24 numbered doors. Each door corresponds to a day leading up to Christmas.



Image: A child engaging with the Advent Calendar, demonstrating the fold-out playmat and the process of opening a daily door.

Operating Instructions

1. **Daily Discovery:** Starting from December 1st, open the door corresponding to the current date.
2. **Retrieve Mini-Build:** Inside each door, you will find a small bag containing LEGO elements for a mini-build or minifigure.
3. **Assembly:** Each daily surprise toy comes with easy step-by-step building instructions printed on the inside of each calendar window. Follow these instructions to assemble your new collectible.
4. **Play and Display:** Once assembled, place your new mini-build or minifigure on the fold-out winter wonderland playmat to enhance your festive scene. The various characters and accessories can be combined with other LEGO City playsets for expanded creative play.



Image: A detailed view of the Advent Calendar's playmat populated with several assembled mini-builds and minifigures.

Your browser does not support the video tag.

Video: A brief overview of the LEGO City Advent Calendar 2023, showcasing the assembled mini-builds and the overall festive theme.

Maintenance

- **Cleaning:** To clean LEGO bricks, use a mild soap solution and lukewarm water. Avoid hot water or harsh chemicals, as these can damage the plastic. Rinse thoroughly and air dry.
- **Storage:** Store LEGO elements in a dry, cool place away from direct sunlight to prevent discoloration and warping. Keep small parts organized to prevent loss.
- **Handling:** Handle LEGO bricks gently to avoid breakage. Do not force pieces together if they do not fit easily.

Troubleshooting

- **Missing Pieces:** If you find any missing pieces, please contact LEGO Customer Service directly through their official website.
- **Assembly Difficulties:** Refer to the step-by-step instructions printed on the inside of each calendar door. If further assistance is needed, online building guides are often available on the LEGO website.
- **Damaged Parts:** For any damaged parts, contact LEGO Customer Service for replacement options.

Specifications

Product Name	LEGO City 2023 Advent Calendar
Model Number	60381 (Item model number: 6425855)
Brand	LEGO
Number of Pieces	258
Recommended Age	5 years and up
Product Dimensions	15 x 10 x 0.1 inches
Item Weight	13.4 ounces
Material	Plastic
Release Date	September 1, 2023

Warranty and Support

For warranty information, replacement parts, or further product support, please visit the official LEGO Customer Service website or contact their support team directly. Details can typically be found on the LEGO website or within the product packaging.
You can also visit the Official LEGO Store on Amazon for more products and information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BXQ52N4L

More documents and user manuals: **https://manuals.plus/**