

## JVC HA-XC72T

# JVC HA-XC72T Wireless Headphones User Manual

Model: HA-XC72T

## INTRODUCTION

---

Thank you for purchasing the JVC HA-XC72T Wireless Headphones. This manual provides essential information for the safe and effective use of your device. Please read it thoroughly before use and keep it for future reference.

## SAFETY INFORMATION

---

- Do not disassemble, repair, or modify the unit.
- Avoid exposing the unit to extreme temperatures, direct sunlight, or high humidity.
- Keep the unit away from water and other liquids, except for its specified water resistance.
- Do not use the unit at excessively high volumes for extended periods to prevent hearing damage.
- Keep out of reach of children. Small parts may pose a choking hazard.

## PACKAGE CONTENTS

---

Verify that all items are present in the package:

- JVC HA-XC72T Wireless Headphones (Left and Right earbuds)
- Charging Case
- USB Charging Cable
- Earpieces (S/M/L sizes)
- "XX" Logo Sticker

## SETUP

---

## 1. Charging the Headphones and Case

Before first use, fully charge the headphones and charging case.

1. Place both left and right earphones into the charging case.
2. Connect the USB charging cable to the charging case and a USB power adapter (not included).
3. The charging indicator lamps on the case will show the charging status. Once fully charged, the lamps will change or turn off.

**最大21時間再生\*2の  
ロングバッテリーライフ**



The JVC HA-XC72T charging case with earbuds, held in a hand, highlighting the long battery life of up to 21 hours (9 hours from earbuds + 12 hours from case). Actual playback time may vary.

## 2. Bluetooth Pairing

To connect your headphones to a device:

1. Take both earphones out of the charging case. They will automatically enter pairing mode. The indicator lamp on one earbud will flash rapidly.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "HA-XC72T" from the list of found devices.
4. Once connected, the indicator lamp will stop flashing.

## OPERATING INSTRUCTIONS

---

### Power On/Off

- **Power On:** Take the earphones out of the charging case. They will power on automatically.
- **Power Off:** Place the earphones back into the charging case. They will power off automatically and begin charging.

### Music Playback and Volume Control

The HA-XC72T features touch controls on each earbud.

- **Play/Pause:** Tap the touch sensor on either earbud once.
- **Next Track:** Tap the touch sensor on the right earbud twice.
- **Previous Track:** Tap the touch sensor on the left earbud twice.
- **Volume Up:** Tap the touch sensor on the right earbud three times.
- **Volume Down:** Tap the touch sensor on the left earbud three times.

### Noise Cancelling / Ambient Sound Mode

The headphones offer Active Noise Cancellation and a Quick Ambient Sound function.

# 静寂な空間で音を楽しむ ノイズキャンセリング機能



A person wearing the JVC HA-XC72T earbud, with visual representation of noise cancellation waves, emphasizing the ability to enjoy sound in quiet environments.

- **Toggle Modes:** Press and hold the touch sensor on the left earbud for approximately 2 seconds to cycle through Noise Cancelling ON, Ambient Sound ON, and Noise Cancelling OFF.
- **Quick Ambient Sound:** This function allows you to hear your surroundings without removing the earphones, useful for conversations.

## Low Latency Mode

This mode reduces audio delay, enhancing the experience for gaming and video playback.

# ゲームや動画がもっと快適に 楽しめる低遅延モード



A person enjoying video content on a smartphone while wearing the JVC HA-XC72T earbuds, illustrating the low latency mode for synchronized audio and video.

- **Activate/Deactivate:** Press and hold the touch sensor on the right earbud for approximately 2 seconds to toggle Low Latency Mode ON/OFF.

## Hands-free Calling

- **Answer/End Call:** Tap the touch sensor on either earbud once.
- **Reject Call:** Press and hold the touch sensor on either earbud for approximately 2 seconds.

## Single Earbud Use

Either the left or right earbud can be used independently for music playback or calls.

## MAINTENANCE

---

To ensure the longevity and performance of your headphones:

- Clean the earphones and charging case regularly with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.
- Ensure the earphones are dry before placing them back into the charging case.
- Store the headphones in their charging case when not in use to protect them from dust and damage.

# 外出時も安心して使える 防水防塵対応\*<sup>1</sup>



The JVC HA-XC72T earbuds on a wet surface, demonstrating their IP55 water and dust resistance, suitable for outdoor use. Note: IP55 rating applies to the earbud body only.

## TROUBLESHOOTING

---

If you encounter issues with your HA-XC72T headphones, refer to the following common solutions:

### No Sound from One Earbud (or other pairing issues)

If only one earbud is producing sound, or if you experience other pairing difficulties, try the following steps:

1. Place both left and right earphones back into the charging case.
2. Take both left and right earphones out of the case simultaneously. Check if the issue is resolved.
3. If the issue persists, delete the "HA-XC72T" Bluetooth registration from your device's Bluetooth settings and attempt to re-pair.
4. If the above steps do not resolve the issue, perform a factory reset (initialization) as follows:

#### **Factory Reset (Initialization) Steps:**

1. Place both left and right earphones into the charging case. Ensure the charging lamps are lit, indicating they are charging.
2. While the earphones are in the case, press and hold the touch sensors on both the left and right earphones for approximately 15 seconds. The lamp will blink or its reaction will change, indicating initialization is in progress. Perform this for both earbuds.
3. Release your fingers from the touch sensors and close the charging case lid.
4. Wait for approximately 10-20 seconds.
5. Take both left and right earphones out of the case simultaneously. The earphones will begin synchronizing with each other again.
6. On your smartphone or device, open the Bluetooth settings. If "HA-XC72T" is still listed, select "Forget Device" or "Delete Device".
7. Perform the Bluetooth pairing process again from step 1 of the "Bluetooth Pairing" section.

#### **No Power**

- Ensure the charging case and earphones are fully charged.
- Check if the charging cable is securely connected.

#### **Poor Sound Quality**

- Ensure the earphones are properly seated in your ears. Try different earpiece sizes for a better seal.
- Move closer to your connected device to reduce interference.
- Clean any debris from the earphone nozzles.

## **SPECIFICATIONS**

---

<b>Brand</b>	JVC
<b>Model Name</b>	HA-XC72T
<b>Headphone Type</b>	In-ear
<b>Color</b>	Black
<b>Wireless Type</b>	Bluetooth (Ver. 5.2, Power Class 1)
<b>Noise Control</b>	Active Noise Cancellation
<b>Control Method</b>	Touch
<b>Waterproof Rating</b>	IP55 (Earphone body only)

<b>Dustproof Rating</b>	IP55 (Earphone body only)
<b>Product Weight</b>	Approx. 4.6 grams (each earbud)
<b>Charging Case Weight</b>	Approx. 34 grams
<b>Battery Life (Earbuds)</b>	Up to 7.5 hours (with Noise Cancelling ON)
<b>Total Battery Life (with Case)</b>	Up to 21 hours (9 hours from earbuds + 12 hours from case)
<b>Additional Features</b>	Deep Bass Sound, Low Latency Mode, Ambient Sound Mode, Hands-free Calling, Single Earbud Use

## WARRANTY

---

This product comes with a 1-year manufacturer's warranty from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

## SUPPORT

---

For further assistance, technical support, or warranty inquiries, please contact JVC customer service through their official website or the contact information provided with your product packaging.