

YOUNGREEN A8

YOUNGREEN Magnetic Wireless Charger (Model A8)

Instruction Manual

Contents	Setup	Operation	Introduction	Package	Specifications	Safety
			Maintenance	Troubleshooting		
			Information	Warranty & Support		

1. INTRODUCTION

Thank you for choosing the YOUNGREEN Magnetic Wireless Charger (Model A8). This device provides efficient and convenient wireless charging for compatible Apple devices. Designed with strong N52 magnets, it ensures secure and optimal alignment for fast charging.

Key Features:

- **Strong Magnetic Alignment:** Upgraded N52 magnets ensure precise alignment and secure attachment for optimal power transfer.
- **Fast Wireless Charging:** Delivers up to 20W charging with the included Type-C adapter, charging from 10% to 50% in approximately 30 minutes and fully in 2.5 hours.
- **Smart LED Indicator:** Features a blue LED that provides clear feedback on charging status without causing light annoyance during sleep.
- **Multiple Protections:** Built-in safeguards against overcharging, over-current, over-voltage, short-circuit, and over-temperature.
- **Compact & Portable:** Slim design (0.26 inches thick, 0.11 lbs) with a 4 ft hardwired cable, ideal for home, office, or travel.

Compatibility:

This charger is compatible with iPhone 17/17 Pro/17 Pro Max/iPhone Air/iPhone 16/iPhone 16 Plus/iPhone 16 Pro/iPhone 16 Pro Max/iPhone 15 Plus/iPhone 15 Pro Max/iPhone 14/iPhone 14 Pro/iPhone 14 Plus/iPhone 14 Pro Max/iPhone 13/iPhone 13 Pro/iPhone 13 Pro Max/iPhone 13 mini/iPhone 12/iPhone 12 Pro/iPhone 12 Pro Max/iPhone 12 mini series and AirPods Pro.

Note: For optimal magnetic adsorption and charging efficiency, use a Mag-Safe compatible case or no case. Thick, non-magnetic cases may weaken the magnetic connection.

2. PACKAGE CONTENTS

Please check the box for the following items:

- YOUNGREEN Magnetic Wireless Charger (Model A8) with integrated 3.94 ft (1.2m) USB Type-C cable
- 20W PD Type-C Adapter
- User Manual



Image: Contents of the YOUNGREEN Magnetic Wireless Charger package, including the charger pad, 20W Type-C adapter, and user manual.

3. SETUP

1. **Connect the Adapter:** Plug the included 20W PD Type-C Adapter into a wall outlet.
2. **Connect the Charger:** Insert the USB Type-C end of the magnetic wireless charger's cable into the 20W PD adapter.
3. **Power On:** Once connected, the blue smart LED indicator on the charger will light up for 3 seconds and then turn off, indicating it is ready for use.

N52 Stronger Magnets & Placement Sensitive



Image: Setup diagram illustrating the connection of the wireless charger to the 20W adapter and a phone being charged.

4. OPERATING INSTRUCTIONS

Charging Your Device:

1. **Place Device:** Gently place your compatible iPhone (12-17 series) or AirPods Pro onto the center of the magnetic wireless charging pad.
2. **Magnetic Alignment:** The strong N52 magnets will automatically align your device to the optimal charging position.
3. **Charging Indication:** The blue smart LED indicator will light up for 5 seconds when charging begins and then turn off to avoid disturbance, especially at night.
4. **Usage During Charging:** The charger's slim and lightweight design allows you to comfortably hold and use your phone while it is charging.

Sturdy & Safety Fast Charging



Image: Demonstrates the high placement sensitivity and 360-degree rotation feature, allowing users to use their phone while it charges.

LED Indicator Behavior:

- **Connected to Power:** Blue LED lights up for 3 seconds, then turns off.
- **Device Charging:** Blue LED lights up for 5 seconds, then turns off.
- **No Light During Sleep:** Designed to be sleep-friendly with no bright light annoyance.



Image: Illustrates the sleep-friendly design of the charger with its smart LED indicator that turns off after a few seconds.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the charger. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and extreme temperatures.
- **Temperature Guidelines:** For optimal device charging and battery longevity, maintain an ambient temperature between 62°F-72°F (16°C-22°C). Exposure to temperatures above 95°F (35°C) may affect charging performance or battery life.
- **Cable Care:** Avoid bending or twisting the cable excessively to prevent damage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging or charging slowly.	• Improper device placement. • Thick or non-magnetic phone case. • Charger not properly connected to power. • Adapter not providing sufficient power. • High ambient temperature.	• Ensure the device is centered on the charging pad. • Remove the phone case or use a Mag-Safe compatible case. • Verify the charger is securely plugged into the 20W PD adapter and the adapter into a working wall outlet. • Ensure you are using the included 20W PD adapter. • Move the device and charger to a cooler environment.
Weak magnetic connection.	• Non-magnetic or thick phone case. • Foreign objects between device and charger.	• Remove the phone case or use a Mag-Safe compatible case. • Ensure there are no objects (e.g., credit cards, metal plates) between your device and the charger.
LED indicator not lighting up.	• Charger not receiving power. • LED has turned off after initial 3 or 5 seconds (normal operation).	• Check all power connections. Try a different outlet. • This is normal behavior. The LED is designed to turn off to avoid light disturbance.

7. SPECIFICATIONS

- **Model Number:** A8
- **Product Dimensions:** 2.33 x 2.35 x 0.26 inches (5.92 x 5.97 x 0.66 cm)
- **Item Weight:** 0.004 ounces (0.11 grams)
- **Cable Length:** Approximately 3.94 ft (1.2 meters)
- **Input Voltage:** 5V-2A, 9V-2A (AC)
- **Output Wattage:** 20W (Max)
- **Connector Type:** USB Type-C
- **Special Features:** Fast Charging, Lightweight Design, Magnetic, MagSafe Compatible, Wireless Charging

8. SAFETY INFORMATION

The YOUNGREEN Magnetic Wireless Charger is designed with multiple intelligent protection features to ensure the safety of your devices and the charger itself:

- **Overcharging Protection:** Prevents your device from being overcharged, extending battery life.
- **Over-current Protection:** Safeguards against excessive current flow.
- **Over-voltage Protection:** Protects against voltage spikes.
- **Short-circuit Protection:** Automatically cuts off power in case of a short circuit.
- **Over-temperature Protection:** Monitors and regulates temperature to prevent overheating.
- **Anti-interruption Charging:** Ensures stable charging without interruptions.



Image: Visual representation of the charger's comprehensive safety features.

General Safety Precautions:

- Do not disassemble or modify the product.
- Keep away from water, fire, and high temperatures.
- Avoid dropping or subjecting the charger to strong impacts.
- Do not use if the product appears damaged.

9. WARRANTY AND SUPPORT

YOUNGREEN is committed to providing high-quality products and customer satisfaction. Your Magnetic Wireless Charger (Model A8) comes with the following support:

- **12 Months Care Service:** Enjoy peace of mind with our extended care service.
- **7 Days Return Support:** Hassle-free returns within 7 days of purchase.
- **24 Hours Online Support:** Our dedicated support team is available 24/7 to assist you with any inquiries or issues.

If you encounter any issues with your wireless charger, please contact us via email at any time. We are here to help.



Image: YOUNGREEN customer care details.

10. PRODUCT VIDEOS

Wireless Charger Magnetic Fast Charging Mag Safe

Your browser does not support the video tag.

Video: An official seller video demonstrating the magnetic fast charging capabilities of the wireless charger.

© 2025 YOUNGREEN. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question