

## InSinkErator 45394Y-ISE

# InSinkErator FHC3010 Hot and Cold Water Dispenser User Manual

Model: 45394Y-ISE | Brand: InSinkErator

## INTRODUCTION

This user manual provides comprehensive instructions for the installation, operation, and maintenance of your InSinkErator FHC3010 Modern Hot and Cold Water Dispenser. Please read this manual thoroughly before installation and use to ensure safe and efficient operation of your appliance. Keep this manual for future reference.

## PRODUCT OVERVIEW

The InSinkErator FHC3010 is a modern hot and cold water dispenser designed for convenience and efficiency in your kitchen. It provides instant access to near-boiling water and filtered cold water directly from your sink.



Figure 1: InSinkErator FHC3010 Hot and Cold Water Dispenser in Matte Black finish.

## Key Features:

- Modern design with Matte Black finish.
- Dedicated faucet for instant hot and cold water.
- Provides near-boiling water (up to 200°F) for hot beverages and cooking.
- Delivers filtered cold water.
- Easy-to-use dual handles for precise temperature control.
- Under-sink installation for a clean countertop appearance.

## SETUP

---

Proper installation is crucial for the performance and safety of your water dispenser. It is recommended that installation be performed by a qualified plumber.

### Before You Begin:

- Ensure you have all necessary tools and components as listed in the packaging.
- Verify that your electrical outlet meets the product's power requirements (Corded Electric).
- Confirm adequate space under the sink for the dispenser tank and connections.
- Turn off the main water supply to your kitchen sink.

### Installation Steps:

1. **Prepare the Sink Hole:** If a hole is not pre-drilled, create a 1-3/8 inch (3.5 cm) diameter hole in your sink or countertop.
2. **Mount the Faucet:** Insert the faucet shank through the sink hole. Secure it from underneath with the provided mounting hardware.
3. **Connect Water Lines:** Connect the hot and cold water supply lines to the appropriate inlets on the dispenser faucet. Ensure all connections are tight to prevent leaks.
4. **Install the Tank:** Position the hot water tank securely under the sink. Connect the tank's outlet to the faucet's hot water inlet.
5. **Electrical Connection:** Plug the dispenser's power cord into a grounded electrical outlet.
6. **Flush the System:** Before heating, open the hot water handle on the dispenser and allow water to flow until it runs smoothly, removing any air from the system.
7. **Activate Heating:** Once flushed, turn on the power to the hot water tank. Allow approximately 15-20 minutes for the water to reach its set temperature.

## OPERATING INSTRUCTIONS

---

Your InSinkErator FHC3010 dispenser is designed for simple and intuitive operation.

### Dispensing Hot Water:

- Locate the hot water handle (typically on the left side).
- Push the handle back and hold it to dispense near-boiling water. Release the handle to stop the flow.
- *Caution:* Hot water can cause burns. Always use care when dispensing hot water.

### Dispensing Cold Water:

- Locate the cold water handle (typically on the right side).
- Pull the handle forward and hold it to dispense filtered cold water. Release the handle to stop the flow.

## MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your dispenser.

### Cleaning:

- Clean the exterior of the faucet with a soft, damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals.
- For the Matte Black finish, use non-abrasive cleaning products specifically designed for matte surfaces to prevent damage.

### Filter Replacement:

- The water filter (if installed) should be replaced every 6 months or as indicated by reduced water flow.
- Refer to your filter's specific instructions for replacement procedures.

### Descaling (for Hot Water Tank):

- In areas with hard water, mineral deposits may accumulate in the hot water tank.
- Consult a qualified technician for descaling procedures if you notice a significant decrease in hot water flow or temperature.

## TROUBLESHOOTING

If you encounter issues with your dispenser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No hot water	Power not connected or tripped breaker. Tank not filled.	Check power connection and circuit breaker. Ensure water flows from the hot side before turning on power.
Low water flow	Clogged filter. Kinked water line.	Replace water filter. Check water lines for kinks or obstructions.
Leaking from faucet	Loose connections. Damaged O-rings.	Tighten connections. Contact customer support for replacement parts or service.
Water not hot enough	Temperature setting too low. Mineral buildup.	Adjust temperature setting on the tank (if applicable). Consider descaling.

If the problem persists, please contact InSinkErator customer support.

## SPECIFICATIONS

Attribute	Detail
Brand	InSinkErator
Model Number	45394Y-ISE (FHC3010)
Color	Matte Black
Style	Modern

Attribute	Detail
Installation Type	Under Sink
Number of Settings	2 (Hot, Cold)
Upper Temperature Rating	200 Degrees Fahrenheit
Power Source	Corded Electric
Product Dimensions	5.21 x 6 x 9 inches
Item Weight	4.3 pounds

## WARRANTY & SUPPORT

InSinkErator products are built with quality and durability in mind. For specific warranty information, please refer to the warranty card included with your product or visit the official InSinkErator website. For technical support, replacement parts, or service inquiries, please contact InSinkErator customer service.

You can find more information and contact details on the [InSinkErator Store on Amazon](#).

© 2023 InSinkErator. All rights reserved.

### Documents - InSinkErator – 45394Y-ISE

#### [pdf] Warranty

PowerPoint Presentation Pastore Marco COMRES ISE UK service training en gb 8864534 insinkerator  
emerson documents Service 26th of January 2023 AGENDA InSinkErator56 77970H 66 77971H  
Evolution 100 78125H 150 78432H IT DOESN T WORK ! Page 55 NEOCHILLER trouble shooting  
Page service 63864insinkerator 8864534insinkerator |||  
Service training 26th of January 2023 - AGENDA 9:00 9:30 am 9:30 - 10:00 am 10:10  
am 10:10 10:25 ... I Moderno tap Hot and H/C 45393-ISE 45393AU-ISE 45393Y-ISE  
45393C-ISE 45394-ISE 45394AU-ISE **45394Y-ISE** 45394C-ISE 45395-ISE 45395AU-  
ISE 45395Y-ISE 45395C-ISE 45396-ISE 45396AU-ISE 4539...

lang:en score:21 filesize: 5.43 M page\_count: 74 document date: 2023-02-16

