

seenda B0BXWLFXPR

seenda Wireless Keyboard and Mouse Combo

INSTRUCTION MANUAL

Model: B0BXWLFXPR

1. INTRODUCTION

Thank you for choosing the seenda Wireless Keyboard and Mouse Combo. This product provides a convenient and efficient wireless solution for your computer, laptop, or desktop PC. Featuring a 2.4GHz wireless connection, quiet keystrokes, and a full-size design, this combo is designed for comfortable and productive use. This manual will guide you through the setup, operation, and maintenance of your new wireless peripherals.

2. PACKAGE CONTENTS

- 1 x seenda Wireless Keyboard
- 1 x seenda Wireless Mouse
- 1 x USB Receiver (stored inside the mouse battery compartment)
- 1 x User Manual

3. PRODUCT OVERVIEW

The seenda Wireless Keyboard and Mouse Combo offers a seamless and ergonomic experience. The keyboard features a full-size layout with a numeric pad, dedicated function keys, and multimedia hotkeys for enhanced productivity. The mouse is designed for comfortable grip and includes adjustable DPI settings for precise control.



Image: The seenda wireless keyboard and mouse combo, showing the purple keyboard, matching mouse, and the small USB receiver.

MULTIMEDIA HOTKEYS & FUNCTIONAL KEYS



Image: Detailed diagram illustrating the multimedia hotkeys on the keyboard and the various components of the mouse, including the left/right buttons, scroll wheel, and power switch.

scroll wheel, DPI switch button, power switch, and USB receiver location.

4. SETUP

Setting up your seenda Wireless Keyboard and Mouse Combo is quick and easy. No drivers are required; simply plug and play.

- 1. Locate the USB Receiver:** The USB receiver is conveniently stored inside the battery compartment of the wireless mouse. Open the battery cover on the underside of the mouse and carefully remove the small USB receiver.
- 2. Insert Batteries:** Insert 1 AA battery into the mouse and 1 AA battery into the keyboard (batteries not included). Ensure correct polarity.
- 3. Connect the USB Receiver:** Plug the USB receiver into an available USB port on your computer, laptop, or desktop PC.
- 4. Power On:** Turn on the power switch located on the underside of the mouse. The keyboard does not have a separate power switch; it activates when batteries are inserted and the receiver is connected.
- 5. Start Using:** Your keyboard and mouse should now be automatically connected and ready for use. The 2.4G wireless technology ensures a stable connection within a 10-meter range.



PLUG AND PLAY

Image: A laptop and the seenda wireless keyboard and mouse, illustrating the simple plug-and-play setup with the USB receiver.

5. OPERATING INSTRUCTIONS

5.1 Keyboard Usage

The keyboard is designed for comfortable and efficient typing.

- Comfortable Typing:** The concave key design perfectly fits your fingertips, providing a comfortable typing experience.
- Adjustable Tilt:** Two foldable stands are located at the back of the keyboard. Flip them out to raise the keyboard to a comfortable angle, reducing wrist stress during long typing sessions.

COMFORTABLE TYPING

Built-in foldable keyboard riser, release your wrist pressure
Concave round keys perfectly fit your fingertips



Image: Close-up showing a hand typing on the keyboard, highlighting the concave keys and the foldable riser for ergonomic comfort.

- **Multimedia Hotkeys:** The keyboard features fourteen multimedia hotkeys (F1-F12, plus dedicated keys) for quick access to common functions. These include media playback controls (Play/Pause, Stop, Previous/Next Track), volume control (Volume Up, Volume Down, Mute), and shortcuts for Search, Home, E-mail, and Calculator.

MULTIMEDIA SHORTCUTS




Image: A detailed diagram illustrating the layout and functions of the multimedia shortcut keys on the keyboard.

5.2 Mouse Usage

The mouse offers precise and quiet navigation.

- **Adjustable DPI:** The mouse features 3 adjustable DPI levels (800-1200-1600). Press the DPI switch button (located behind the scroll wheel) to cycle through the sensitivity settings to match your preference and task.
- **Silent & Sensitive:** The mouse is designed for quiet clicks, minimizing noise in quiet environments, while maintaining high sensitivity for accurate tracking.



Image: A close-up of the mouse, highlighting its silent operation and the 3 adjustable DPI settings (800-1200-1600).

6. MAINTENANCE

To ensure the longevity and optimal performance of your seenda Wireless Keyboard and Mouse Combo, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the surfaces of the keyboard and mouse. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** When the keyboard or mouse performance degrades (e.g., delayed response, erratic movement), it's time to replace the batteries. Open the battery compartments and replace the old batteries with fresh AA batteries, ensuring correct polarity.
- **Storage:** When not in use for extended periods, it is recommended to turn off the mouse to conserve battery life. Store the combo in a cool, dry place away from direct sunlight and extreme temperatures.
- **USB Receiver:** Keep the USB receiver in a safe place when not plugged into your computer. It can be stored inside the mouse battery compartment for safekeeping during travel or storage.

7. TROUBLESHOOTING

If you encounter any issues with your seenda Wireless Keyboard and Mouse Combo, please refer to the following common solutions:

- **No Connection / Not Responding:**

- Ensure the USB receiver is securely plugged into a working USB port on your computer. Try a different USB port.
- Check the batteries in both the keyboard and mouse. Replace them if they are low or depleted.
- Make sure the mouse's power switch is in the 'ON' position.
- Move the keyboard and mouse closer to the USB receiver to rule out range issues.
- Restart your computer.

- **Lagging or Intermittent Connection:**

- Ensure there are no large metal objects or other wireless devices (like Wi-Fi routers, cordless phones) operating too close to the receiver, which might cause interference.
- Replace batteries, even if they seem to have some charge left.

- **Mouse Cursor Erratic or Not Moving Smoothly:**

- Clean the optical sensor on the underside of the mouse.
- Ensure you are using the mouse on a suitable surface (non-reflective, non-transparent). A mouse pad is recommended.
- Adjust the DPI setting to a lower value if the cursor is too sensitive.

- **Keys Not Registering / Sticky Keys:**

- Check for debris under the keys and clean the keyboard.
- Replace keyboard batteries.

If the problem persists after trying these steps, please contact seenda customer support for further assistance.

8. SPECIFICATIONS

| Feature | Detail |
|-------------------------|---|
| Brand | seenda |
| Model Number | B0BXWLFXPR |
| Color | Black and Purple |
| Connectivity Technology | Radio Frequency, USB (2.4GHz Wireless) |
| Special Features | Ergonomic, Full Size, Comfortable, Quiet Typing, Adjustable DPI |
| Compatible Devices | Laptop, Computer, PC, Desktop, Notebook |
| Item Weight | 1.94 pounds |
| Package Dimensions | 17.63 x 5.98 x 2.32 inches |
| Date First Available | March 10, 2023 |

FULL SIZE DESIGN



17.24 inch

0.72 inch
1.3 inch



Image: A diagram showing the full size design of the keyboard and mouse with their respective dimensions in inches.

9. WARRANTY AND SUPPORT

seenda products are manufactured with high-quality standards. For information regarding warranty coverage, please refer to the product packaging or the official seenda website. If you require technical support or have any questions not covered in this manual, please contact seenda customer service through the retailer's platform or the brand's official support channels.



Image: The seenda wireless keyboard and mouse combo set up on a desk next to a computer monitor, demonstrating its use in a typical workspace.

© 2023 seenda. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Related Documents

| | |
|---|---|
|  | <p><u>Seenda MOE300 Ergonomic Wireless Mouse User Manual</u></p> <p>User manual for the Seenda MOE300 ergonomic wireless mouse, featuring 2.4G connectivity, USB & Type-C receiver, and rechargeable design. Available in English, German, French, and Japanese.</p> |
|  | <p><u>Seenda JPX006 2.4G Wireless Backlight Keyboard Mouse Combo User Manual</u></p> <p>Comprehensive user manual for the Seenda JPX006 2.4G wireless keyboard and mouse combo. Learn about features, setup, lighting controls, system compatibility, and specifications.</p> |
|  | <p><u>Seenda COE203 3-Device Wireless Bluetooth Keyboard and Mouse Combo User Manual</u></p> <p>User manual for the Seenda COE203 wireless keyboard and mouse combo, detailing setup, features, specifications, and troubleshooting for this 3-device Bluetooth and 2.4G wireless input solution.</p> |
|  | <p><u>Seenda 2.4G Wireless Keyboard and Mouse Combo User Manual</u></p> <p>User manual for the Seenda 2.4G Wireless Keyboard and Mouse Combo (Model KB7001+MS2237), providing setup, pairing, key functions, FAQs, and safety warnings.</p> |