

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Ohniyou](#) /

› [Ohniyou 52-Inch Farmhouse Ceiling Fan with Lights and Remote Instruction Manual](#)

Ohniyou GLX050

Ohniyou 52-Inch Farmhouse Ceiling Fan with Lights and Remote

Model: GLX050

Brand: Ohniyou

PRODUCT OVERVIEW

The Ohniyou 52-inch Farmhouse Ceiling Fan is designed to provide optimal airflow and lighting for various indoor and outdoor spaces. Featuring a rustic design with a caged light fixture, it includes 6 blades and 5 E26 light bases (bulbs not included). Its reversible DC motor ensures efficient air circulation for both summer cooling and winter warmth. The fan operates quietly with a noise level of $\leq 40\text{dB}$ and includes a convenient timer function for energy saving and peaceful sleep. Suitable for medium to large rooms, it can be installed on flat ceilings or those with a slant up to 15 degrees.



Figure 1: Ohniyou 52-inch Farmhouse Ceiling Fan with Lights and Remote.

SAFETY INFORMATION

- Always turn off power at the circuit breaker before installation or maintenance.

- Ensure all electrical connections comply with local codes and ordinances.
- Mount the fan to a ceiling joist or a suitable support structure capable of holding the fan's weight.
- Do not bend the blade holders during installation or cleaning.
- Keep hands, clothing, and other objects clear of the fan blades when the fan is operating.
- This fan is suitable for both indoor and covered outdoor use. Ensure it is not exposed directly to water.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Ceiling Fan Motor Assembly
- Fan Blades (6x)
- Caged Light Fixture
- Remote Control and Receiver
- Downrod (Standard and Extended options)
- Mounting Bracket and Hardware
- Wire Nuts and Connectors
- Instruction Manual

Note: E26 light bulbs are not included and must be purchased separately.

SETUP AND INSTALLATION

Proper installation is crucial for the safe and efficient operation of your ceiling fan. Please follow these steps carefully. For a visual guide, refer to the official installation video provided below.

Installation Steps Overview:

- 1. Prepare the Mounting Location:** Ensure the electrical box is securely mounted to a ceiling joist and can support the fan's weight. Turn off power at the circuit breaker.
- 2. Assemble the Light Fixture:** Connect the wiring for the light sockets and secure the light fixture to the fan motor assembly.
- 3. Attach the Fan Blades:** Securely fasten each of the six fan blades to the motor housing using the provided screws.
- 4. Install the Downrod:** Insert the downrod through the canopy and connect it to the fan motor. Feed the electrical wires through the downrod.
- 5. Mount the Fan:** Lift the fan assembly and hang it from the mounting bracket. Make all necessary electrical connections (live, neutral, ground, and remote receiver wires).
- 6. Secure the Canopy:** Slide the canopy up to the ceiling and secure it to the mounting bracket.
- 7. Install Light Bulbs:** Screw in the E26 light bulbs (not included) into the sockets.
- 8. Test Operation:** Restore power and test all fan and light functions using the remote control.

Your browser does not support the video tag.

Video 1: Step-by-step installation guide for the Ohniyou 52 Inch Farmhouse Ceiling Fan with Lights.

Your browser does not support the video tag.

Video 2: Overview of the Ohniyou 52" Farmhouse Ceiling Fan with Light Fixture, showcasing its features and design.

Your browser does not support the video tag.

Video 3: Demonstration of the Ohniyou 52 Inch Ceiling Fan with Lights, highlighting its quiet operation and remote control functions.

OPERATING INSTRUCTIONS

Your Ohniyou ceiling fan comes with a remote control for convenient operation of all its features.

Remote Control Functions:



Figure 2: Layout of the remote control for the Ohniyou Ceiling Fan.

- **Fan ON/OFF:** Press the central "FAN/OFF" button to turn the fan on or off.
- **Fan Speed Control (1-6):** Select desired fan speed from 1 (lowest) to 6 (highest).
- **Light ON/OFF:** Press the "LIGHT ON/OFF" button to control the light fixture.
- **Natural Wind Mode:** Activates a varying fan speed to simulate natural breeze.
- **Forward/Reverse Rotation (F/R):** Use the "F" button for forward (summer downdraft) and "R" button for reverse (winter

updraft) rotation.

- **Timer Setting (1H/2H/4H):** Set the fan to automatically turn off after 1, 2, or 4 hours.

- **Mute Function:** The fan operates with a low noise level (≤ 40 dB) for quiet operation.

Seasonal Operation:




Figure 3: Illustration of fan rotation for different seasons.

- **Summer Downdraft Mode:** Set the fan to rotate counter-clockwise (forward) to create a cooling breeze.
- **Winter Updraft Mode:** Set the fan to rotate clockwise (reverse) to circulate warm air trapped near the ceiling, distributing it throughout the room.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents.

- **Light Bulb Replacement:** Ensure power is off before replacing bulbs. This fan uses 5 E26 light bases.
- **Tighten Fasteners:** Periodically check and tighten all screws and fasteners on the fan blades and mounting hardware.



Figure 4: Close-up view of the light sockets and fan base for maintenance reference.

TROUBLESHOOTING

If you encounter issues with your Ohniyou ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not operate.	No power, loose wiring, remote control issue.	Check circuit breaker. Ensure all wires are securely connected. Verify remote control batteries and pairing.
Light flickers or does not turn on.	Loose bulb, faulty bulb, wiring issue.	Tighten or replace bulbs. Check light fixture wiring connections.
Fan is noisy.	Loose screws, unbalanced blades, motor issue.	Tighten all screws. Check blade balance (a balancing kit may be needed). Ensure fan is securely mounted.
Remote control not working.	Dead batteries, not paired, interference.	Replace batteries. Re-pair remote with receiver according to manual instructions. Reduce interference sources.

SPECIFICATIONS

- **Brand:** Ohniyou
- **Model Name:** GLX050
- **Color:** Black
- **Electric Fan Design:** Ceiling Fan
- **Power Source:** AC/DC
- **Style:** Farmhouse
- **Product Dimensions:** 52"D x 52"W x 18.9"H
- **Room Type:** Kitchen, Bedroom, Living Room, Patio, Dining Room
- **Special Feature:** Timer
- **Recommended Uses:** Cooling
- **Wattage:** 60 watts

- **Finish Type:** Painted
- **Theme:** Rustic
- **Voltage:** 220 Volts (DC)
- **Switch Type:** Remote
- **Included Components:** Mounting Hardware, Remote
- **Indoor/Outdoor Usage:** Outdoor, Indoor
- **Item Weight:** 20.8 pounds
- **Country of Origin:** China
- **Installation Method:** Ceiling Mount
- **Number of Pieces:** 1
- **Type of Bulb:** Incandescent, LED (E26 bases)
- **Luminous Flux:** 10000 lumen




Figure 5: Detailed dimensions of the Ohniyou Ceiling Fan.



**Wet Rating:
Dry Indoor
Damp Covered**



Mute Motor for Good Sleep

Motor: Reversible DC Motor

Mounting Type: Downrod Mount

Detail: 6 Black ABS Blades

5 x E26 Light Socket: Max 60W Each

Space: Suitable for 12ft x 12ft to 18ft x 18ft

(Bulbs Not Included)




Figure 6: Key features including mute motor for quiet operation and wet rating suitability.



Figure 7: Recommended fan speed settings for various activities (sleeping, entertainment, sports).

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official Ohniyou website. Keep your purchase receipt for warranty claims.