

[Manuals.plus](#) /

> [BLX](#) /

> BLX Sweet Girl Concert Time Building Set 24417 User Manual

BLX 24417

BLX Sweet Girl Concert Time Building Set 24417 User Manual

Model: 24417 | Brand: BLX

1. INTRODUCTION

Welcome to the BLX Sweet Girl Concert Time Building Set! This set allows children to construct a vibrant concert stage with musical instruments and figures, fostering creativity and fine motor skills. This manual provides essential information for assembly, operation, maintenance, and safety.

Recommended Age: Children 3 years and older.

Number of Pieces: 119

2. SETUP AND ASSEMBLY

Follow these steps to assemble your BLX Sweet Girl Concert Time Building Set:

- Unpack Components:** Carefully open the packaging and remove all building blocks and figures. Verify that all 119 pieces are present by comparing them with the parts list provided in the box (if applicable).
- Review Instructions:** Refer to the detailed assembly diagrams included in your product box. These diagrams illustrate the step-by-step process for constructing the concert stage, instruments, and figures.
- Assemble Base:** Begin by connecting the larger base pieces to form the foundation of the concert stage.
- Build Structure:** Follow the diagrams to build the stage arch, backdrop, and platforms using the various colored blocks.
- Add Details:** Attach the smaller decorative elements, microphones, and musical instruments to complete the stage.
- Place Figures:** Position the Sweet Girl figures on the stage to prepare for their performance.



Image 1: The BLX Sweet Girl Concert Time Building Set packaging and the fully assembled concert stage with figures and instruments.

3. OPERATING INSTRUCTIONS (PLAY)

Once assembled, the BLX Sweet Girl Concert Time Building Set is ready for imaginative play:

- **Role-Playing:** Encourage children to create their own concert scenarios, having the figures perform on stage.
- **Creative Reconfiguration:** The modular nature of building blocks allows for rearrangement of stage elements or creation of new structures, fostering creativity.
- **Interaction:** The figures can be moved and positioned freely on the stage, interacting with the instruments and each other.



Image 2: A detailed view of the assembled BLX Sweet Girl Concert Time stage, highlighting the figures and musical instruments.

4. MAINTENANCE

Proper care will ensure the longevity of your building set:

- **Cleaning:** To clean the blocks and figures, gently wipe them with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the plastic or paint.
- **Drying:** Ensure all pieces are completely dry before storing to prevent moisture damage.
- **Storage:** Store the building set in a cool, dry place away from direct sunlight. Keeping the pieces in their original box or a dedicated storage container will help prevent loss and damage.

5. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Missing Pieces:** If you find any pieces missing upon opening the box, please contact the retailer or manufacturer's customer support for assistance.
- **Difficulty Assembling:** If you are having trouble connecting pieces, ensure they are correctly oriented according to the assembly diagrams. Apply gentle, even pressure. Do not force pieces together, as this may cause damage.
- **Loose Connections:** If assembled parts feel loose, double-check that all connecting studs are fully engaged.

6. SPECIFICATIONS

Feature	Detail
Brand	BLX
Model Number	24417
Part Number	8680863032435
Age Range	Children (3+)
Number of Pieces	119

7. SAFETY INFORMATION

Please observe the following safety guidelines:

- **Choking Hazard:** This set contains small parts and is not suitable for children under 3 years of age due to potential choking hazards.
- **Adult Supervision:** Adult supervision is recommended during play, especially for younger children.
- **Inspect Regularly:** Periodically inspect all pieces for damage or wear. Discard any broken or damaged parts to prevent injury.
- **Keep Away from Heat:** Do not expose the product to extreme heat or open flames, as this may cause melting or deformation.

8. WARRANTY AND SUPPORT

For warranty information or customer support regarding your BLX Sweet Girl Concert Time Building Set, please refer to the contact details provided on the product packaging or visit the official BLX website. Keep your proof of purchase for any warranty claims.

© 2023 BLX. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BXZ5CZ86>

More documents and user manuals: <https://manuals.plus/>