

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Yaheetech](#) /

> [Yaheetech Upholstered Dining Chairs Instruction Manual \(Model 614696\)](#)

Yaheetech 614696

Yaheetech Upholstered Dining Chairs Instruction Manual

Model: 614696 | Brand: Yaheetech

1. INTRODUCTION

Thank you for choosing Yaheetech Upholstered Dining Chairs. This manual provides essential information for the safe and correct assembly, operation, and maintenance of your new chairs. Please read these instructions thoroughly before beginning assembly and retain them for future reference.

2. PRODUCT OVERVIEW

The Yaheetech Upholstered Dining Chairs are designed for comfort and style, featuring a button-tufted backrest, durable fabric, and sturdy rubberwood legs. These chairs are suitable for dining rooms, living rooms, and restaurant settings.



Figure 2.1: Yaheetech Upholstered Dining Chairs in a dining room setting.



Figure 2.2: Multiple views of the dining chair, showcasing its design details.

Key Features:

- **Button-tufted Backrest:** Upholstered in breathable terry fabric with stitched button tufting and bronze-finished nailhead trims.
- **Sturdy Construction:** Crafted with a solid wood frame and rubberwood legs, supporting a maximum weight capacity of 309 lb (140 kg).
- **Adjustable Foot Pads:** Equipped with protective pads on the four legs to prevent floor scratches and allow for minor height adjustments.
- **High-Density Foam Seat:** Provides a comfortable and supportive seating experience.

Your browser does not support the video tag.

Video 2.1: Official product video showcasing the Yaheetech Upholstered Fabric Dining Chairs, highlighting design and features.

3. COMPONENTS LIST

Before assembly, ensure all parts and hardware are present and undamaged. Refer to the diagram below for identification.



Figure 3.1: Exploded view of chair components and hardware.

Package Contents (per chair):

- 1x Backrest
- 1x Seat Cushion
- 2x Front Legs
- 1x Hardware Packet (bolts, washers, Allen wrench)

4. ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately 10-15 minutes per chair. It is recommended to assemble on a soft, clean surface to prevent damage.

- 1. Attach Front Legs:** Carefully align the two front legs with the designated attachment points on the underside of the seat cushion. Secure them using the provided bolts and washers from the hardware packet. Tighten with the Allen wrench.
- 2. Attach Backrest:** Position the backrest against the rear of the seat cushion, ensuring the pre-drilled holes align. Insert the remaining bolts and washers, then tighten securely with the Allen wrench.
- 3. Check Stability:** Once all components are attached, gently shake the chair to ensure all connections are firm and stable. Adjust the foot pads if necessary to level the chair.



Figure 4.1: Adjustable foot pad for leveling and floor protection.

5. USAGE AND CARE

Operating Guidelines:

- Ensure the chair is placed on a stable, level surface before use.
- Do not exceed the maximum weight capacity of 309 pounds (140 kg).
- Avoid standing on the chair or using it as a step stool.

Maintenance:

- **Cleaning:** Wipe clean with a damp cloth. For spills, blot immediately with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Regular Checks:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten if necessary.
- **Floor Protection:** The adjustable foot pads help protect your floors. Ensure they are properly adjusted and replace if worn.



Figure 5.1: Detail of the high-density foam and S-spring cushion for enhanced comfort.

6. SPECIFICATIONS

Feature	Detail
Brand	Yaheetech
Model Number	614696
Color	Beige
Material	Fabric (Terry), Foam, Rubberwood, Bronze
Product Dimensions (D x W x H)	25"D x 18.5"W x 41"H
Seat Depth	18 inches
Maximum Weight Recommendation	309 Pounds (140 kg)
Assembly Required	Yes
Back Style	Tufted Back

Arm Style	Armless
Indoor Outdoor Usage	Indoor

 Max Weight Capacity: 309 lb



Figure 6.1: Detailed product dimensions.

7. TROUBLESHOOTING

Common Issues:

- **Wobbly Chair:** Ensure all bolts are securely tightened. Adjust the foot pads on each leg to level the chair on uneven surfaces.
- **Missing Parts:** If any parts are missing or damaged upon arrival, please contact customer support immediately.
- **Difficulty Assembling:** Review the assembly instructions carefully. Ensure all components are oriented correctly before tightening bolts.

8. WARRANTY AND SUPPORT

Yaheetech offers a 30-day easy return policy for this product. For any questions, concerns, or support needs, please contact Yaheetech Customer Support through your purchase platform. Please have your model number

(614696) and purchase details ready for faster service.