

[Manuals.plus](#) /

> [VASAGLE](#) /

> VASAGLE 4-Tier Slim Kitchen Cart Instruction Manual

VASAGLE LRC033B01

VASAGLE 4-Tier Slim Kitchen Cart Instruction Manual

Model: LRC033B01

PRODUCT OVERVIEW

The VASAGLE 4-Tier Slim Kitchen Cart is a versatile storage solution designed for small spaces. It features a sturdy steel frame, durable particleboard top, and mesh shelves, making it suitable for various rooms such as the kitchen, bathroom, office, living room, and bedroom. Equipped with four smooth-gliding wheels and a convenient handle, this cart offers easy mobility.





Figure 1: VASAGLE 4-Tier Slim Kitchen Cart (Rustic Brown and Black)

SAFETY INFORMATION

For safety reasons, children are prohibited from climbing on or playing with the kitchen shelf. Do not exceed the maximum total static load capacity of 20 kg (44 lbs). Do not place this kitchen cart in a humid environment to avoid damage. If water is accidentally spilled, wipe it immediately with a dry cloth.

PACKAGE CONTENTS

Please ensure all components are present before assembly:

- 1 x Kitchen Cart
- 1 x Assembly Kit (includes all necessary hardware)
- 1 x Instruction Manual

SETUP AND ASSEMBLY

The VASAGLE 4-Tier Slim Kitchen Cart is designed for easy assembly. Follow the illustrated instructions and use the numbered parts provided in the assembly kit.

Assembly Steps:

1. Unpack all components and verify against the parts list in the manual.
2. Attach the wheels to the base frame. Ensure they are securely fastened.
3. Assemble the main frame structure using the provided screws and tools.
4. Slide the mesh shelves into their designated slots on the frame. The raised edges of the shelves should face upwards to prevent items from falling.
5. Attach the top particleboard panel to the upper frame.
6. Secure the handle to the side of the top panel.
7. Once assembled, gently push the cart to ensure all wheels rotate freely and the structure is stable.





Figure 2: Detailed dimensions and structural components for assembly.



Bord surélevé pour empêcher les objets de tomber



Poignée métallique robuste



Roulette pivotante à 360°

Figure 3: Key features including the robust metal handle, 7 cm raised shelf edges, and 360-degree swivel wheels for easy maneuverability.

OPERATING AND USAGE

This 4-tier cart is designed to maximize storage in compact areas. Its slim profile (22 cm width) allows it to fit into narrow spaces in various rooms.

- **Mobility:** The four smooth-gliding wheels and integrated handle allow you to easily move the cart wherever needed,

from kitchen to living room or bathroom.

- **Storage Capacity:** The cart features a top surface for frequently accessed items and three mesh shelves below. The shelves are designed with raised edges (7 cm high) to prevent jars, bottles, and other items from falling off.
- **Versatile Use:** Ideal for storing spices, oils, canned goods, kitchen utensils, bathroom essentials, office supplies, or small decorative items.



Figure 4: The cart positioned in a kitchen, demonstrating its utility for storing various kitchen items.

Grande capacité

4 niveaux



Figure 5: Visual representation of the cart's large capacity across its four levels, suitable for various items.



Facile à déplacer

Les 4 roulettes glissent en douceur



Figure 6: The cart's slim design, measuring 22 cm in width, allows it to fit into narrow spaces.



Figure 7: The cart serving as a convenient mobile storage unit in a kitchen environment.

MAINTENANCE

To ensure the longevity and appearance of your VASAGLE Kitchen Cart, follow these maintenance guidelines:

- **Cleaning:** Wipe the cart with a damp cloth and dry immediately. Avoid using abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** In case of accidental spills, especially liquids, wipe them up promptly with a dry cloth to prevent moisture damage to the particleboard and steel components.
- **Environment:** Do not place the cart in excessively humid environments, as this can lead to material degradation.
- **Load Capacity:** Adhere to the maximum static load capacity of 20 kg (44 lbs) to prevent structural damage.

TROUBLESHOOTING

This section addresses common issues you might encounter with your VASAGLE Kitchen Cart.

- **Cart is unstable/wobbly:**
 - Ensure all screws and fasteners are tightened securely.
 - Verify that the cart is placed on a flat, level surface.
- **Wheels do not roll smoothly:**
 - Check for any debris or hair caught in the wheel mechanisms.
 - Ensure the wheels are properly installed and not overtightened.
- **Items falling off shelves:**
 - Confirm that the shelves are installed with the raised edges facing upwards.
 - Do not overload shelves beyond their capacity or place items precariously.

If you encounter issues not listed here or require further assistance, please contact VASAGLE customer support.

SPECIFICATIONS

Feature	Detail
Brand	VASAGLE
Model Number	0194343045832 (LRC033B01)
Color	Rustic Brown + Black
Dimensions (L x W x H)	22 x 45.5 x 77 cm (8.7 x 17.9 x 30.3 inches)
Weight	3.6 kg (7.9 lbs)
Material	Engineered Wood (Particleboard), Alloy Steel
Shelf Type	Multi-tier shelf (Mesh)
Number of Tiers	4
Maximum Weight Recommendation	20 kg (44 lbs)
Assembly Required	Yes
Care Instructions	Wipe with a damp cloth and dry

WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available data. For details regarding warranty coverage, returns, or technical support, please refer to the official VASAGLE website or contact their customer service directly.

You can often find support contact information on the product packaging or the brand's official online store.

OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were found in the provided data.

